



D-Link[®]

4 PORT ADSL 2 ROUTER ANNEX B
DSL-2540U

**QUICK
INSTALLATION
GUIDE**

РУКОВОДСТВО ПО БЫСТРОЙ УСТАНОВКЕ

CONTENTS OF PACKAGING

CONTENTS



INSTALLATION CD
INCLUDES SET-UP WIZARD & TECHNICAL MANUAL



4 PORT ADSL 2 ROUTER ANNEX B
DSL-2540U



12V 0.5A POWER ADAPTER
ADAPTER



ETHERNET CABLE (RJ-45 CABLE)
CONNECT THE ROUTER TO YOUR PC DURING SET-UP



PHONE CABLE



SPLITTER



If any of these items are missing from your packaging contact your reseller

PRODUCT SETUP

CD SETUP WIZARD



INSTALLATION CD

The Setup Wizard on the Installation CD contains all of the instructions required to set up the DSL-2540U.



INSERT CD

Insert the CD into the CD drive of your computer. The Setup Wizard should start automatically. Make sure that your Internet connection is active. (Do not plug in the DSL-2540U yet)



SETUP WIZARD

Select your language from the drop-down menu and follow the steps within the wizard to complete setting up the DSL-2540U.

ADVANCED SETUP (ACCESS VIA IP ADDRESS)

To configure DSL-2540U manually (without the set-up CD) connect your computer to the DSL-2540U using the ethernet cable provided. Then connect the power cable on the DSL-2540U. The power light will display as solid green.

Then simply open a browser window and enter the IP address in the browser address field:

IP ADDRESS: <http://192.168.1.1>

USERNAME: admin

PASSWORD: admin

TROUBLESHOOTING

SETUP AND CONFIGURATION PROBLEMS

1. HOW DO I CONFIGURE MY DSL-2540U ROUTER WITHOUT THE CD?

- Connect your PC to the router using an Ethernet cable.
- Open a web browser and enter the address <http://192.168.1.1>
- The default username is admin. The default password is admin.
- If you have changed the password and can not remember it, you will need to reset the router to set the password back to admin.

2. HOW DO I RESET MY DSL-2540U ROUTER TO FACTORY DEFAULT SETTINGS?

- Ensure the router is powered on.
 - Press and hold the reset button on the rear of the device for 10 seconds.
- Note: Resetting the router to factory default will erase the current configuration settings. To re-configure your settings, log into the router as outlined in question 1, then run the Setup Wizard.

3. WHY CAN I NOT GET AN INTERNET CONNECTION?

For ADSL users please contact your ISP to make sure the service has been enabled/connected by your ISP and that your ISP username and password is correct.

КОМПЛЕКТ ПОСТАВКИ

СОДЕРЖИМОЕ



УСТАНОВОЧНЫЙ CD-ДИСК

СОДЕРЖИТ МАСТЕР УСТАНОВКИ И РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ



4 PORT ADSL 2 ROUTER ANNEX B

DSL-2540U



АДАПТЕР ПИТАНИЯ 12В, 0,5А

АДАПТЕР



КАБЕЛЬ ETHERNET (С РАЗЪЕМОМ RJ-45)


ДЛЯ ПОДКЛЮЧЕНИЯ МАРШРУТИЗАТОРА К КОМПЬЮТЕРУ ВО ВРЕМЯ УСТАНОВКИ



ТЕЛЕФОННЫЙ КАБЕЛЬ



СПЛИТТЕР



Если что-либо из перечисленного отсутствует, пожалуйста, обратитесь к поставщику

УСТАНОВКА

МАСТЕР УСТАНОВКИ С CD-ДИСКА



УСТАНОВОЧНЫЙ CD-ДИСК

Мастер установки на CD-диске содержит все инструкции, необходимые для установки DSL-2540U.



ВСТАВЬТЕ CD-ДИСК

Вставьте диск в привод CD-ROM. Запуск Мастера установки произойдет автоматически. Убедитесь, что Интернет-соединение активно. (Не подключайте пока DSL-2540U).



МАСТЕР УСТАНОВКИ

Выберите нужный язык из списка и выполните шаги по установке DSL-2540U.

РАСШИРЕННАЯ УСТАНОВКА (ДОСТУП НА ОСНОВЕ IP-АДРЕСА)

Для настройки беспроводного маршрутизатора вручную (без CD-диска) подключите DSL-2540U к компьютеру с помощью входящего в комплект поставки кабеля Ethernet. Затем подключите кабель питания к DSL-2540U. Индикатор питания загорится зеленым светом.

Откройте окно браузера и введите IP-адрес в поле адреса браузера:

IP-АДРЕС: <http://192.168.1.1>

ИМЯ ПОЛЬЗОВАТЕЛЯ: admin

ПАРОЛЬ: admin

ПОИСК И УСТРАНЕНИЕ НЕИСПРАВНОСТЕЙ

ПРОБЛЕМЫ УСТАНОВКИ И НАСТРОЙКИ

1. КАК НАСТРОИТЬ DSL-2540U, ЕСЛИ CD-ДИСК ОТСУТСТВУЕТ?

- Подключите компьютер к маршрутизатору с помощью кабеля Ethernet.
- Откройте Web-браузер и введите адрес <http://192.168.1.1>
- Имя пользователя по умолчанию 'admin'. Пароль по умолчанию 'admin'.
- Если пароль был изменен и забыт, то необходимо сбросить настройки маршрутизатора, чтобы снова установить пароль 'admin'.

2. КАК ВЕРНУТЬ МАРШРУТИЗАТОР DSL-2540U К ЗАВОДСКИМ НАСТРОЙКАМ ПО УМОЛЧАНИЮ?

- Убедитесь, что маршрутизатор включен.
 - Нажмите и удерживайте кнопку 'reset' в течение 10 секунд.
- Внимание: Сброс маршрутизатора к заводским настройкам по умолчанию сотрет все выполненные настройки. Для изменения настроек выполните последовательность действий, указанную в вопросе 1, а затем запустите Мастер установки.

3. ПОЧЕМУ ОТСУТСТВУЕТ ИНТЕРНЕТ-СОЕДИНЕНИЕ?

Пользователям ADSL необходимо связаться с провайдером и убедиться, что услуга активирована / подключена, имя пользователя и пароль верные.

ТЕХНИЧЕСКАЯ ПОДДЕРЖКА

Обновления программного обеспечения и документация доступны на Интернет-сайте D-Link. D-Link предоставляет бесплатную поддержку для клиентов в течение гарантийного срока.

Клиенты могут обратиться в группу технической поддержки D-Link по телефону или через Интернет.

Техническая поддержка D-Link:

+7(495) 744-00-99

Техническая поддержка через Интернет

<http://www.dlink.ru>

e-mail: support@dlink.ru

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Australia:

Tel: 1300-766-868

24/7(24Hrs, 7days a week) technical support

<http://www.dlink.com.au>

e-mail: support@dlink.com.au

India:

Customer Support: - 1800-233-0000 (MTNL & BSNL Toll Free) or +91-832-2885700 (GSM, CDMS & Others)

E-Mail Address: - helpdesk@dlink.co.in, techsupport@dlink.co.in

Website: - www.dlink.co.in

Indonesia, Malaysia, Singapore and Thailand:

Tel: +62-21-5731610 (Indonesia)

Tel: 1800-882-880 (Malaysia)

Tel: +65 6501 4200 (Singapore)

Tel: +66-2-719-8978/9 (Thailand)

24/7, for English Support Only

<http://www.dlink.com.sg/support/>

e-mail: support@dlink.com.sg

Korea:

Tel: +82-2-2028-1815

Monday to Friday 9:00am to 6:00pm

<http://www.d-link.co.kr>

e-mail: arthur@d-link.co.kr

New Zealand:

Tel: 0800-900-900

24/7(24Hrs, 7days a week) technical support

<http://www.dlink.co.nz>

e-mail: support@dlink.co.nz

Egypt:

Tel: +202-2919035 or +202-2919047

Sunday to Thursday 9:00am to 5:00pm

<http://support.dlink-me.com>

Email: support.eg@dlink-me.com

Iran:

Te: +98-21-88880918,19

Saturday to Thursday 9:00am to 5:00pm

<http://support.dlink-me.com>

Email : support.ir@dlink-me.com & support@dlink.ir

TECHNICAL SUPPORT

You can find software updates and user documentation on the D-Link website.

Tech Support for customers in

Israel:

Magshimim 20, Petach Tikva 49348

Website: www.dlink.co.il

Main Tel: 972-3-9215173

Customer Support Tel: 972-3-9212886

Pakistan:

Tel: +92-21-4548158 or +92-21-4548310

Monday to Friday 10:00am to 6:00pm

<http://support.dlink-me.com>

E-mail: zkashif@dlink-me.com

South Africa and Sub Sahara Region:

Tel: +27-12-665-2165

08600 DLINK (for South Africa only)

Monday to Friday 8:30am to 9:00pm South Africa Time

<http://www.d-link.co.za>

Turkey:

Tel: +90-212-2895659

Monday to Friday 9:00am to 6:00pm

<http://www.dlink.com.tr>

e-mail: turkiye@dlink-me.com

e-mail: support@d-link.co.za

U.A.E and North Africa:

Tel: +971-4-4278127 (U.A.E)

Sunday to Thursday 9.00AM to 6.00PM GMT+4

Web: <http://www.dlink-me.com>

E-mail: support.me@dlink-me.com

Saudi ARABIA (KSA):

Telephone : +966 01 217 0008

Facsimile : +966 01 217 0009

e-mail: Support.sa@dlink-me.com

Saturday to Wednesday 9.30AM to 6.30PM

Thursdays 9.30AM to 2.00 PM

NOTES

