

Quick Installation Guide DWA-110

Wireless G USB Adapter

Package Contents

If any of the items are missing, please contact your reseller.



DWA-110
Wireless G USB Adapter



CD-ROM
(Installation CD, Manual
and Warranty)




Cradle


Quick Installation

Warning: Do NOT install the Adapter into your computer before installing the driver software from the D-Link CD.

1 Remove the D-Link CD-ROM.



2 A. Insert D-Link CD-ROM into your computer.
(OS requirement: WINDOWS 98SE/ ME/ 2000/ XP/ Vista)



B. Click "Install Driver"
(Follow the instruction on the screen and for more information please click " View Manual")

