

## Quick Installation Guide

### DWA-120

Wireless 108G USB Adapter

## Package Contents

If any of the items are missing, please contact your reseller.



DWA-120  
Wireless 108G USB  
Adapter



CD-ROM  
(Installation CD, Manual  
and Warranty)




Cradle


## Quick Installation

**Warning:** Do NOT install the Adapter into your computer before installing the driver software from the D-Link CD.

- 1 Remove the D-Link Click and Connect CD.



- 2 A. Insert D-Link CD-ROM into your computer.  
(OS requirement: WINDOWS 2000/XP/Vista)



- B. Click "Install Driver"  
(Follow the instruction on the screen and for more information please click "View Manual")



# Troubleshooting

---

## 1. If I've lost my CD what can I do?

The CD contains software drivers and manual which can be obtained from D-Link (see Technical Support below). Windows 2000, XP, Vista in most cases will automatically install the correct drivers.

## 2. If I've forgotten my wireless encryption key?

The wireless encryption key is configured at the Wireless Access Point, Router or DSL Modem Router. If you are unable to obtain your encryption key, the only solution would be to re-configure your Access Point/Router to use a new encryption key. Please contact your Wireless Access Point/Router/DSL Modem Router manufacturer.

## 3. Why can't I get a wireless connection?

- Check that your DWA-120 is plugged in properly to the USB port or try to plug the DWA-120 into another USB port if available.
- The LED on the DWA-120 should be lit, otherwise there could be a physical fault on the USB port or the driver is not installed properly.
- Ensure that the wireless settings on the DWA-120 match the settings on your Access Point/Router. Please check and confirm your settings for.

Wireless Network Name (SSID)

Wireless Encryption Key

Wireless Security Method (E.g. WEP, WPA2)

To check whether a Wireless connection has been made, in the Windows System Tray (bottom right). Red means no valid connections have been made.

- Check that your Internet is working fine on existing computers.
- Ensure that you have followed and completed the software installation process, otherwise, please re-install the software. The LED on the DWA-120 should come on after software installation.

## 4. Which Operating Systems does the DWA-120 support?

The DWA-120 support all popular Operating Systems including Microsoft Windows XP/2000/Vista.

**Note:** If you are unable to connect, see the Troubleshooting chapter of the product manual in the **D-Link DWA-120 Wireless 108G USB Adapter CD**