



D-Link

CLI Reference Guide

DES-1210-28/ME

Metro Ethernet Managed Switch

V1.1



Information in this document is subject to change without notice.

© 2009 D-Link Computer Corporation. All rights reserved.

Reproduction in any manner whatsoever without the written permission of D-Link Computer Corporation is strictly forbidden.

Trademarks used in this text: D-Link and the D-Link logo are trademarks of D-Link Computer Corporation; Microsoft and Windows are registered trademarks of Microsoft Corporation.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. D-Link Computer Corporation disclaims any proprietary interest in trademarks and trade names other than its own.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with this user's guide, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CE Mark Warning

This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Warnung!

Dies ist ein Produkt der Klasse A. Im Wohnbereich kann dieses Produkt Funkstörungen verursachen. In diesem Fall kann vom Benutzer verlangt werden, angemessene Massnahmen zu ergreifen.

Precaución!

Este es un producto de Clase A. En un entorno doméstico, puede causar interferencias de radio, en cuyo caso, puede requerirse al usuario para que adopte las medidas adecuadas.

Attention!

Ceci est un produit de classe A. Dans un environnement domestique, ce produit pourrait causer des interférences radio, auquel cas l'utilisateur devrait prendre les mesures adéquates.

Attenzione!

Il presente prodotto appartiene alla classe A. Se utilizzato in ambiente domestico il prodotto può causare interferenze radio, nel cui caso è possibile che l'utente debba assumere provvedimenti adeguati.

VCCI Warning

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

January, 2012

Table of Contents

INTRODUCTION	1
USING THE CONSOLE CLI	3
COMMAND SYNTAX	7
BASIC SWITCH COMMANDS	10
enable password encryption.....	10
disable password encryption.....	11
create account.....	11
config account.....	12
show account.....	13
delete account.....	13
show session.....	14
show switch.....	14
enable web.....	15
disable web.....	16
enable autoconfig.....	16
disable autoconfig.....	17
show autoconfig.....	17
save.....	17
reboot.....	18
reset.....	19
logout.....	19
ping.....	20
enable telnet.....	20
disable telnet.....	21
show tech support.....	21
SMTP SERVER COMMANDS	23
enable smtp.....	23
disable smtp.....	23
config smtp.....	24
show smtp.....	24
smtp sent_testmsg.....	25
MODIFY BANNER AND PROMPT COMMANDS	26
config command_prompt.....	26
config greeting_message.....	27
show greeting_message.....	28
SWITCH PORT COMMANDS	29
config ports.....	29
show ports.....	30
LOOPBACK DETECTION COMMANDS	31
config loopdetect.....	31
config loopdetect mode.....	31
config loopdetect ports.....	32
config loopdetect.....	32
show loopdetect.....	33
DOS PREVENTION COMMANDS	34

config dos_prevention dos_type.....	34
show dos_prevention.....	35
clear dos_prevention counters.....	36
enable dos_prevention trap_log.....	36
disable dos_prevention trap_log.....	37
PPPOE CIRCUIT ID INSERTION COMMANDS	38
config pppoe circuit_id_insertion state.....	38
config pppoe circuit_id_insertion ports.....	39
show pppoe circuit_id_insertion.....	39
show pppoe circuit_id_insertion ports.....	40
DHCP SERVER SCREENING COMMANDS	41
config filter dhcp_server.....	41
show filter dhcp_server.....	42
config dhcp_server screening ports.....	43
show dhcp_server screening.....	43
IP-MAC-PORT BINDING COMMANDS	45
create address_binding ip_mac ipaddress.....	45
config address_binding ip_mac ports.....	46
config address_binding auto_scan.....	46
delete address_binding.....	47
show address_binding.....	48
show address_binding auto_scan list.....	49
enable address_binding dhcp_snoop.....	49
disable address_binding dhcp_snoop.....	49
NETWORK MANAGEMENT (SNMP) COMMANDS.....	51
create snmp user.....	53
delete snmp user.....	54
show snmp user.....	54
create snmp view.....	55
delete snmp view.....	56
show snmp view.....	56
create snmp community.....	57
delete snmp community.....	57
show snmp community.....	58
config snmp engineID.....	58
show snmp engineID.....	59
create snmp group.....	59
delete snmp group.....	61
show snmp global state.....	61
show snmp groups.....	61
create snmp host.....	62
delete snmp host.....	63
show snmp host.....	64
enable trusted_host.....	64
disable trusted_host.....	65
create trusted_host.....	65
show trusted_host.....	65

delete trusted_host.....	66
enable snmp traps.....	67
disable snmp traps.....	67
enable snmp authenticate trap.....	67
disable snmp authenticate trap.....	68
show snmp traps.....	68
config syslocation.....	69
config sysname.....	69
enable snmp.....	69
disable snmp.....	70
enable snmp DHCP_ screening traps.....	70
disable snmp DHCP_ screening traps.....	71
enable snmp IMPB_ violation traps.....	71
disable snmp IMPB_ violation traps.....	71
enable snmp fiber_port_link traps.....	72
disable snmp fiber_port_link traps.....	72
enable snmp firmware_upgrade_state traps.....	73
disable snmp firmware_upgrade_state traps.....	73
enable snmp LBD traps.....	73
disable snmp LBD traps.....	74
enable snmp port_security_violation traps.....	74
disable snmp port_security_violation traps.....	75
enable snmp rstpport_state_change traps.....	75
disable snmp rstpport_state_change traps.....	76
enable snmp system_device_bootup traps.....	76
disable snmp system_device_bootup traps.....	76
enable snmp twistedpair_port_link traps.....	77
disable snmp twistedpair_port_link traps.....	77
enable snmp duplicate_IP_detected traps.....	78
disable snmp duplicate_IP_detected traps.....	78
DOWNLOAD/UPLOAD COMMANDS.....	79
download.....	79
upload.....	80
DHCP RELAY COMMANDS.....	82
enable dhcp_relay.....	82
disable dhcp_relay.....	83
config dhcp_relay add ipif system.....	83
config dhcp_relay delete ipif system.....	84
config dhcp_relay.....	84
config dhcp_relay option_82.....	85
show dhcp_relay.....	86
enable dhcp_local_relay.....	86
disable dhcp_local_relay.....	87
config dhcp_local_relay vlan.....	87
show dhcp_local_relay.....	88
GRATUITOUS ARP COMMANDS.....	89
config gratuitous_arp send ipif_status_up.....	89

config gratuitous_arp send dup_ip_detected	90
config gratuitous_arp learning.....	90
enable gratuitous_arp.....	91
disable gratuitous_arp.....	91
show gratuitous_arp.....	92
config gratuitous_arp send periodically interval	92
NETWORK MONITORING COMMANDS	94
show packet ports	94
show error ports.....	95
show utilization	96
clear counters.....	97
clear log	97
show log	97
enable syslog	98
disable syslog	98
show syslog	99
create syslog host.....	99
config syslog host.....	101
delete syslog host.....	103
show syslog host.....	104
cable diagnostic port.....	104
SPANNING TREE COMMANDS	106
config stp	106
config stp ports	107
config stp version	109
config stp fbpdu.....	109
config stp priority	110
enable stp.....	110
disable stp	110
show stp.....	111
show stp ports.....	112
show stp instance.....	113
show stp mst_config_id.....	114
create stp instance_id.....	114
delete stp instance_id.....	115
config stp mst_config_id	115
config stp mst_ports	116
FORWARDING DATABASE COMMANDS	117
create fdb	117
create multicast_fdb.....	118
config multicast_fdb.....	118
config fdb aging_time.....	119
delete fdb	119
enable flood_fdb.....	120
disable flood_fdb.....	120
show flood_fdb.....	121
clear flood_fdb	121

show multicast_fdb.....	121
show fdb	122
config multicast filter	123
show multicast filter port_mode.....	123
create auto_fdb	124
delete auto_fdb.....	124
BROADCAST STORM CONTROL COMMANDS	126
config traffic control.....	126
show traffic control.....	127
config traffic trap.....	127
QOS COMMANDS.....	129
config scheduling	130
show scheduling	131
config bandwidth_control.....	132
show bandwidth_control	132
config cos mac_mapping.....	133
show cos mac_mapping.....	134
delete cos mac_mapping.....	134
config cos ip_mapping	134
show cos ip_mapping	135
delete cos ip_mapping.....	135
config cos mapping.....	136
show cos mapping	136
config cos protocol_mapping	137
show cos protocol_mapping	137
delete cos protocol_mapping.....	138
config cos vlanid_mapping.....	138
show cos vlanid_mapping	139
delete cos vlanid_mapping	139
config cos tos.....	140
show cos tos.....	140
config cos tcp_port_mapping	141
show cos tcp_port_mapping	141
delete cos tcp_port_mapping.....	142
config cos udp_port_mapping	142
show cos udp_port_mapping.....	142
delete cos udp_port_mapping.....	143
config 802.1p user_priority	143
show 802.1p user_priority.....	144
config 802.1p default_priority.....	145
show 802.1p default_priority.....	145
config scheduling_mechanism	146
show scheduling_mechanism	147
config dscp mode.....	147
config dscp_mapping.....	147
show dscp_mapping	148
RMON COMMANDS.....	149

enable rmon	149
disable rmon	150
create rmon alarm	150
delete rmon alarm	151
create rmon collection stats	151
delete rmon collection stats	152
create rmon collection history	152
delete rmon collection history	153
create rmon event	153
delete rmon event	154
show rmon	154
PORT MIRRORING COMMANDS	156
enable mirror	156
disable mirror	156
config mirror target	157
show mirror	158
VLAN COMMANDS	159
create vlan	160
delete vlan	160
config vlan	160
config gvrp	161
config pvid	162
config gvrp timer	162
enable gvrp	163
disable gvrp	163
show vlan	164
show gvrp	164
show gvrp timer	165
enable vlan_trunk	165
disable vlan_trunk	166
show vlan_trunk	166
config vlan_trunk ports	167
enable asymmetric_vlan	167
disable asymmetric_vlan	167
show asymmetric_vlan	168
enable management vlan	168
disable management vlan	168
config management vlan	169
show management vlan	169
Q-IN-Q COMMANDS	171
enable qinq	171
disable qinq	172
show qinq	172
config qinq ports	173
create vlan_translation	173
show vlan_translation	174
delete vlan_translation cvid	174

LINK AGGREGATION COMMANDS.....	176
create link_aggregation	176
delete link_aggregation	177
config link_aggregation.....	177
show link_aggregation.....	178
BASIC IP COMMANDS.....	179
config ipif System	179
show ipif.....	180
BPDU ATTACK PROTECTION COMMANDS.....	181
config bpdu_protection ports.....	181
config bpdu_protection recovery_timer	182
config bpdu_protection.....	183
enable bpdu_protection	183
disable bpdu_protection.....	184
show bpdu_protection	184
MAC NOTIFICATION COMMANDS.....	186
enable mac_notification.....	186
disable mac_notification.....	186
config mac_notification.....	187
config mac_notification ports.....	187
show mac_notification.....	188
show mac_notification ports.....	188
IGMP SNOOPING COMMANDS.....	190
config igmp_snooping	191
config igmp_snooping querier.....	192
config igmp_snooping querier_selection.....	192
config igmp_snooping querier_interval.....	193
config igmp_snooping robustness_variable	193
create igmp_snooping multicast_vlan	194
config igmp_snooping multicast_vlan.....	194
delete igmp_snooping multicast_vlan	195
config igmp_snooping multicast_vlan_group	195
config igmp_snooping data_driven_learning	196
config igmp_snooping data_driven_learning	196
clear igmp_snooping data_driven_group	197
config igmp_snooping max_response_time	197
config router_ports	198
config router_ports_forbidden.....	198
config igmp_access_authentication ports.....	199
show igmp_access_authentication ports.....	199
enable igmp_snooping.....	200
disable igmp_snooping.....	200
show igmp_snooping.....	201
show igmp_snooping group	202
show igmp_snooping forwarding	202
show igmp_snooping host	203
show router_port.....	203

LIMITED IP MULTICAST ADDRESS COMMANDS	205
create mcast_filter_profile.....	205
config mcast_filter_profile profile_id.....	206
config mcast_filter_profile profile_name	206
delete mcast_filter_profile.....	207
show mcast_filter_profile	207
config limited_multicast_addr ports.....	208
show limited_multicast_addr.....	208
config max_mcast_group ports	209
show max_mcast_group ports	209
802.1X COMMANDS	211
enable 802.1x.....	212
disable 802.1x.....	212
show 802.1x.....	213
config 802.1x feap.....	213
show 802.1x auth_state	213
show 802.1x feap status.....	214
show 802.1x auth_configuration	215
config 802.1x auth_parameter ports	216
config 802.1x init	217
config 802.1x auth_protocol.....	218
config 802.1x reauth.....	218
config radius add	218
config radius delete.....	219
config radius	219
show radius.....	220
config 802.1x auth_mode	221
create 802.1x guest_vlan	221
delete 802.1x guest_vlan	222
config 802.1x guest_vlan ports.....	222
show 802.1x guest_vlan	223
create 802.1x user.....	223
show 802.1x user.....	224
delete 802.1x user.....	224
config 802.1x capability ports	225
PORT SECURITY COMMANDS	226
config port_security.....	226
show port_security	227
TIME AND SNTP COMMANDS	228
config sntp	228
show sntp.....	229
enable sntp.....	229
disable sntp.....	230
config time.....	230
config time_zone operator.....	231
config dst.....	231
show time	232

ARP COMMANDS	234
create ArpSpoofing.....	234
show ArpSpoofing.....	235
delete ArpSpoofing.....	235
config arp_aging time.....	236
clear arptable	236
show arprentry	237
show arprentry aging_time	237
BANNER COMMANDS	238
config log_save_timing	238
show log_save_timing.....	239
show log	239
COMMAND HISTORY LIST COMMANDS	240
?	240
show command_history.....	241
dir	242
SSH COMMANDS	243
enable ssh	243
disable ssh.....	244
config ssh algorithm	244
config ssh authmode.....	245
show ssh authmode.....	245
config ssh server	246
show ssh server.....	246
show ssh algorithm.....	247
config ssh user.....	248
show ssh user authmode	248
SSL COMMANDS.....	249
enable ssl	249
disable ssl	249
show ssl	250
download ssl certificate	250
ACCESS AUTHENTICATION CONTROL COMMANDS	252
create authen_login method_list_name	253
config authen_login.....	253
delete authen_login method_list_name	255
show authen_login.....	255
show authen_policy	256
create authen_enable method_list_name	256
config authen_enable.....	257
delete authen_enable method_list_name	258
show authen_enable.....	259
enable authen_policy	259
disable authen_policy	260
config authen application	260
show authen application	261
config authen parameter	262

show authen parameter	262
create authen server_host	263
config authen server_host	264
delete authen server_host	265
show authen server_host	265
create authen server_group	266
config authen server_group	267
delete authen server_group	268
show authen server_host	268
enable admin	269
config admin local_enable	269
LACP COMMANDS	271
config lacp port_priority	271
show lacp	271
LLDP COMMANDS	273
enable lldp	273
disable lldp	274
config lldp message_tx_interval	274
config lldp message_tx_hold_multiplier	275
config lldp reinit_delay	275
config lldp tx_delay	276
show lldp	276
show lldp ports	277
show lldp local_ports	278
show lldp remote_ports	279
config lldp ports	279
show lldp mgt_addr	283
show lldp statistics	283
ACCESS CONTROL LIST COMMANDS	285
create access_profile	286
config access_profile	287
delete access_profile	290
show access_profile	290
create cpu_access_profile	291
config cpu_access_profile	292
delete cpu_access_profile	294
show cpu_access_profile	295
TRAFFIC SEGMENTATION COMMANDS	296
config traffic_segmentation	296
show traffic_segmentation	296
SAFEGUARD COMMANDS	298
config safeguard_engine	298
show safeguard_engine	298
DEVICE SPECIFICATIONS	300
Technical Specifications	300
Cable Lengths	302

INTRODUCTION

The DES-1210-28/ME consists of 24 10/100Mbps ports plus 2 combo 10/100/100/SFP ports and 2 dedicated SFP ports.

The Switch can be managed through the Switch's serial port, Telnet, or the Web-based management agent. The Command Line Interface (CLI) can be used to configure and manage the Switch via the serial port or Telnet interfaces.

This manual provides a reference for all of the commands contained in the CLI. Configuration and management of the Switch via the Web-based management agent is discussed in the Manual. For detailed information on installing hardware please refer also to the Manual.

Accessing the Switch via the Serial Port

The Switch's serial port's default settings are as follows:

- 9600 bps
- No parity
- 8 data bits
- 1 stop bit

A computer running a terminal emulation program capable of emulating a VT-100 terminal and a serial port configured as above then connected to the Switch's serial port via an RJ-45 cable.

With the serial port properly connected to a management computer, the following screen should be visible. If this screen does not appear, try pressing Ctrl+r to refresh the console screen.

```

DES 1210 28/ME Fast Ethernet Switch
Command Line Interface

Firmware: Build 6.00.004
Copyright (C) 2010 D-Link Corporation. All rights reserved.

DES 1210 28/ME login:
Password:

```

Figure 1–1 Initial CLI screen

There is no initial username or password. Just press the Enter key twice to display the CLI input cursor – DES-1210-28/ME:5#. This is the command line where all commands are input.

Setting the Switch's IP Address

Each Switch must be assigned its own IP Address, which is used for communication with an SNMP network manager or other TCP/IP application (for example BOOTP, TFTP). The Switch's default IP address is 10.90.90.90. You can change the default Switch IP address to meet the specification of your networking address scheme.

The Switch is also assigned a unique MAC address by the factory. This MAC address cannot be changed, but can be found on the initial boot console screen – shown below.

```

Boot Procedure
-----
Please wait, loading Runtime image ..... 100%
MAC Address : 00-B2-FD-D0-LL-LB
H/W Version :
F/W Version : 6.00.004
.....

```

Figure 1–2 Boot Screen

The Switch's MAC address can also be found in the Web management program on the Switch Information

(Basic Settings) window in the Configuration folder.

The IP address for the Switch must be set before it can be managed with the Web-based manager. The Switch IP address can be automatically set using BOOTP or DHCP protocols, in which case the actual address assigned to the Switch must be known.

The IP address may be set using the Command Line Interface (CLI) over the console serial port as follows: Starting at the command line prompt, enter the command **config ipif System ipaddress xxx.xxx.xxx.xxx/yyy.yyy.yyy.yyy**. Where the x's represent the IP address to be assigned to the IP interface named System and the y's represent the corresponding subnet mask.

Alternatively, users can enter **config ipif System ipaddress xxx.xxx.xxx.xxx/z**. Where the x's represent the IP address to be assigned to the IP interface named System and the z represents the corresponding number of subnets in CIDR notation.

The IP interface named System on the Switch can be assigned an IP address and subnet mask which can then be used to connect a management station to the Switch's Telnet or Web-based management agent.

```
DES-1220/ME:5#config ipif System ipaddress 10.73.21.11/8
Command: config ipif System ipaddress 10.73.21.11/8

Success.

DES-1220/ME:5#
```

Figure 1–3 Assigning an IP Address

In the above example, the Switch was assigned an IP address of 10.73.21.11 with a subnet mask of 255.0.0.0. The system message Success indicates that the command was executed successfully. The Switch can now be configured and managed via Telnet, SNMP MIB browser and the CLI or via the Web-based management agent using the above IP address to connect to the Switch.

USING THE CONSOLE CLI

The Switch supports a console management interface that allows the user to connect to the Switch's management agent via a serial port and a terminal or a computer running a terminal emulation program. The console can also be used over the network using the TCP/IP Telnet protocol. The console program can be used to configure the Switch to use a SNMP-based network management software over the network.

This chapter describes how to use the console interface to access the Switch, change its settings, and monitor its operation.



NOTE: Switch configuration settings are saved to non-volatile RAM using the save command. The current configuration will then be retained in the Switch's NV-RAM, and reloaded when the Switch is rebooted. If the Switch is rebooted without using the save command, the last configuration saved to NV-RAM is loaded.

Connecting to the Switch

The console interface is used by connecting the Switch to a VT100-compatible terminal or a computer running an ordinary terminal emulator program (for example, the HyperTerminal program included with the Windows operating system) using an RJ-45 serial cable. Your terminal parameters will need to be set to:

- VT-100 compatible
- 9600 bps
- 8 data bits
- No parity
- One stop bit
- No flow control

The same functions may also be accessed over a Telnet interface. Once an IP address for the Switch has been set, a Telnet program can be used (in VT-100 compatible terminal mode) to access and control the Switch. All of the screens are identical, whether accessed from the console port or from a Telnet interface.

After the Switch reboots and you have to log in, the console looks like this:

```

DFS 1210 28/ME Fast Ethernet Switch
Command Line Interface

Firmware: Build 6.00.004
Copyright (C) 2010 D Link Corporation. All rights reserved.

DFS 1210 28/ME login:
Password:

```

Figure 2–1 Initial Console Screen after Logging In

Commands are entered at the command prompt, DES-1210-28/ME:5#

There are a number of helpful features included in the CLI. Entering the ? command displays a list of all of the top-level commands.

```

Command: ?

?
cable diagnostic port
clear arptable
clear counters
clear dos_prevention counters
clear flood_fdb
clear igmp_snooping data_driven_group
clear log
config 802.lp default_priority
config 802.lp user_priority
config 802.lx auth_mode ports
config 802.lx auth_parameter ports
config 802.lx auth_protocol
config 802.lx capability ports
config 802.lx feap
config 802.lx guest_vlan ports
config 802.lx init_port_based ports
config 802.lx reauth port_based ports
config access_profile ip
config access_profile profile_id
CTRL+C LSC q Quit SPNL n Next Page LHILR Next Entry a DLL_

```

Figure 2–2 The ? Command

When entering a command without its required parameters, the CLI displays the prompt: command: config account message and the options listed below.

```

traffic_segmentation          vlan          vlan_trunk

DLS-1210-28/ML:5# config ipif
Command: config ipif

Next possible completions:
System
DLS-1210-28/ML:5# config mirror
Command: config mirror

Next possible completions:
target
DLS-1210-28/ML:5# config vlan
Command: config vlan

Next possible completions:
<vlan_name 20>          vlanid
DLS-1210-28/ML:5# config time
Command: config time

Next possible completions:
<date>
DLS-1210-28/ML:5#

```

Figure 2–3 Example Command Parameter Help

In this case, the command config account was entered with the parameter <username>. The CLI will then prompt to enter the <username> with the message, command: config account. Every command in the CLI has this feature, and complex commands have several layers of parameter prompting.

In addition, after typing any given command plus one space, users can see all of the next possible sub-commands, in sequential order, by pressing the ? key.

To re-enter the previous command at the command prompt, press the up arrow cursor key. The previous command appears at the command prompt.


```

Next possible completions:
<vlan name 20>      vlanid
DFS 1210 28/ME:5# config time
Command: config time

Next possible completions:
<date>
DFS 1210 28/ME:5# config time
Command: config time

Next possible completions:
<date>
DFS 1210 28/ME:5# config vlan
Command: config vlan

Next possible completions:
<vlan name 20>      vlanid
DFS 1210 28/ME:5# config vlan
Command: config vlan

Next possible completions:
<vlan name 20>      vlanid
DFS 1210 28/ME:5#

```

Figure 2–4 Using the Up Arrow to Re-enter a Command

In the above example, the command `config account` was entered without the required parameter `<username>`, the CLI returned the `command: config account` prompt. The up arrow cursor control key was pressed to re-enter the previous command (`config account`) at the command prompt. Now the appropriate username can be entered and the `config account` command re-executed.

All commands in the CLI function in this way. In addition, the syntax of the help prompts are the same as presented in this manual angle brackets `< >` indicate a numerical value or character string. The `< >` can also indicate a word with a number for character allowed.

If a command is entered that is unrecognized by the CLI, the top-level commands are displayed under the `Available commands:` prompt.

```

<vlan name 20>      vlanid
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
DFS 1210 28/ME:5#
Available commands:
?
create          delete         disable       download
enable         logout        ping          reboot
erase          save          show          snmp
upload
DFS 1210 28/ME:5#

```

Figure 2–5 Available Commands

The top-level commands consist of commands such as `show` or `config`. Most of these commands require one or more parameters to narrow the top-level command. This is equivalent to `show what?` or `config what?` Where the `what?` is the next parameter.

For example, entering the `show` command with no additional parameters, the CLI will then display all of the possible next parameters.

```

igmp_snooping      ipif          lacp
limited_multicast_addr  link_aggregation lldp
log                log_save_timing loopdetect        mac_notification
management        max_mcast_group mcast_filter_profile
mirror            multicast     multicast_fdb     packet
port_security     ports        pppoe             qinq
radius            rmon        router_ports      safeguard_engine
scheduling        scheduling_mechanism session
smart_binding     snmp         snmp              snmp
ssh               ssl          stp               switch
syslog            tech         time              traffic
traffic_segmentation  trusted_host  uplink
CTRL+C LSC q Quit SPNCL n Next Page LHILR Next Entry a ALL

```

Figure 2–6 Next possible completions: Show Command

In the above example, all of the possible next parameters for the show command are displayed. At the next command prompt in the example, the up arrow was used to re-enter the show command, followed by the account parameter. The CLI then displays the user accounts configured on the Switch.

COMMAND SYNTAX

The following symbols are used to describe how command entries are made and values and arguments are specified in this manual. The online help contained in the CLI and available through the console interface uses the same syntax.



NOTE: All commands are case-sensitive. Be sure to disable Caps Lock or any other unwanted function that changes text case.

<angle brackets>	
Purpose	Encloses a variable or value that must be specified.
Syntax	create account [admin oper user] <username 15>
Description	In the above syntax example, supply a username in the <username> space. Do not type the angle brackets.
Example Command	create account admin newadmin1

[square brackets]	
Purpose	Encloses a required value or set of required arguments. One value or argument can be specified.
Syntax	create account [admin oper user] <username 15>
Description	In the above syntax example, specify admin , oper or a user level account to be created. Do not type the square brackets.
Example Command	create account user newuser1

vertical bar	
Purpose	Separates two or more mutually exclusive items in a list, one of which must be entered.
Syntax	create account [admin oper user] <username 15>
Description	In the above syntax example, specify admin , oper , or user . Do not type the vertical bar.
Example Command	create account user newuser1

All commands are case-sensitive. Be sure to disable Caps Lock or any other unwanted function that changes text case.

{braces}	
Purpose	Encloses an optional value or set of optional arguments.
Syntax	reset
Description	execute "reset" will return the switch to its factory default setting.
Example command	reset Please be aware that all configuration will be reset to default value. Are you sure you want to proceed with system reset now? (Y/N)[N] N

Line Editing Key Usage	
Delete	Deletes the character under the cursor and then shifts the remaining characters in the line to the left.
Backspace	Deletes the character to the left of the cursor and then shifts the remaining characters in the line to the left.
Insert or Ctrl+R	Toggle on and off. When toggled on, inserts text and shifts previous text to the right.
Left Arrow	Moves the cursor to the left.
Right Arrow	Moves the cursor to the right.
Up Arrow	Repeats the previously entered command. Each time the up arrow is pressed, the command previous to that displayed appears. This way it is possible to review the command history for the current session. Use the down arrow to progress sequentially forward through the command history list.
Down Arrow	The down arrow displays the next command in the command history entered in the current session. This displays each command sequentially as it was entered. Use the up arrow to review previous commands.
Tab	Shifts the cursor to the next field to the left.

Multiple Page Display Control Keys	
Space	Displays the next page.
CTRL+c	Stops the display of remaining pages when multiple pages are to be displayed.
ESC	Stops the display of remaining pages when multiple pages are to be displayed.
n	Displays the next page.
p	Displays the previous page.
q	Stops the display of remaining pages when multiple pages are to be displayed.
r	Refreshes the pages currently displayed.
a	Displays the remaining pages without pausing between pages.
Enter	Displays the next line or table entry.

BASIC SWITCH COMMANDS

The Basic Switch commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable password encryption	
disable password encryption	
create account	[admin operator user] <username 15>
config account	<username 15>
show account	
delete account	<username 15>
show session	
show switch	
enable web	<tcp_port_number 1-65535>
disable web	
enable autoconfig	
disable autoconfig	
save	{[config config_id <value 1-2> log account]}
reboot	
reset	{[config system account password]} {force_agree}
logout	
ping	<ipaddr> {times <value 1-255>} {timeout <sec 1-99>}
enable telnet	
disable telnet	
show tech support	

Each command is listed in detail, as follows:

enable password encryption

Purpose	Used to enable password encryption on a user account.
Syntax	enable password encryption
Description	The user account configuration information will be stored in the configuration file, and can be applied to the system at a time in the future. If the password encryption is enabled, the password will be in encrypted form. If password encryption is disabled and the user specifies the password in encrypted form, or if the password has

	been converted to encrypted form by the last enabled password encryption command, the password will still be in encrypted form. It can not revert back to plain text.
Parameters	None.
Restrictions	Only Administrator level users can issue this command.

Example usage:

To enable password encryption on the Switch:

```
DES-1210-28/ME:5# enable password encryption
Command: enable password encryption
```

```
Success.
```

```
DES-1210-28/ME:5#
```

disable password encryption

Purpose	Used to disable password encryption on a user account.
Syntax	disable password encryption
Description	The user account configuration information will be stored in the configuration file, and can be applied to the system at a time in the future. If the password encryption is enabled, the password will be in encrypted form. If password encryption is disabled and the user specifies the password in encrypted form, or if the password has been converted to encrypted form by the last enabled password encryption command, the password will still be in encrypted form. It can not revert back to plain text.
Parameters	None.
Restrictions	Only Administrat level users can issue this command.

Example usage:

To disable password encryption on the Switch:

```
DES-1210-28/ME:5# disable password encryption
Command: disable password encryption
```

```
Success.
```

```
DES-1210-28/ME:5#
```

create account

Purpose	To create user accounts.
Syntax	create account [admin operator user] <username 15>
Description	The create account command creates an administrator, operator, or user account that consists of a username and an optional

	password. Up to 31 accounts can be created. You can enter username and Enter. In this case, the system prompts for the account's password, which may be between 0 and 15 characters. Alternatively, you can enter the username and password on the same line.
Parameters	<p><i>admin</i> – Name of the administrator account.</p> <p><i>oper</i> – Specify an operator level account.</p> <p><i>user</i> – Specify a user account with read-only permissions.</p> <p><i><username 1-15></i> – The account username may be between 1 and 15 characters.</p> <p><i>password <password_string> {encrypted}</i> - the account password can be included, and (optionally) can be encrypted.</p>
Restrictions	<p>Only Administrator level users can issue this command.</p> <p>Usernames can be between 1 and 15 characters.</p> <p>Passwords can be between 0 and 15 characters.</p>



NOTE: You are not required to enter a User Name. However, if you do not enter a User Name, you cannot perform the following actions:

Create a monitor or operator (level 1 or level 14) users until an administrator user (level 15) is defined.

Delete the last administrator user if there are monitor and/or operator users defined.

Example usage:

To create an administrator-level user account with the username 'dlink':

```
DES-1210-28/ME:5# create account admin dlink
Command: create account admin dlink

Enter a case-sensitive new password:*****
Enter the new password again for confirmation:*****

Success.

DES-1210-28/ME:5#
```

config account

Purpose	To change the password for an existing user account.
Syntax	config account <username 15>
Description	The config account command changes the password for a user account that has been created using the create account command. The system prompts for the account's new password, which may be between 0 and 15 characters.
Parameters	<i><username 1-15></i> – the account username.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To configure the user password of 'dlink' account:


```

DES-1210-28/ME:5# config account dlink
Enter a old password:****

Enter a case-sensitive new password:*****
Enter the new password again for confirmation:*****

Success.

DES-1210-28/ME:5#

```

show account

Purpose	To display information about all user accounts on the Switch.
Syntax	show account
Description	The show account command displays all account usernames and their access levels created on the Switch. Up to 31 user accounts can exist on the Switch at one time.
Parameters	None.
Restrictions	None.

Example usage:

To display the account which have been created:

```

DES-1210-28/ME:5# show account
Command: show account

Username      Access Level
-----
dlink         Admin

Total Entries : 1

DES-1210-28/ME:5#

```

delete account

Purpose	To delete an existing user account.
Syntax	delete account <username 15>
Description	The delete account command deletes a user account that has been created using the create account command.
Parameters	<username 15> – the account username.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To delete the user account 'System':

```

DES-1210-28/ME:5# delete account System
Command: delete account System

```

Success.

DES-1210-28/ME:5#

show session

Purpose	To display information about currently logged-in users.
Syntax	show session
Description	The show session command displays a list of all the users that are logged-in at the time the command is issued. The information includes the session ID (0 for the first logged-in user, 1 for the next logged-in user, etc.), the Protocol used to connect to the Switch, the user's IP address, the user's access Level (1=user, 15=admin), and the account name on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the way users logged in:

```
DES-1210-28/ME:5# show session
Command: show session

Total Entries: 1

ID Login Time          Live Time   From          Level Name
-----
0 Jan 1 01:04:08 2011 00:11:05   Serial Port   14   dorothy

Total Entries: 1

CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh
```

show switch

Purpose	To display information about the Switch.
Syntax	show switch
Description	The show switch command displays information about the Switch settings, including Device Type, MAC Address, IP configuration, Hardware/Software version, System information, and Switch Network configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display the Switch information:

```

DES-1210-28/ME:5# show switch
Command: show switch

System name           :
System Contact        :
System Location       :
System up time        : 0 days, 1 hrs, 17 min, 19 secs
System Time           : 01/01/2011 01:17:20
System hardware version :
System firmware version : 6.00.004
System boot version   : 1.00.002
System Protocol version : 2.001.004
System serial number  : 1MB1733K0000A
MAC Address           : 00-B2-FD-DA-EE-EB
STP                   : Disabled
SNMP Status           : Enabled
Port Mirroring        : Disabled
802.1X Status         : Disabled
Storm Control         : Disabled
802.1Q Management VLAN : Disabled
Safeguard Engine      : Enabled
IGMP Snooping         : Disabled

DES-1210-28/ME:5#

```

enable web

Purpose	To enable the HTTP-based management software on the Switch.
Syntax	enable web <tcp_port_number 1-65535>
Description	The enable web command enables the Web-based management software on the Switch. The user can specify the TCP port number the Switch uses to listen for Telnet requests.
Parameters	<tcp_port_number 1-65535> – The TCP port number. TCP ports are numbered between 1 and 65535. The ‘well-known’ port for the Web-based management software is 80.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable HTTP and configure the TCP port number to listen for Telnet requests:

```

DES-1210-28/ME:5# enable web 80
Command: enable web 80

Success.

DES-1210-28/ME:5#

```

disable web

Purpose	To disable the HTTP-based management software on the Switch.
Syntax	disable web
Description	The disable web command disables the Web-based management software on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable HTTP-based management software on the Switch:

```
DES-1210-28/ME:5# disable web
```

```
Command: disable web
```

```
Success.
```

```
DES-1210-28/ME:5#
```

enable autoconfig

Purpose	Used to activate the auto configuration function for the Switch. This will load a previously saved configuration file for current use.
Syntax	enable autoconfig
Description	When autoconfig is enabled on the Switch, the DHCP reply will contain a configuration file and path name. It will then request the file from the TFTP server specified in the reply. When autoconfig is enabled, the ipif settings will automatically become DHCP client.
Parameters	None.
Restrictions	When autoconfig is enabled, the Switch becomes a DHCP client automatically (same as: config ipif System dhcp). The DHCP server must have the TFTP server IP address and configuration file name, and be configured to deliver this information in the data field of the DHCP reply packet. The TFTP server must be running and have the requested configuration file in its base directory when the request is received from the Switch. Consult the DHCP server and TFTP server software instructions for information on loading a configuration file. If the Switch is unable to complete the auto configuration process the previously saved local configuration file present in Switch memory will be loaded.

Example usage:

To enable auto configuration on the Switch:

```
DES-1210-28/ME:5# enable autoconfig
```

```
Command: enable autoconfig
```

```
Success.
```

```
DES-1210-28/ME:5#
```

disable autoconfig

Purpose	Use this to deactivate auto configuration from DHCP.
Syntax	disable autoconfig
Description	The disable autoconfig command is used to instruct the Switch not to accept auto configuration instruction from the DHCP server. This does not change the IP settings of the Switch. The ipif settings will continue as DHCP client until changed with the config ipif command.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command. .

Example usage:

To stop the auto configuration function:

```
DES-1210-28/ME:5# disable autoconfig
```

```
Command: disable autoconfig
```

```
Success.
```

```
DES-1210-28/ME:5#
```

show autoconfig

Purpose	Used to display the current autoconfig status of the Switch.
Syntax	show autoconfig
Description	The show autoconfig command is used to list the current status of the auto configuration function.
Parameters	None.
Restrictions	None.

Example usage:

To display the autoconfig status:

```
DES-1210-28/ME:5# show autoconfig
```

```
Command: show autoconfig
```

```
Autoconfig State: Enabled
```

```
DES-1210-28/ME:5#
```

save

Purpose	To save changes in the Switch's configuration to non-volatile RAM.
Syntax	save {[config config_id <value 1-2> log account]}
Description	The save command used to enter the current switch configuration into non-volatile RAM. The saved switch configuration will be loaded into the Switch's memory each time the Switch is restarted.
Parameters	<i>config</i> – Used to save the current configuration to a file. <i>config_id</i> <value 1-2> - Specifies which cfg file ID. if cfg ID is not specified, it refers to the boot_up CFG file.

	<i>log</i> – Used to save the current log to a file. The log file cannot be deleted.
	<i>account</i> – Used to save the account to a file.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To save the Switch's current configuration to non-volatile RAM:

```
DES-1210-28/ME:5# save
Command: save

Building configuration ...
[OK]
DES-1210-28/ME:5#
```

reboot	
Purpose	To reboot the Switch. If the Switch is a member of a stack, it may be rebooted individually, without affecting the other members of the stack.
Syntax	reboot
Description	The reboot command restarts the Switch.
Parameters	None.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To restart the Switch:

```
DES-1210-28/ME:5# reboot
Command: reboot

Are you sure you want to proceed with the system reboot?(y/n)y
% Please wait, the switch is rebooting...
DES-1210-28/ME:5# System will Reboot....
◀

Boot Procedure
-----

Please wait, loading Runtime image ..... 100%

MAC Address : 00-B2-FD-DA-EE-EB
H/W Version :
F/W Version : 6.00.004
-----

DES-1210-28/ME Fast Ethernet Switch
Command Line Interface
```

Firmware: Build 6.00.004
Copyright(C) 2010 D-Link Corporation. All rights reserved.

DES-1210-28/ME login:

reset

Purpose	To reset the Switch to the factory default settings.
Syntax	reset {[config system account password]} { force_agree }
Description	The reset command restores the Switch's configuration to the default settings assigned from the factory. Execution of the reset command through the CLI retains the unit's current stack membership number.
Parameters	<p><i>config</i> - If the keyword 'config' is specified, all of the factory default settings are restored on the Switch including the IP address, user accounts, and the switch history log. The Switch will not save or reboot.</p> <p><i>system</i> - If the keyword 'system' is specified all of the factory default settings are restored on the Switch. The Switch will save and reboot after the settings are changed to default. Rebooting will clear all entries in the Forwarding Data Base.</p> <p><i>account</i> - If the keyword 'account' is specified, all of the factory default account settings are restored on the Switch.</p> <p><i>password</i> - If the keyword 'password' is specified, all of the factory default password settings are restored on the Switch.</p> <p>{<i>force_agree</i>} - When <i>force_agree</i> is specified, the reset command will be executed immediately without further confirmation.</p> <p>If no parameter is specified, the Switch's current IP address, user accounts, and the switch history log are not changed. All other parameters are restored to the factory default settings. The Switch will not save or reboot.</p>
Restrictions	Only administrator-level users can issue this command.

Example usage:

To restore all of the Switch's parameters to their default values:

```
DES-1210-28/ME:5# reset system
Command: reset system

Are you sure you want to proceed with the system reset?(y/n)y
% Success.
DES-1210-28/ME:5# System will Reboot....
```

logout

Purpose	To log out a user from the Switch's console.
Syntax	Logout
Description	The logout command terminates the current user's session on the

	Switch's console.
Parameters	None.
Restrictions	None.

Example usage:

To terminate the current user's console session:

```
DES-1210-28/ME:5# logout
```

ping

Purpose	To test the connectivity between network devices.
Syntax	ping <ipaddr> {times <value 1-255>} {timeout <sec 1-99>}
Description	The ping command sends Internet Control Message Protocol (ICMP) echo messages to a remote IP address. The remote IP address then 'echos' or returns the message. This is used to confirm connectivity between the Switch and the remote device.
Parameters	<p><i><ipaddr></i> - The IP address of the host.</p> <p><i>times <value 1-255></i> - The number of individual ICMP echo messages to be sent. The maximum value is 255. The default is 4.</p> <p><i>timeout <sec 1-99></i> - The time-out period while waiting for a response from the remote device. A value of 1 to 99 seconds can be specified. The default is 1 second.</p>
Restrictions	None.

Example usage:

To ping the IP address 10.6.150.34 three times:

```
DES-1210-28/ME:5# ping 10.6.150.34 times 3
Command: ping 10.6.150.34 times 3

Reply Not Received From : 10.6.150.34, Timeout : 5 secs
Reply Not Received From : 10.6.150.34, Timeout : 5 secs
Reply Not Received From : 10.6.150.34, Timeout : 5 secs

--- 10.6.150.34 Ping Statistics ---
3 Packets Transmitted, 0 Packets Received, 100% Packets Loss
DES-1210-28/ME:5#
```

enable telnet

Purpose	To enable the telnet.
Syntax	enable telnet
Description	The enable telnet command enables telnet.
Parameters	None.
Restrictions	Only Administrator or operate-level users can issue this command

Example usage:

To enable telnet:

```
DES-1210-28/ME:5# enable telnet
```


Command: enable telnet

Success.

DES-1210-28/ME:5#

disable telnet

Purpose	To disable telnet.
Syntax	disable telnet
Description	The disable telnet command disables telnet.
Parameters	None.
Restrictions	Only Administrator or operate-level users can issue this command

Example usage:

To disable telnet:

DES-1210-28/ME:5# disable telnet

Command: disable telnet

Success.

DES-1210-28/ME:5#

show tech support

Purpose	To display system and configuration information. to provide to the Technical Assistance Center when reporting a problem, use the show tech-support command.
Syntax	show tech support
Description	<p>The show tech support command displays system and configuration information. to provide to the Technical Assistance Center when reporting a problem.</p> <p>By default, this command displays the output for technical-support-related show commands. Use keywords to specify the type of information to be displayed. If you do not specify any parameters, the system displays all configuration and memory data.</p> <p>The show tech support command may time out if the configuration file output takes longer to display than the configured session timeout time. If this happens, enter a set logout <i>timeout</i> value of 0 to disable automatic disconnection of idle sessions or enter a longer <i>timeout</i> value.</p> <p>The show tech support command output is continuous; it does not display one screen at a time. To interrupt the output, press Esc.</p>
Parameters	None.
Restrictions	Only Administrator-level users can issue this command..

Example usage:

To display technical support information on the Switch:

DES-1210-28/ME:5# show tech support

Command: show tech support

- System Info. -

System name :
System Contact :
System Location :
System up time : 0 days, 1 hrs, 28 min, 24 secs
System Time : 01/01/2011 01:28:22
System hardware version :
System firmware version : 6.00.004
System boot version : 1.00.002
System Protocol version : 2.001.004
System serial number : 1MB1733K0000A
MAC Address : 00-B2-FD-DA-EE-EB
STP : Disabled
SNMP Status : Enabled
Port Mirroring : Disabled
802.1X Status : Disabled
Storm Control : Disabled
802.1Q Management VLAN : Disabled
Safeguard Engine : Enabled
IGMP Snooping : Disabled
CTRL+C ESC q Quit SPACE n Next Page ENTER Next Entry a ALL

SMTP SERVER COMMANDS

The SMTP Server commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable smtp	
disable smtp	
config smtp	[self_mail_addr <mail_addr 64> server <ipaddr> server_port <tcp_port_number 1-65535>] [{add mail_receiver <mail_addr 64> delete mail_receiver <index 1-8>}]
show smtp	
smtp sent_testmsg	

Each command is listed in detail, as follows:

enable smtp

Purpose	To enable the SMTP server feature on the Switch.
Syntax	enable smtp
Description	The enable smtp command enables the SMTP server feature on the Switch.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command..

Example usage:

To enable SMTP feature on the Switch:

```
DES-1210-28/ME:5# enable smtp
Command: enable smtp

Success!
DES-1210-28/ME:5#
```

disable smtp

Purpose	To disable the SMTP server feature on the Switch.
Syntax	disable smtp
Description	The disable smtp command disables the SMTP server feature on the Switch.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command..

Example usage:

To disable SMTP feature on the Switch:

```
DES-1210-28/ME:5# disable smtp
```

```
Command: disable smtp
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config smtp

Purpose	To configure the fields to set up the SMTP server for the switch, along with setting e-mail addresses to which switch log files can be sent when a problem arises on the Switch.
Syntax	config smtp [<i>self_mail_addr</i> < <i>mail_addr</i> 64> server < <i>ipaddr</i> > server_port < <i>tcp_port_number</i> 1-65535>] [{ add mail_receiver < <i>mail_addr</i> 64> delete mail_receiver < <i>index</i> 1-8>}]
Description	The config smtp command is used to configure the fields to set up the SMTP server for the switch, along with setting e-mail addresses to which switch log files can be sent when a problem arises on the Switch.
Parameters	<p><i>self_mail_addr</i> <<i>mail_addr</i> 64> – Specifies the e-mail address from which mail messages will be sent. Only one self mail address can be configured on the Switch.</p> <p><i>server</i> <<i>ipaddr</i>> – Specifies the IP address of the SMTP server. This will be the device that sends out the mail for user. For example, 10.90.90.99.</p> <p><<i>tcp_port_number</i> 1-65535> – Specifies the port number that the Switch will connect with on the SMTP server. The range is between 1 and 65535.</p> <p><i>add mail_receiver</i> <<i>mail_addr</i> 64> – Specifies a list of e-mail addresses so recipients can receive e-mail messages regarding Switch functions. Up to 8 e-mail address can be added per Switch.</p> <p><i>delete mail_receiver</i> <<i>index</i> 1-8> – Specifies the e-mail address index to be deleted.</p>
Restrictions	Only Administrator-level users can issue this command..

Example usage:

To config SMTP with self mail address 'dlink@mail.com.tw' on the Switch:

```
DES-1210-28/ME:5# config smtp self_mail_addr dlink@mail.com.tw
```

```
Command: config smtp self_mail_addr dlink@mail.com.tw
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show smtp

Purpose	To display the SMTP server settings on the Switch.
Syntax	show smtp
Description	The show smtp command displays the SMTP server settings on the Switch.
Parameters	None.

Restrictions	None.
--------------	-------

Example usage:

To display SMTP information on the Switch:

```
DES-1210-28/ME:5# show smtp
Command: show smtp

smtp status : Enable
smtp server address : 0.0.0.0
smtp server port : 25
self mail address : dlink@mail.com.tw

Index          Mail Receiver Address
-----
1
2
3
4
5
6
7
8

DES-1210-28/ME:5#
```

smtp sent_testmsg

Purpose	To send test messages to all mail recipients configured on the Switch.
Syntax	smtp sent_testmsg
Description	The smtp sent_testmsg command is used to send test messages to all mail recipients configured on the Switch.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command..

Example usage:

To send SMTP test message to all mail receivers:

```
DES-1210-28/ME:5# smtp sent_testmsg
Command: smtp sent_testmsg

Subject: This is a SMTP test
Content: Hello everybody!!

Sending mail, please wait...

Success!

DES-1210-28/ME:5#
```

MODIFY BANNER AND PROMPT COMMANDS

The **Modify Banner and Prompt** commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config command_prompt	[<string 32> default username]
config greeting_message	{default}
show greeting_message	

Each command is listed in detail, as follows:

config command_prompt	
Purpose	To configure the command prompt.
Syntax	config command_prompt [<string 32> default username]
Description	The config command_prompt command configures the command prompt.
Parameters	<p><string 32> – The command prompt can be changed by entering a new name of no more that 32 characters.</p> <p><i>default</i> – The command prompt will reset to factory default command prompt. Default = the name of the Switch model, for example “DES-1210-28”.</p> <p><i>username</i> – The command prompt will be changed to the login username.</p>
Restrictions	<p>Only Administrator-level users can issue this command. Other restrictions include:</p> <p>If the “reset” command is executed, the modified command prompt will remain modified. However, the “reset config/reset system” command will reset the command prompt to the original factory banner.</p>

Example usage:

To modify the command prompt to “AtYourService”:

```
DES-1210-28/ME:5# config command_prompt AtYourService
Command: config command_prompt AtYourService

Success.

AtYourService:5#
```

config greeting_message

Purpose	Used to configure the login banner (greeting message).
Syntax	config greeting_message {default}
Description	The config greeting_message command to modify the login banner (greeting message).
Parameters	<p><i>default</i> – If the user enters default to the modify banner command, then the banner will be reset to the original factory banner. To open the Banner Editor, click Enter after typing the config greeting_message command. Type the information to be displayed on the banner by using the commands described on the Banner Editor:</p> <p>Quit without save: Ctrl+C Save and quit: Ctrl+W Move cursor: Left/Right/Up/Down Delete line: Ctrl+D Erase all setting: Ctrl+X Reload original setting: Ctrl+L</p>
Restrictions	<p>Only Administrator-level users can issue this command. Other restrictions include:</p> <p>If the “reset” command is executed, the modified banner will remain modified. However, the “reset config/reset system” command will reset the modified banner to the original factory banner. The capacity of the banner is 6*80. 6 Lines and 80 characters per line.</p> <p>Ctrl+W will only save the modified banner in the DRAM. Users need to type the “save config/save all” command to save it into Flash.</p> <p>Only valid in threshold level.</p>

Example usage:

To the banner:

```

DES-1210-28/ME:5#
Command: config greeting_message

Greeting Messages Editor
=====

DES-1210-28/ME Fast Ethernet Switch
Command Line Interface

Copyright(C) 2012 D-Link Corporation. All rights reserved.

=====

<Function Key>      <Control Key>
Ctrl+C  Quit without save  left/right/
Ctrl+W  Save and quit     up/down  Move cursor
                   Ctrl+D   Delete line
                   Ctrl+X   Erase all setting
                   Ctrl+L   Reload original setting

```

show greeting_message

Purpose	Used to view the currently configured greeting message configured on the Switch.
Syntax	show greeting_message
Description	The show greeting_message command is used to view the currently configured greeting message on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To view the currently configured greeting message:

```

DES-1210-28/ME:5# show greeting_message
Command: show greeting_message

DES-1210-28/ME Fast Ethernet Switch
Command Line Interface

Copyright(C) 2012 D-Link Corporation. All rights reserved.

DES-1210-28/ME:5#

```


SWITCH PORT COMMANDS

The Switch Port commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config ports	config ports [all <portlist>] medium_type [copper fiber_100 fiber_1G] MDI/MDIX [MDI MDIX auto] {description <desc 32> flow_control [enable disable] learning [enable disable] state [enable disable] speed [auto 10_half 100_full 100_half 10_full 10_half]}
show ports	{<portlist> all} {description err_disabled}

Each command is listed in detail, as follows:

config ports	
Purpose	To configure the Switch's Ethernet port settings.
Syntax	config ports [all <portlist>] medium_type [copper fiber_100 fiber_1G] MDI/MDIX [MDI MDIX auto] {description <desc 32> flow_control [enable disable] learning [enable disable] state [enable disable] speed [auto 10_half 100_full 100_half 10_full 10_half]}
Description	The config ports command configures the Switch's Ethernet port settings. Only the ports listed in the <portlist> are affected.
Parameters	<p><i><portlist></i> – A port or range of ports to be configured.</p> <p><i>all</i> – Configures all ports on the Switch.</p> <p><i>medium_type [copper fiber_100 fiber_1G]</i> – If configuring the Combo ports, this defines the type of medium being configured.</p> <p><i>MDI/MDIX [MDI MDIX j auto]</i> – Specifies the MDI or MDIX setting of the port. The MDIX setting can be auto, normal or cross.</p> <p>If set to normal state, the port in MDIX mode, can be connected to PC NIC using a straight cable. If set to cross state, the port in mdi mode, can be connected to a port (in mdix mode) on another switch through a straight cable.</p> <p><i>description <desc 32></i> – Enter an alphanumeric string of no more than 32 characters to describe a selected port interface.</p> <p><i>flow_control [enable]</i> – Enables flow control for the specified ports.</p> <p><i>flow_control [disable]</i> – Disables flow control for the specified ports.</p> <p><i>learning [enable disable]</i> c Enables or disables the MAC address learning on the specified range of ports.</p> <p><i>state [enable disable]</i> – Enables or disables the specified range of ports.</p> <p><i>speed</i> – Sets the speed of a port or range of ports, with the addition of one of the following:</p> <ul style="list-style-type: none"> <i>auto</i> – Enables auto-negotiation for the specified range of ports.

- *[10 | 100 | 1000]* – Configures the speed in Mbps for the specified range of ports.
- *[half | full]* – Configures the specified range of ports as either full or half-duplex.

Restrictions Only administrator or operate-level users can issue this command.

Example usage:

To configure the speed of ports 1-3 to be 100 Mbps, full duplex, learning and state enabled:

```
DES-1210-28/ME:5# config ports 1-3 medium_type copper speed 100_full learning enable state enable
```

```
Command: config ports 1-3 medium_type copper speed 100_full learning enable state enable
```

Success

```
DES-1210-28/ME:5#
```

show ports

Purpose	To display the current configuration of a range of ports.
Syntax	show ports {<portlist> all} {description err_disabled}
Description	The show ports command displays the current configuration of a port or range of ports.
Parameters	<i><portlist></i> – A port or range of ports whose settings are to be displayed. <i>all</i> – Specifies all ports to be displayed.
Restrictions	None.

Example usage:

To display the configuration of port 8 on the Switch:

```
DES-1210-28/ME:5# show ports 8
```

```
Command: show ports 8
```

Port Type	State/MDI	Settings Speed/Duplex/FlowCtrl	Connection Speed/Duplex/FlowCtrl	Address Learning
8	Enabled Auto	Auto/Disabled	Link Down	Enabled

```
DES-1210-28/ME:5#
```

LOOPBACK DETECTION COMMANDS

The Loopback Detection commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config loopdetect	[enable disable]
config loopdetect mode	[portbase vlanbase]
config loopdetect ports	[<portlist> all] [enable disable]
config loopdetect	interval_time <value 1-32767> lbd_recover_time [0 <value 60-1000000>]
show loopdetect	{ports [<portlist> all]}

Each command is listed in detail, as follows:

config loopdetect

Purpose	To enable the loop back detection to be enabled or disabled on the Switch.
Syntax	config loopdetect [enable disable]
Description	The config loopdetect command enables or disables the loop back detection on the Switch.
Parameters	<i>[enabled disabled]</i> – Specifies the loop back detection is enabled or disabled on the Switch.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To enable the loopback detection feature on the Switch:

```
DES-1210-28/ME:5# config loopdetect enable
Command: config loopdetect enable
```

```
Success!
DES-1210-28/ME:5#
```

config loopdetect mode

Purpose	To configure the loop back detection mode to be portbase or vlanbase on the Switch.
Syntax	config loopdetect mode [portbase vlanbase]
Description	The config loopdetect mode command configures loop back detection mode to be portbase or vlanbase on the Switch.
Parameters	<i>[portbase vlanbase]</i> - Specifies the loopdetect mode to be portbase or vlanbase.

Restrictions	None.
--------------	-------

Example usage:

To configure the loopback detection mode to be portbase on the Switch:

```
DES-1210-28/ME:5# config loopdetect mode portbase
Command: config loopdetect mode portbase
```

```
Success!
DES-1210-28/ME:5#
```

config loopdetect ports

Purpose	To configures the loop back detection to be enabled or disabled for the specific ports on the Switch.
Syntax	config loopdetect ports [<portlist> all] [enable disable]
Description	The config loopdetect ports command configures the loop back detection to be enabled or disabled for the specific ports on the Switch.
Parameters	<i><portlist></i> – A port or range of ports to be configured. <i>all</i> – All ports settings are to be configured. <i>[enabled disabled]</i> – Specifies the loop back detection is enabled or disabled for the specified ports on the Switch.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To enable the loop back detection on the Switch:

```
DES-1210-28/ME:5# config loopdetect ports all enable
Command: config loopdetect ports all enable
```

```
Success!
DES-1210-28/ME:5#
```

config loopdetect

Purpose	To configure the loop back detection interval time and recover time on the Switch.
Syntax	config loopdetect interval_time <value 1-32767> lbd_recover_time [0 <value 60-100000>]
Description	The config loopdetect command configures the loop back detection interval time and recover time on the Switch.
Parameters	<i>interval_time <value 1-32767></i> – Specifies the interval time of loop back detection. The range is between 1 and 32767 seconds. <i>lbd_recover_time [0 <value 60-10000>]</i> – Specifies the recover time of loop back detection on the switch. The range is between 60 and 10000 seconds.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To configure the loop back detection with interval time 500 on the Switch:

```
DES-1210-28/ME:5# config loopdetect interval_time 500
Command: config loopdetect interval_time 500

Success!
DES-1210-28/ME:5#
```

show loopdetect

Purpose	To display the loop back detection information on the Switch.
Syntax	show loopdetect {ports [<portlist> all]}
Description	The show loopdetect command displays the loop back detection information on the Switch.
Parameters	<portlist> – A port or range of ports to be displayed. all – All ports settings are to be displayed.
Restrictions	None.

Example usage:

To display the loop back detection information on the Switch:

```
DES-1210-28/ME:5# show loopdetect
Command: show loopdetect

Loopdetect Global Settings
-----
Loopdetect Status   : Enabled
Loopdetect Mode     : Port-Base
Loopdetect Interval : 100
Recover Time       : 60
DES-1210-28/ME:5#
```

DOS PREVENTION COMMANDS

The DoS Prevention commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config dos_prevention dos_type	[{land_attack blat_attack smurf_attack tcp_null_scan tcp_xmascan tcp_synfin tcp_syn_srcport_less_1024} all] {action [drop mirror <portlist> {priority <value 0-7> rx_rate [no_limit <value 64-1024000>] }] enable disable] }
show dos_prevention	{ land_attack blat_attack smurf_attack tcp_null_scan tcp_xmascan tcp_synfin tcp_syn_srcport_less_1024 }
clear dos_prevention counters	[land_attack blat_attack smurf_attack tcp_null_scan tcp_xmascan tcp_synfin tcp_syn_srcport_less_1024]
enable dos_prevention trap_log	
disable dos_prevention trap_log	

Each command is listed in detail, as follows:

config dos_prevention dos_type	
Purpose	Used to discard the L3 control packets sent to CPU from specific ports.
Syntax	config dos_prevention dos_type [{land_attack blat_attack smurf_attack tcp_null_scan tcp_xmascan tcp_synfin tcp_syn_srcport_less_1024} all] {action [drop mirror <portlist> {priority <value 0-7> rx_rate [no_limit <value 64-1024000>] }] enable disable] }
Description	The create snmp user command is used to configure the prevention of DoS attacks, and includes state and action. The packets matching will be used by the hardware. For a specific type of attack, the content of the packet, regardless of the receipt port or destination port, will be matched against a specific pattern.
Parameters	The type of DoS attack. Possible values are as follows: land_attack, blat_attack, smurf_attack, tcp_null_scan, tcp_xmascan tcp_synfin and tcp_syn_srcport_less_1024. <i>state</i> - Enable or disable DoS prevention. By default, prevention for all types of DoS are enabled except for tcp_syn_srcport_less_1024. <i>action</i> - When enabling DoS prevention, the following actions can be taken. <i>drop</i> – Drop the attack packets. <i>mirror</i> – Mirror the packet to other port for further process.

	<p><i>priority</i> – Change packet priority by the Switch from 0 to 7. If the priority is not specified, the original priority will be used.</p> <p><i>rx_rate</i> – controls the rate of the received DoS attack packets.</p> <ul style="list-style-type: none"> • If not specified, the default action is drop.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To configure a land attack and blat attack prevention:

```
DES-1210-28/ME:5# config dos_prevention dos_type blat_attack action
drop
Command: config dos_prevention dos_type blat_attack action drop

Success!

DES-1210-28/ME:5#
```

show dos_prevention

Purpose	Used to display DoS prevention information.
Syntax	show dos_prevention { land_attack blat_attack smurf_attack tcp_null_scan tcp_xmascan tcp_synfin tcp_syn_srcport_less_1024 }
Description	The show dos_prevention command is used to display DoS prevention information, including the type of DoS attack, the prevention state, the corresponding action if the prevention is enabled, and the counter information of the DoS packet.
Parameters	The type of DoS attack. Possible values are as follows: land_attack, blat_attack, smurf_attack, tcp_null_scan, tcp_xmascan tcp_synfin and tcp_syn_srcport_less_1024.
Restrictions	None.

Example usage:

To display DoS prevention information:

```
DES-1210-28/ME:5# show dos_prevention
Command: show dos_prevention

DosType           State      Action     Frame Counts
Land Attack       Disabled  Mirror     0
Blat Attack       Disabled  Mirror     0
Smurf Attack      Disabled  Mirror     0
Tcp Null Scan    Disabled  Mirror     0
Tcp Xmascan      Disabled  Mirror     0
Tcp Synfin       Disabled  Mirror     0
Tcp Syn Srcport less 1024 Disabled  Mirror     0

Success!

DES-1210-28/ME:5#
```

To display DoS prevention information for Land Attack:

```
DES-1210-28/ME:5# show dos_prevention land_attack
Command: show dos_prevention land_attack

DoS Type: Land Attack
State: Disabled
Action: Mirror
Port: 7
Priority: 5
Rx Rate(Kbit/sec): 1024
Frame Counts: 0

Success!

DES-1210-28/ME:5#
```

clear dos_prevention counters

Purpose	Used to clear the counters of the prevention of each DoS attack.
Syntax	clear dos_prevention counters [land_attack blat_attack smurf_attack tcp_null_scan tcp_xmascan tcp_synfin tcp_syn_srcport_less_1024]
Description	The clear dos_prevention counters command is used to clear the counters of the prevention of each DoS attack.
Parameters	The type of DoS attack. Possible values are as follows: land_attack, blat_attack, smurf_attack, tcp_null_scan, tcp_xmascan tcp_synfin and tcp_syn_srcport_less_1024.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To clear all counters of the prevention of each smurf attack:

```
DES-1210-28/ME:5# clear dos_prevention counters smurf_attack
Command: clear dos_prevention counters smurf_attack

DES-1210-28/ME:5#
```

enable dos_prevention trap_log

Purpose	Used to enable a DoS prevention trap/log.
Syntax	enable dos_prevention trap_log
Description	The enable dos_prevention trap_log command is used to send traps and logs when a DoS attack event occurs. The event will be logged only when the action is specified as drop.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To enable a DoS prevention trap/log:


```
DES-1210-28/ME:5# enable dos_prevention trap_log
```

```
Command: enable dos_prevention trap_log
```

```
DES-1210-28/ME:5#
```

disable dos_prevention trap_log

Purpose	Used to disable a DoS prevention trap/log.
Syntax	disable dos_prevention trap_log
Description	The disable dos_prevention trap_log command is used to disable a DoS prevention trap/log.
Parameters	None.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To disable a DoS prevention trap/log:

```
DES-1210-28/ME:5# disable dos_prevention trap_log
```

```
Command: disable dos_prevention trap_log
```

```
DES-1210-28/ME:5#
```

PPPOE CIRCUIT ID INSERTION COMMANDS

PPPoE Circuit ID Insertion is used to produce the unique subscriber mapping capability that is possible on ATM networks between ATM-DSL local loop and the PPPoE server. The PPPoE server will use the inserted Circuit Identifier sub-tag of the received packet to provide AAA services (Authentication, Authorization and Accounting). Through this method, Ethernet networks can be as the alternative of the ATM networks.

The PPPoE Circuit ID Insertion commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config pppoe circuit_id_insertion state	[enable disable]
config pppoe circuit_id_insertion ports	[circuit_id [mac ip udf <string 32>] state [enable disable]]
show pppoe circuit_id_insertion	
show pppoe circuit_id_insertion ports	{<portlist>}

Each command is listed in detail, as follows:

config pppoe circuit_id_insertion state	
Purpose	Used to enable or disable the PPPoE circuit identifier insertion.
Syntax	config pppoe circuit_id_insertion state [enable disable]
Description	<p>When PPPoE circuit identifier insertion is enabled, the system will insert the circuit ID tag to the received PPPoE discover and request packet if the tag is absent, and remove the circuit ID tag from the received PPPoE offer and session confirmation packet.</p> <p>The inserted circuit ID contains the following information:</p> <ul style="list-style-type: none"> Client MAC address Device ID Port number <p>By default, the Switch IP address is used as the device ID to encode the circuit ID option.</p>
Parameters	<i>[enable disable]</i> – Enables or disable PPPoE circuit ID insertion globally. The function is disabled by default.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To globally enable PPPoE circuit identifier insertion:

```
DES-1210-28/ME:5# config pppoe circuit_id_insertion state enable
Command: config pppoe circuit_id_insertion state enable
```

Success.

DES-1210-28/ME:5#

config pppoe circuit_id_insertion ports

Purpose	Used to enable and disable PPPoE circuit identifier insertion on a per port basis and specify how to encode the circuit ID option.
Syntax	config pppoe circuit_id_insertion ports <portlist> [circuit_id [mac ip udf <string 32>] state [enable disable]]
Description	When the port's state and the global state are enabled, the system will insert the Circuit ID TAG to the received PPPoE discovery initiation and request packet if the TAG is absent, and remove the Circuit ID tag, inserted by the system, from the received PPPoE offer and session confirmation packet.
Parameters	<p><i><portlist></i> – Specifies a list of ports to be configured.</p> <p>The default settings are enabled for ID insertion per port, but disabled globally.</p> <p><i>circuit_id</i> – Configures the device ID used for encoding of the circuit ID option.</p> <p><i>mac</i> – Specifies that the Switch MAC address be used to encode the circuit ID option.</p> <p><i>ip</i> – Specifies that the Switch IP address be used to encode the circuit ID option.</p> <p><i>udf</i> – A user defined string to be used to encode the circuit ID option. The maximum length is 32.</p> <p>The default encoding for the device ID option is the Switch IP address.</p> <p><i>state</i> – Specify to enable or disable PPPoE circuit ID insertion for the ports listed.</p>
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To enable port 1~5 PPPoE circuit ID insertion function and use Host MAC:

```
DES-1210-28/ME:5# config pppoe circuit_id_insertion ports 1-5 circuit_id mac state enable
```

```
Command: config pppoe circuit_id_insertion ports 1-5 circuit_id mac state enable
```

Success.

DES-1210-28/ME:5#

show pppoe circuit_id_insertion

Purpose	Used to display the PPPoE circuit identifier insertion status for the Switch.
Syntax	show pppoe circuit_id_insertion
Description	The show pppoe circuit_id_insertion command is used to display

	the global state configuration of the PPPoE circuit ID insertion function.
Parameters	None.
Restrictions	None.

Example usage:

To view the global PPPoE ID insertion state:

```
DES-1210-28/ME:5# show pppoe circuit_id_insertion
Command: show pppoe circuit_id_insertion

Status: Enabled

DES-1210-28/ME:5#
```

show pppoe circuit_id_insertion ports

Purpose	Used to display the PPPoE ID insertion configuration on a per port basis.
Syntax	show pppoe circuit_id_insertion ports {<portlist>}
Description	The show pppoe circuit_id_insertion ports command allows the user to view the configuration of PPPoE ID insertion for each port.
Parameters	<portlist> - Specifies which ports to display. If no ports are specified, all ports configuration will be listed.
Restrictions	None.

Example usage:

To view the PPPoE circuit ID configuration for ports 2 to 5:

```
DES-1210-28/ME:5# show pppoe circuit_id_insertion ports 2-5
Command: show pppoe circuit_id_insertion ports 2-5

Port State  Cirucit ID
-----
2  Enabled Switch MAC
3  Enabled Switch MAC
4  Enabled Switch MAC
5  Enabled Switch MAC

DES-1210-28/ME:5#
```

DHCP SERVER SCREENING COMMANDS

The DHCP server screening commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Due to this function allow you not only to restrict all DHCP Server packets but also to receive any specified DHCP server packet by any specified DHCP client, it is useful when one or more than one DHCP servers are present on the network and both provide DHCP services to different distinct groups of clients.

When DHCP Server Screening function is enabled, all DHCP Server packets will be filtered from a specific port. Also, you are allowed to create entries for specific Server IP address and Client MAC address binding by port-based. Be aware that the DHCP Server Screening function must be enabled first. Once all settings are done, all DHCP Server packets will be filtered from a specific port except those that meet the Server IP Address and Client MAC Address binding.

Command	Parameter
config filter dhcp_server	[add permit server_ip <ipaddr> { client_mac <macaddr>} ports [<portlist> all] delete permit server_ip <ipaddr> { client_mac <macaddr> } ports [<portlist> all] ports [<portlist> all] state [enable disable]]
show filter dhcp_server	
config dhcp_server screening ports	<portlist> state [enable disable]
show dhcp_server screening	

Each command is listed in detail, as follows:

config filter dhcp_server	
Purpose	DHCP server packets except those that have been IP/client MAC bound will be filtered. This command is used to configure the state of the function for filtering of DHCP server packet and to add/delete the DHCP server/client binding entry.
Syntax	config filter dhcp_server [add permit server_ip <ipaddr> { client_mac <macaddr>} ports [<portlist> all] delete permit server_ip <ipaddr> { client_mac <macaddr> } ports [<portlist> all] ports [<portlist> all] state [enable disable]]
Description	The config filter dhcp_server command has two purposes: To filter all DHCP server packets on the specified port(s) and to allow some DHCP server packets to be forwarded if they are on the pre-defined server IP address/MAC address binding list. Thus the DHCP server can be restricted to service a specified DHCP client. This is useful when there are two or more DHCP servers present on the network.
Parameters	<p><i><ipaddr></i> – The IP address of the DHCP server to be filtered</p> <p><i><macaddr></i> – The MAC address of the DHCP client.</p> <p><i>state</i> – Enable/Disable the DHCP filter state</p> <p><i>ports <portlist></i> – The port number to which the DHCP filter will be applied.</p>

Restrictions	Only administrator or operate-level users can issue this command.
--------------	---

Example usage:

To add an entry from the DHCP server/client filter list in the Switch's database:

```
DES-1210-28/ME:5# config filter dhcp_server add permit server_ip
10.1.1.1 client_mac 00-00-00-00-00-01 ports all
Command: config filter dhcp_server add permit server_ip 10.1.1.1
client_mac 00-0
0-00-00-00-01 ports all

Success!
DES-1210-28/ME:5#
```

show filter dhcp_server

Purpose	Used to display current DHCP server/client filter list created on the switch.
Syntax	show filter dhcp_server
Description	The show filter dhcp_server command is used to display DHCP server/client filter list created on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the DHCP server filter list created on the switch:

```
DES-1210-28/ME:5# show filter dhcp_server
Command: show filter dhcp_server

IP Address      MAC Address      Ports
-----
10.1.1.1        00-00-00-00-00-01 1-28

Total Entries: 1

Success!
DES-1210-28/ME:5#
```

config dhcp_server screening ports

Purpose	To configure a DHCP server screening from the DHCP Relay server list.
Syntax	config dhcp_server screening ports <portlist> state [enable disable]
Description	The config dhcp_server screening ports command configures the ports of DHCP servers screening on the Switch.
Parameters	<i><portlist></i> – Specifies a port or a range of ports to be configured. <i>state [enable disable]</i> – Enable/Disable the DHCP server screening for the specified ports.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To configure the DHCP server screening of port 1~5 on the Switch:

```
DES-1210-28/ME:5# config dhcp_server screening ports 1-5 state enable
Command: config dhcp_server screening ports 1-5 state enable

Success.

DES-1210-28/ME:5#
```

show dhcp_server screening

Purpose	To display the DHCP server screening on the Switch.
Syntax	show dhcp_server screening
Description	The show dhcp_server screening command displays the DHCP server screening on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display DHCP server screening settings:

```
DES-1210-28/ME:5# show dhcp_server screening
Command: show dhcp_server screening

DHCP server screening :
Port Admin state
----
1 disabled
2 disabled
3 disabled
4 disabled
5 disabled
6 disabled
7 disabled
8 disabled
9 disabled
```

10	disabled
11	disabled
12	disabled
13	disabled

IP-MAC-PORT BINDING COMMANDS

The IP network layer uses a four-byte address. The Ethernet link layer uses a six-byte MAC address. Binding these two address types together allows the transmission of data between the layers. The primary purpose of IP-MAC-port binding is to restrict the access to a switch to a number of authorized users. Only the authorized client can access the Switch's port by checking the pair of IP-MAC addresses with the pre-configured database. If an unauthorized user tries to access an IP-MAC-port binding enabled port, the system will block the access by dropping its packet. The maximum number of IP-MAC-port binding entries is dependant on chip capability (e.g. the ARP table size) and storage size of the device. For the Switch, the maximum value for the IP-MAC-port binding ARP mode is 500. The creation of authorized users can be manually configured by CLI or Web. The function is port-based, meaning a user can enable or disable the function on the individual port.

The IP-MAC-Port Binding commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table:

Command	Parameter
create address_binding ip_mac ipaddress	<ipaddr> mac_address <macaddr> ports <port 1-28>
config address_binding ip_mac ports	[<portlist> all] {state [disable enable] ip_inspection [disable enable] arp_inspection [loose strict]}
config address_binding auto_scan	from_ip <ipaddr> to_ip <ipaddr>
delete address_binding	[ip_mac [ipaddress <ipaddr> mac_address <macaddr> all] blocked [all vlan_name <vlan_name> mac_address <macaddr> port <port 1-28>]]
show address_binding	{[ip_mac [all {ipaddress <ipaddr> mac_address <macaddr>}] blocked [all vlan_name <vlan_name> mac_address <macaddr> port <port 1-28>] ports]}
show address_binding auto_scan list	
enable address_binding dhcp_snoop	ports [<portlist> all]
disable address_binding dhcp_snoop	ports [<portlist> all]

Each command is listed in detail, as follows:

create address_binding ip_mac ipaddress	
Purpose	Used to create an IP-MAC-port binding entry.
Syntax	create address_binding ip_mac ipaddress <ipaddr> mac_address <macaddr> ports <port 1-28>
Description	The create address_binding ip_mac ipaddress command is used to create an IP-MAC-port binding entry.
Parameters	<ipaddr> – The IP address of the device where the IP-MAC-port binding is made.

	<i><macaddr></i> – The MAC address of the device where the IP-MAC-port binding is made.
	<i><port 1-28></i> – Specifies a port to be configured for address binding.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To create address binding on the Switch:

```
DES-1210-28/ME:5# create address_binding ip_mac ipaddress 10.0.0.21
mac_address 00-00-00-00-01-02 ports 3
Command: create address_binding ip_mac ipaddress 10.0.0.21
mac_address 00-00-00-00-01-02 ports 3

Success.
DES-1210-28/ME:5#
```

config address_binding ip_mac ports

Purpose	Used to configure an IP-MAC-port binding state to enable or disable for specified ports.
Syntax	config address_binding ip_mac ports [<i><portlist></i> all] {state [<i>disable</i> <i>enable</i>] ip_inspection [<i>disable</i> <i>enable</i>] arp_inspection [<i>loose</i> <i>strict</i>]}
Description	The config address_binding ip_mac ports command is used to configure the IP-MAC-port binding state to enable or disable for specified ports.
Parameters	<i><portlist></i> – Specifies a port or range of ports. <i>all</i> – Specifies all ports on the switch. <i>[enable disable]</i> – Enables or disables the specified range of ports for state and IP-inspection. <i>arp_inspection [loose strict]</i> – Specifies to check the ARP inspection to be loose or strict for the specified ports.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To configure address binding on the Switch:

```
DES-1210-28/ME:5# config address_binding ip_mac ports 3 state disable
arp_inspection loose ip_inspection disable
Command: config address_binding ip_mac ports 3 state disable
arp_inspection loose ip_inspection disable

Success.
DES-1210-28/ME:5#
```

config address_binding auto_scan

Purpose	Used to configure an IP-MAC-port binding auto scan for specified IP addresses.
Syntax	config address_binding auto_scan from_ip <ipaddr> to_ip <ipaddr>

Description	The config address_binding auto_scan command is used to configure the IP-MAC-port binding auto scan for specified IP addresses.
Parameters	<i><ipaddr></i> – Specifies a range of IP addresses for address binding auto scan on the Switch.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To configure address binding auto scan on the Switch:

```
DES-1210-28/ME:5# config address_binding auto_scan from_ip 10.0.0.10
to_ip 10.0.0.12
Command: config address_binding auto_scan from_ip 10.0.0.10 to_ip
10.0.0.12

Success.
DES-1210-28/ME:5#
```

delete address_binding

Purpose	Used to delete IP-MAC-port binding entries.
Syntax	delete address_binding [ip_mac [ipaddress <ipaddr> mac_address <macaddr> all] blocked [all vlan_name <vlan_name> mac_address <macaddr> port <port 1-28>]]
Description	<p>The delete address_binding command is used to delete IP-MAC-port binding entries. Two different kinds of information can be deleted.</p> <p><i>ip_mac</i> – Individual address binding entries can be deleted by entering the physical and IP addresses of the device. Toggling to all will delete all the address binding entries.</p> <p><i>blocked</i> – Blocked address binding entries (bindings between VLAN names and MAC addresses) can be deleted by entering the VLAN name and the physical address of the device. To delete all the blocked address binding entries, toggle all.</p>
Parameters	<p><i><ipaddr></i> – The IP address of the device where the IP-MAC-port binding is made.</p> <p><i><macaddr></i> – The MAC address of the device where the IP-MAC-port binding is made.</p> <p><i>vlan_name <string 20></i> – The VLAN name of the VLAN that is bound to a MAC address in order to block a specific device on a known VLAN.</p> <p><i>all</i> – For IP-MAC-port binding all specifies all the IP-MAC-port binding entries; for blocked address binding entries all specifies all the blocked VLANs and their bound physical addresses.</p> <p><i><port 1-28></i> – Specifies a port to be deleted for address binding.</p>
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To delete all address binding entries on the Switch:

```
DES-1210-28/ME:5# delete address_binding ip_mac all
Command: delete address_binding ip_mac all
```

Success.

DES-1210-28/ME:5#

show address_binding

Purpose	Used to display IP-MAC-port binding entries.
Syntax	show address_binding {[<i>ip_mac</i> [<i>all</i> { <i>ipaddress</i> < <i>ipaddr</i> > <i>mac_address</i> < <i>macaddr</i> >}] <i>blocked</i> [<i>all</i> <i>vlan_name</i> < <i>vlan_name</i> > <i>mac_address</i> < <i>macaddr</i> > <i>port</i> < <i>port 1-28</i> >] <i>ports</i>]}
Description	This command is used to display IP-MAC-port binding entries. Four different kinds of information can be viewed. <i>ip_mac</i> – Address binding entries can be viewed by entering the physical and IP addresses of the device. <i>blocked</i> – Blocked address binding entries (bindings between VLAN names and MAC addresses) can be viewed by entering the VLAN name and the physical address of the device. <i>ports</i> – The number of enabled ports on the device.
Parameters	<i>ip_mac</i> – The database the user creates for address binding. <i>all</i> – For IP MAC binding <i>all</i> specifies all the IP-MAC-port binding entries; for blocked address binding entries <i>all</i> specifies all the blocked VLANs and their bound physical addresses. <i>blocked</i> – The address database that the system auto learns and blocks. < <i>ipaddr</i> > – The IP address of the device where the IP-MAC-port binding is made. < <i>macaddr</i> > – The MAC address of the device where the IP-MAC-port binding is made. <i>vlan_name</i> < <i>string 20</i> > – The VLAN name of the VLAN that is bound to a MAC address in order to block a specific device on a known VLAN. <i>port</i> < <i>port 1-28</i> > – Specifies a port to be displayed for the address binding on the Switch.
Restrictions	None.

Example usage:

To display address binding entries on the Switch:

```
DES-1210-28/ME:5# show address_binding ip_mac all
```

```
Command: show address_binding ip_mac all
```

IP Address	MAC Address	Port
-----	-----	----
10.0.0.21	00-00-00-00-01-02	3

```
DES-1210-28/ME:5#
```

show address_binding auto_scan list

Purpose	Used to display IP-MAC-port binding entries.
Syntax	show address_binding auto_scan list
Description	This command is used to display auto scan list of address binding on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the auto scan list of address binding on the Switch:

```
DES-1210-28/ME:5# show address_binding auto_scan list
```

```
Command: show address_binding auto_scan list
```

```
VLAN IP Address    MAC Address    Port Bound
-----
```

```
DES-1210-28/ME:5#
```

enable address_binding dhcp_snoop

Purpose	Used to enable IP-MAC-port binding DHCP Snooping.
Syntax	enable address_binding dhcp_snoop ports [<portlist> all]
Description	This command is used to enable IP-MAC-port binding DHCP snooping entries.
Parameters	<i>[<portlist> all]</i> – Specifies a port, a range of ports or all ports to be enabled of the address binding DHCP snooping on the Switch.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To enable the DHCP snooping of address binding for port 3~5 on the Switch:

```
DES-1210-28/ME:5# enable address_binding dhcp_snoop ports 3-5
```

```
Command: enable address_binding dhcp_snoop ports 3-5
```

```
Success.
```

```
DES-1210-28/ME:5#
```

disable address_binding dhcp_snoop

Purpose	Used to disable IP-MAC-port binding DHCP Snooping.
Syntax	disable address_binding dhcp_snoop ports [<portlist> all]
Description	This command is used to disable IP-MAC-port binding DHCP snooping entries.
Parameters	<i>[<portlist> all]</i> – Specifies a port, a range of ports or all ports to be enabled of the address binding DHCP snooping on the Switch.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To disable the DHCP snooping of address binding for port 3~5 on the Switch:

```
DES-1210-28/ME:5# disable address_binding dhcp_snoop ports 4  
Command: disable address_binding dhcp_snoop ports 4  
  
Success.  
DES-1210-28/ME:5#
```

NETWORK MANAGEMENT (SNMP) COMMANDS

The Switch supports the Simple Network Management Protocol (SNMP) versions 1, 2c, and 3. Users can specify which version of the SNMP users want to use to monitor and control the Switch. The three versions of SNMP vary in the level of security provided between the management station and the network device. The following table lists the security features of the three SNMP versions:

SNMP Version	Authentication Method	Description
v1	Community String	Community String is used for authentication - NoAuthNoPriv
v2c	Community String	Community String is used for authentication - NoAuthNoPriv
v3	Username	Username is used for authentication – NoAuthNoPriv
v3	MD5 or SHA	Authentication is based on the HMAC-MD5 or HMAC-SHA algorithms – AuthNoPriv
v3	MD5 DES or SHA DES	Authentication is based on the HMAC-MD5 or HMAC-SHA algorithms – AuthPriv. DES 56-bit encryption is added based on the CBC-DES(DES-56) standard

The Network Management commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create snmp user	<username 32> <groupname 32> [v1 v2c v3 [MD5 <auth_password 32> SHA <auth_password 32> none] [DES <priv_password 32> none]
delete snmp user	<username 32> [v1 v2c v3]
show snmp user	
create snmp view	<view_name 32> <oid 32> <oid_mask 32 view_type [included excluded]
delete snmp view	<view_name 32> <oid 32>
show snmp view	{<view_name 32>}
create snmp community	<community_string 32> <username 32>
delete snmp community	<community_string 32>
show snmp community	{<community_string 32>}
config snmp engineID	<snmp_engineID 64>
show snmp engineID	
create snmp group	<groupname 32> [v1 v2c v3 [noauth_nopriv auth_nopriv auth_priv]{notify_view <view_name 32>}] {read_view <view_name 32> write_view <view_name 32>}
delete snmp group	<groupname 32> [v1 v2c v3] [auth_nopriv auth_priv noauth_priv]
show snmp global state	
show snmp groups	

Command	Parameter
create snmp host	<ipaddr> [v1 <username 32> v2c <username 32> v3 [noauth_nopriv auth_nopriv auth_priv] <username 32>]
delete snmp host	<ipaddr>
show snmp host	{<ipaddr>}
enable trusted_host	
disable trusted_host	
create trusted_host	<ipaddr>{network <network_address>} {application [telnet ssh snmp http https ping all]}
show trusted_host	
delete trusted_host	[<ipaddr> all network <network_address>]
enable snmp traps	
disable snmp traps	
enable snmp authenticate trap	
disable snmp authenticate trap	
show snmp traps	
config syslocation	<string 20>
config sysname	<string 20>
enable snmp	
disable snmp	
enable snmp DHCP_screening traps	
disable snmp DHCP_screening traps	
enable snmp IMPB_violation traps	
disable snmp IMPB_violation traps	
enable snmp fiber_port_link traps	
disable snmp fiber_port_link traps	
enable snmp firmware_upgrade_state traps	
disable snmp firmware_upgrade_state traps	
enable snmp LBD traps	

Command	Parameter
disable snmp LBD traps	
enable snmp port_security_violation traps	
disable snmp port_security_violation traps	
enable snmp rstpport_state_change traps	
disable snmp rstpport_state_change traps	
enable snmp system_device_bootup traps	
disable snmp system_device_bootup traps	
enable snmp twistedpair_port_link traps	
disable snmp twistedpair_port_link traps	
enable snmp duplicate_IP_detected traps	
disable snmp duplicate_IP_detected traps	

Each command is listed in detail, as follows:

create snmp user	
Purpose	To create a new SNMP user and add the user to an SNMP group.
Syntax	create snmp user <username 32> <groupname 32> [v1 v2c v3 [MD5 <auth_password 32> SHA <auth_password 32> none] [DES <priv_password 32> none]]
Description	The create snmp user command creates a new SNMP user and adds the user to an existing SNMP group.
Parameters	<p><i><username 32></i> - The new SNMP username, up to 32 alphanumeric characters.</p> <p><i><groupname 32></i> - The SNMP groupname the new SNMP user is associated with, up to 32 alphanumeric characters.</p> <p><i>auth</i> - The user may also choose the type of authentication</p>

algorithms used to authenticate the snmp user. The choices are:

- *MD5* – Specifies that the HMAC-MD5-96 authentication level to be used. md5 may be utilized by entering one of the following:
- *<auth_password 32>* - A string of between 1 and 32 alphanumeric characters used to authorize the agent to receive packets for the host.
- *SHA* – Specifies that the HMAC-SHA-96 authentication level will be used.
- *<priv_password 32>* - A string of between 1 and 32 alphanumeric characters used to authorize the agent to receive packets for the host.
- *DES* – Specifies that the DES authentication level will be used.

Restrictions

Only administrator or operate-level users can issue this command.

Example usage:

To create an SNMP user on the Switch:

```
DES-1210-28/ME:5# create snmp user dlink SW22 v3 MD5 1234 DES jklj22
Command: create snmp user dlink SW22 v3 MD5 1234 DES jklj22
```

Success!

```
DES-1210-28/ME:5#
```

delete snmp user

Purpose	To remove an SNMP user from an SNMP group and also to delete the associated SNMP group.
Syntax	delete snmp user <username 32> [v1 v2c v3]
Description	The delete snmp user command removes an SNMP user from its SNMP group and then deletes the associated SNMP group.
Parameters	<i><username 32></i> - A string of up to 32 alphanumeric characters that identifies the SNMP user to be deleted.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To delete a previously created SNMP user on the Switch:

```
DES-1210-28/ME:5# delete snmp user dlink v3
Command: delete snmp user dlink v3
```

Success!

show snmp user

Purpose	To display information about each SNMP username in the SNMP group username table.
---------	---

Syntax	show snmp user
Description	The show snmp user command displays information about each SNMP username in the SNMP group username table.
Parameters	None.
Restrictions	None.

Example usage:

To display the SNMP users currently configured on the Switch:

```
DES-1210-28/ME:5# show snmp user
Command: show snmp user
```

Username	Group Name	SNMP Version	Auth-Protocol	PrivProtocol
ReadOnly	ReadOnly	V1	None	None
ReadOnly	ReadOnly	V2	None	None
ReadWrite	ReadWrite	V1	None	None
ReadWrite	ReadWrite	V2	None	None

Total Entries: 4

```
DES-1210-28/ME:5#
```

create snmp view

Purpose	To assign views to community strings to limit which MIB objects an SNMP manager can access.
Syntax	create snmp view <view_name 32> <oid 32> <oid_mask 32 view_type [included excluded]
Description	The create snmp view command assigns views to community strings to limit which MIB objects an SNMP manager can access.
Parameters	<p><view_name 32> – A string of up to 30 alphanumeric characters that identifies the SNMP view to be created.</p> <p><oid 32> – The object ID that identifies an object tree (MIB tree) to be included or excluded from access by an SNMP manager.</p> <p><oid_mask 32> – The object ID mask that identifies an object tree (MIB tree) to be included or excluded from access by an SNMP manager.</p> <p><i>included</i> – Includes this object in the list of objects that an SNMP manager can access.</p> <p><i>excluded</i> – Excludes this object from the list of objects that an SNMP manager can access.</p>
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To create an SNMP view:

```
DES-1210-28/ME:5# create snmp view dlink 1.3.6 1.1.1 view_type excluded
Command: create snmp view dlink 1.3.6 1.1.1 view_type excluded
```

Success!

DES-1210-28/ME:5#

delete snmp view

Purpose	To remove an SNMP view entry previously created on the Switch.
Syntax	delete snmp view <view_name 32> <oid 32>
Description	The delete snmp view command removes an SNMP view previously created on the Switch.
Parameters	<p><view_name 32> – A string of up to 32 alphanumeric characters that identifies the SNMP view to be deleted.</p> <p><oid 32> – The object ID that identifies an object tree (MIB tree) that is deleted from the Switch.</p>
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To delete a previously configured SNMP view from the Switch:

```
DES-1210-28/ME:5# delete snmp view dlink 1.3.6
Command: delete snmp view dlink 1.3.6

Success.

DES-1210-28/ME:5#
```

show snmp view

Purpose	To display an SNMP view previously created on the Switch.
Syntax	show snmp view {<view_name 32>}
Description	The show snmp view command displays an SNMP view previously created on the Switch.
Parameters	<view_name 32> – A string of up to 30 alphanumeric characters that identifies the SNMP view to be displayed.
Restrictions	None.

Example usage:

To display SNMP view configuration:

```
DES-1210-28/ME:5# show snmp view
Command: show snmp view

SNMP View Table Configuration
View Name      Subtree OID      OID Mask      View Type
-----
dlink          1.2.3.4          1.1.1.1      Excluded
ReadWrite     1                 1             Included
```

Total Entries: 2

DES-1210-28/ME:5#

create snmp community

Purpose	To create an SNMP community string to define the relationship between the SNMP manager and an SNMP agent.
Syntax	create snmp community <community_string 32> <username 32>
Description	<p>The create snmp community command creates an SNMP community string and assigns access-limiting characteristics to this community string. The community string acts like a password to permit access to the agent on the Switch. One or more of the following characteristics can be associated with the community string:</p> <p>An Access List of IP addresses of SNMP managers that are permitted to use the community string to gain access to the Switch's SNMP agent.</p> <p>An MIB view that defines the subset of all MIB objects to be accessible to the SNMP community.</p> <p>Read/write or read-only level permission for the MIB objects accessible to the SNMP community.</p>
Parameters	<p><i><community_string 32></i> - A string of up to 32 alphanumeric characters that is used to identify members of an SNMP community. This string is used like a password to give remote SNMP managers access to MIB objects in the Switch's SNMP agent.</p> <p><i><username 32></i> - A string of up to 32 alphanumeric characters that is used to identify the group of MIB objects that a remote SNMP manager is allowed to access on the Switch.</p>
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To create the SNMP community string 'dlink:'

DES-1210-28/ME:5# create snmp community dlinkgroup dlink

Success.

DES-1210-28/ME:5#

delete snmp community

Purpose	To remove a specific SNMP community string from the Switch.
Syntax	delete snmp community <community_string 32>
Description	The delete snmp community command removes a previously defined SNMP community string from the Switch.
Parameters	<i><community_string 32></i> - A string of up to 32 alphanumeric characters that is used to identify members of an SNMP community to delete. This string is used like a password to give remote SNMP managers access to MIB objects in the Switch's SNMP agent.

Restrictions	Only administrator or operate-level users can issue this command.
--------------	---

Example usage:

To delete the SNMP community string 'dlink':

```
DES-1210-28/ME:5# delete snmp community dlink
Command: delete snmp community dlink

Success!

DES-1210-28/ME:5#
```

show snmp community

Purpose	To display SNMP community strings configured on the Switch.
Syntax	show snmp community {<community_string 32>}
Description	The show snmp community command displays SNMP community strings that are configured on the Switch.
Parameters	<community_string 32> - A string of up to 20 alphanumeric characters that is used to identify members of an SNMP community. This string is used like a password to give remote SNMP managers access to MIB objects in the Switch's SNMP agent.
Restrictions	None.

Example usage:

To display the currently entered SNMP community strings:

```
DES-1210-28/ME:5# show snmp community
Command: show snmp community

SNMP Community Table
(Maximum Entries : 10)

Community Name      User Name
-----
public              ReadOnly
private             ReadWrite

Total Entries: 2

DES-1210-28/ME:5#
```

config snmp engineID

Purpose	To configure a name for the SNMP engine on the Switch.
Syntax	config snmp engineID <snmp_engineID 64>
Description	The config snmp engineID command configures a name for the SNMP engine on the Switch.
Parameters	<snmp_engineID 64> - A string, of between 10 and 64

	alphanumeric characters, to be used to identify the SNMP engine on the Switch.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To give the SNMP agent on the Switch:

```
DES-1210-28/ME:5# config snmp engineID 12345678900
Command: config snmp engineID 12345678900

Success!

DES-1210-28/ME:5#
```

show snmp engineID

Purpose	To display the identification of the SNMP engine on the Switch.
Syntax	show snmp engineID
Description	The show snmp engineID command displays the identification of the SNMP engine on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the current name of the SNMP engine on the Switch:

```
DES-1210-28/ME:5# show snmp engineID
Command: show snmp engineID

Default SNMP Engine ID : 4445532d313231

SNMP Engine ID      : 012345678900

DES-1210-28/ME:5#
```

create snmp group

Purpose	To create a new SNMP group, or a table that maps SNMP users to SNMP views.
Syntax	create snmp group <groupname 32> [v1 v2c v3 [noauth_nopriv auth_nopriv auth_priv]{notify_view <view_name 32>}] {read_view <view_name 32> write_view <view_name 32>}
Description	The create snmp group command creates a new SNMP group, or a table that maps SNMP users to SNMP views.
Parameters	<groupname 32> – A name of up to 30 alphanumeric characters that identifies the SNMP group the new SNMP user is to be associated with. v1 – Specifies that SNMP version 1 is to be used. The Simple Network Management Protocol (SNMP), version 1, is a network management protocol that provides a means to monitor and control

network devices.

v2c – Specifies that SNMP version 2c is to be used. The SNMP v2c supports both centralized and distributed network management strategies. It includes improvements in the Structure of Management Information (SMI) and adds some security features.

v3 – Specifies that the SNMP version 3 is to be used. SNMP v3 provides secure access to devices through a combination of authentication and encrypting packets over the network. SNMP v3 adds:

- Message integrity – Ensures that packets have not been tampered with during transit.
- Authentication – Determines if an SNMP message is from a valid source.
- Encryption – Scrambles the contents of messages to prevent it from being viewed by an unauthorized source.

noauth_nopriv – Specifies that there is no authorization and no encryption of packets sent between the Switch and a remote SNMP manager.

auth_nopriv – Specifies that authorization is required, but there is no encryption of packets sent between the Switch and a remote SNMP manager.

auth_priv – Specifies that authorization is required, and that packets sent between the Switch and a remote SNMP manager are encrypted.

read_view – Specifies that the SNMP group being created can request SNMP messages.

- *<view_name 32>* – A string of up to 32 objects that a remote SNMP manager is allowed to access on the Switch.

write_view – Specifies that the SNMP group being created has write privileges.

- *<view_name 32* identifies the group of MIB objects that a remote SNMP manager is allowed to access on the Switch.

notify_view – Specifies that the SNMP group being created can receive SNMP trap messages generated by the Switch's SNMP agent.

- *<view_name 32>* – A string of up to 32 alphanumeric characters that identifies the group of MIB objects that a remote SNMP manager is allowed to access on the Switch.

Restrictions

Only administrator or operate-level users can issue this command.

Example usage:

To create an SNMP group named 'sg1:'

```
DES-1210-28/ME:5# create snmp group sg1 v2c read_view sg1 write_view sg1
notify_view sg1
```

```
Command: create snmp group sg1 v2c read_view sg1 write_view sg1 notify_view
sg1
```

Success!

```
DES-1210-28/ME:5#
```


delete snmp group

Purpose	To remove an SNMP group from the Switch.
Syntax	delete snmp group <groupname 32> [v1 v2c v3 [auth_priv noauth_nopriv]]
Description	The delete snmp group command removes an SNMP group from the Switch.
Parameters	<groupname 32> - A string of that identifies the SNMP group the new SNMP user will be associated with. Up to 32 alphanumeric characters.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To delete the SNMP group named 'sg1':

```
DES-1210-28/ME:5# delete snmp group sg1 v3 auth_priv
Command: delete snmp group sg1 v3 auth_priv

Success!

DES-1210-28/ME:5#
```

show snmp global state

Purpose	To display the global state of SNMP currently configured on the Switch.
Syntax	show snmp global state
Description	The show snmp global state command displays the global state of SNMP groups currently configured on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the currently configured SNMP global state on the Switch:

```
DES-1210-28/ME:5# show snmp global state
Command: show snmp global state

SNMP Global State : Enable

DES-1210-28/ME:5#
```

show snmp groups

Purpose	To display the group-names of SNMP groups currently configured on the Switch. The security model, level, and status of each group are also displayed.
---------	---

Syntax	show snmp groups
Description	The show snmp groups command displays the group-names of SNMP groups currently configured on the Switch. The security model, level, and status of each group are also displayed.
Parameters	None.
Restrictions	None.

Example usage:

To display the currently configured SNMP groups on the Switch:

```
DES-1210-28/ME:5# show snmp groups
Command: show snmp groups

SNMP Group Table

Group Name  Read View  Write View  Notify View  Security Model  Security Level
-----
sg1         df         df          d            v3             AuthPriv
ReadOnly    ReadWrite  ---         ReadWrite    v1             NoAuthNoPriv
ReadOnly    ReadWrite  ---         ReadWrite    v2c            NoAuthNoPriv
ReadWrite   ReadWrite  ReadWrite   ReadWrite    v1             NoAuthNoPriv
ReadWrite   ReadWrite  ReadWrite   ReadWrite    v2c            NoAuthNoPriv

Total Entries: 5

DES-1210-28/ME:5#
```

create snmp host

Purpose	To create a recipient of SNMP traps generated by the Switch's SNMP agent.
Syntax	create snmp host <ipaddr> [v1 <username 32> v2c <username 32> v3 [noauth_nopriv auth_nopriv auth_priv] <username 32>]
Description	The create snmp host command creates a recipient of SNMP traps generated by the Switch's SNMP agent.
Parameters	<p><i><ipaddr></i> – The IP address of the remote management station to serve as the SNMP host for the Switch.</p> <p><i>v1</i> – Specifies that SNMP version 1 is to be used. The Simple Network Management Protocol (SNMP), version 1, is a network management protocol that provides a means to monitor and control network devices.</p> <p><i>v2c</i> – Specifies that SNMP version 2c is to be used. The SNMP v2c supports both centralized and distributed network management strategies. It includes improvements in the Structure of Management Information (SMI) and adds some security features.</p> <p><i>v3</i> – Specifies that the SNMP version 3 is to be used. SNMP v3 provides secure access to devices through a combination of authentication and encrypting packets over the network. SNMP v3 adds:</p> <ul style="list-style-type: none"> • Message integrity – ensures that packets have not been

tampered with during transit.

- Authentication – determines if an SNMP message is from a valid source.
- Encryption – scrambles the contents of messages to prevent it being viewed by an unauthorized source.

<username 32> – A string of up to 32 alphanumeric characters that identifies user name of an SNMP community. This string is used like a password to give remote SNMP managers access to MIB objects in the Switch's SNMP agent.

noauth_nopriv – Specifies that there is no authorization and no encryption of packets sent between the Switch and a remote SNMP manager.

auth_nopriv – Specifies that authorization is required, but there is no encryption of packets sent between the Switch and a remote SNMP manager.

auth_priv – Specifies that authorization is required, and that packets sent between the Switch and a remote SNMP manager are encrypted.

Restrictions

Only Administrator and oper-level users can issue this command

Example usage:

To create an SNMP host to receive SNMP messages:

```
DES-1210-28/ME:5# create snmp host 10.90.90.22 v3 noauth_nopriv
dlink
```

```
Command: create snmp host 10.90.90.22 v3 noauth_nopriv dlink
```

```
Success!
```

```
DES-1210-28/ME:5#
```

delete snmp host

Purpose	To remove a recipient of SNMP traps generated by the Switch's SNMP agent.
Syntax	delete snmp host <ipaddr>
Description	The delete snmp host command deletes a recipient of SNMP traps generated by the Switch's SNMP agent.
Parameters	<i><ipaddr></i> – The IP address of a remote SNMP manager that receives SNMP traps generated by the Switch's SNMP agent.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To delete an SNMP host entry:

```
DES-1210-28/ME:5# delete snmp host 10.90.90.22
```

```
Command: delete snmp host 10.90.90.22
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show snmp host

Purpose	To display the recipient of SNMP traps generated by the Switch's SNMP agent.
Syntax	show snmp host {<ipaddr>}
Description	The show snmp host command is used to display the IP addresses and configuration information of remote SNMP managers that are designated as recipients of SNMP traps generated by the Switch's SNMP agent.
Parameters	<ipaddr> – The IP address of a remote SNMP manager that receives SNMP traps generated by the Switch's SNMP agent.
Restrictions	None.

Example usage:

To display the currently configured SNMP hosts on the Switch:

```
DES-1210-28/ME:5# show snmp host
Command: show snmp host

SNMP Host Table
(Maximum Entries : 10)
Host IP Address   SNMP Version   Community Name/SNMPv3 User Name
-----
10.90.90.22      V3-NoAuthNoPriv  dlink

Total Entries : 1

DES-1210-28/ME:5#
```

enable trusted_host

Purpose	To enable the trusted host.
Syntax	enable trusted_host
Description	The enable trusted_host command enables the trusted host feature.
Parameters	None.
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To enable the trusted host on the Switch:

```
DES-1210-28/ME:5# enable trusted_host
Command: enable trusted_host

Success!

DES-1210-28/ME:5#
```

disable trusted_host

Purpose	To enable the trusted host.
Syntax	disable trusted_host
Description	The disable trusted_host command disables the trusted host feature.
Parameters	None.
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To disable the trusted host on the Switch:

```
DES-1210-28/ME:5# disable trusted_host
```

```
Command: disable trusted_host
```

```
Success!
```

```
DES-1210-28/ME:5#
```

create trusted_host

Purpose	To create a trusted host.
Syntax	create trusted_host <ipaddr>{network <network_address>}
Description	The create trusted_host command creates a trusted host. The Switch allows specifying up to 30 IP addresses that are allowed to manage the Switch via in-band based management software. These IP addresses must be members of the Management VLAN. If no IP addresses are specified, then there is nothing to prevent any IP address from accessing the Switch, provided the user knows the Username and Password.
Parameters	<i><ipaddr></i> – The IP address of the trusted host to be created. <i><network_address></i> – The subnet mask of the trusted host to be created. This parameter is optional. If not specified, the default subnet mask is 255.255.255.0.
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To create the trusted host:

```
DES-1210-28/ME:5# create trusted_host 10.90.90.91
```

```
Command: create trusted_host 10.90.90.91
```

```
Success.
```

```
DES-1210-28/ME:5#
```

show trusted_host

Purpose	To display a list of trusted hosts entered on the Switch using the create trusted_host command above.
---------	---

Syntax	show trusted_host
Description	The show trusted_host command displays a list of trusted hosts entered on the Switch using the create trusted_host command above.
Parameters	None.
Restrictions	None.

Example usage:

To display the list of trusted hosts:

```
DES-1210-28/ME:5# show trusted_host
Command: show trusted_host
```

```
Trusted Host Status : Enable
```

Management Stations

```
IP Address    Subnet Mask
-----
10.90.90.91   255.255.255.255
10.90.90.92   255.255.255.255
```

```
Total Entries: 2
```

```
DES-1210-28/ME:5#
```

delete trusted_host

Purpose	To delete a trusted host entry made using the create trusted_host command above.
Syntax	delete trusted_host [<i><ipaddr></i> all network <i><network_address></i>]
Description	The delete trusted_host command deletes a trusted host entry made using the create trusted_host command above.
Parameters	<i><ipaddr></i> – The IP address of the trusted host. <i>all</i> – The all IP address of the trusted host. <i>network</i> <i><network_address></i> – The subnet mask of the trusted host to be deleted. This parameter is optional.
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To delete a trusted host with an IP address **10.90.90.91**:

```
DES-1210-28/ME:5# delete trusted_host 10.90.90.91
```

```
Command: delete trusted_host 10.90.90.91
```

```
Success.
```

```
DES-1210-28/ME:5#
```

enable snmp traps

Purpose	To enable SNMP trap support.
Syntax	enable snmp traps
Description	The enable snmp traps command enables SNMP trap support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To enable SNMP trap support on the Switch:

```
DES-1210-28/ME:5# enable snmp traps
Command: enable snmp traps

Success!

DES-1210-28/ME:5#
```

disable snmp traps

Purpose	To disable SNMP trap support on the Switch.
Syntax	disable snmp traps
Description	The disable snmp traps command disables SNMP trap support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To prevent SNMP traps from being sent from the Switch:

```
DES-1210-28/ME:5# disable snmp traps
Command: disable snmp traps

Success!

DES-1210-28/ME:5#
```

enable snmp authenticate trap

Purpose	To enable SNMP authentication trap support.
Syntax	enable snmp authenticate trap
Description	The enable snmp authenticate trap command enables SNMP authentication trap support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To turn on SNMP authentication trap support:

```
DES-1210-28/ME:5# enable snmp authenticate traps
Command: enable snmp authenticate traps

Success!

DES-1210-28/ME:5#
```

disable snmp authenticate trap

Purpose	To disable SNMP authentication trap support.
Syntax	disable snmp authenticate trap
Description	The disable snmp authenticate trap command disables SNMP authentication trap support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To disable the SNMP authentication trap support:

```
DES-1210-28/ME:5# disable snmp authenticate traps
Command: disable snmp authenticate traps

Success!

DES-1210-28/ME:5#
```

show snmp traps

Purpose	To display SNMP trap support status on the Switch.
Syntax	show snmp traps
Description	The show snmp traps command displays the SNMP trap support status currently configured on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To view the current SNMP trap support:

```
DES-1210-28/ME:5# show snmp traps
Command: show snmp traps

SNMP Traps : Disable
SNMP Authentication Traps : Disable
System Device Bootup : Disable
Fiber Port Link Up / Link Down : Disable
Twisted Pair Port Link Up / Link Down : Disable
RSTP Port State Change : Disable
Firmware Upgrade State : Disable
Port Security State : Disable
```


IMPBv2 State	: Disable
Loopback detection State	: Disable
DHCP server screen State	: Disable
Gratutious ARP State	: Disable
DES-1210-28/ME:5#	

config syslocation

Purpose	To enter a description of the location of the Switch.
Syntax	config syslocation <string 20>
Description	The config syslocation command enters a description of the location of the Switch. A maximum of 20 characters can be used.
Parameters	<string 20> - A maximum of 20 characters is allowed.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To configure the Switch location for 'HQ5F':

DES-1210-28/ME:5# config syslocation HQ5F
Command: config syslocation HQ5F
Success.
DES-1210-28/ME:5#

config sysname

Purpose	To define the name for the Switch.
Syntax	config sysname <string 20>
Description	The config sysname command defines the name of the Switch.
Parameters	<string 20> - A maximum of 20 characters is allowed.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To configure the Switch name as '28ME':

DES-1210-28/ME:5# config sysname 28ME
Command: config sysname 28ME
Success.
DES-1210-28/ME:5#

enable snmp

Purpose	To enable SNMP support.
Syntax	enable snmp

Description	The enable snmp command enables SNMP support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To enable SNMP support on the Switch:

```
DES-1210-28/ME:5# enable snmp
Command: enable snmp

Success!

DES-1210-28/ME:5#
```

disable snmp

Purpose	To disable SNMP support.
Syntax	disable snmp
Description	The disable snmp command enables SNMP support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To disable SNMP support on the Switch:

```
DES-1210-28/ME:5# disable snmp
Command: disable snmp

Success!

DES-1210-28/ME:5#
```

enable snmp DHCP_screening traps

Purpose	To enable SNMP DHCP screening traps.
Syntax	enable snmp DHCP_screening traps
Description	The enable snmp DHCP_screening traps command enables SNMP DHCP screening traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To enable SNMP DHCP screening traps support on the Switch:

```
DES-1210-28/ME:5# enable snmp DHCP_screening traps
Command: enable snmp DHCP_screening traps

Success!
```

DES-1210-28/ME:5#

disable snmp DHCP_screening traps

Purpose	To disable SNMP DHCP screening traps.
Syntax	disable snmp DHCP_screening traps
Description	The disable snmp DHCP_screening traps command enables SNMP DHCP screening traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To disable SNMP DHCP screening traps support on the Switch:

```
DES-1210-28/ME:5# disable snmp DHCP_screening traps
Command: disable snmp DHCP_screening traps

Success!

DES-1210-28/ME:5#
```

enable snmp IMPB_violation traps

Purpose	To enable SNMP IMPB violation traps.
Syntax	enable snmp IMPB_violation traps
Description	The enable snmp IMPBv2 traps command enables SNMP IMPB violation traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To enable SNMP IMPB violation traps support on the Switch:

```
DES-1210-28/ME:5# enable snmp IMPB_violation traps
Command: enable snmp IMPB_violation traps

Success!

DES-1210-28/ME:5#
```

disable snmp IMPB_violation traps

Purpose	To disable SNMP IMPB violation traps.
Syntax	disable snmp IMPB_violation traps
Description	The disable snmp IMPB_violation traps command enables SNMP IMPB violation traps support on the Switch.
Parameters	None.

Restrictions	Only Administrator or operator-level users can issue this command
--------------	---

Example usage:

To disable SNMP IMPB violation traps support on the Switch:

```
DES-1210-28/ME:5# disable snmp IMPB_violation traps
Command: disable snmp IMPB_violation traps

Success!

DES-1210-28/ME:5#
```

enable snmp fiber_port_link traps

Purpose	To enable SNMP fiber port link traps support on the Switch.
Syntax	enable snmp fiber_port_link traps
Description	The enable snmp fiber_port_link traps command enables SNMP fiber port link traps support on the Switch. After enables the SNMP fiber port link traps support, the Switch will send out a trap to the SNMP manage host when the fiber port is link up or link down.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To enable SNMP fiber port link traps support on the Switch:

```
DES-1210-28/ME:5# enable snmp fiber_port_link traps
Command: enable snmp fiber_port_link traps

Success!

DES-1210-28/ME:5#
```

disable snmp fiber_port_link traps

Purpose	To disable SNMP fiber port link traps.
Syntax	disable snmp fiber_port_link traps
Description	The disable snmp fiber_port_link traps command disables SNMP fiber port link traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To disable SNMP fiber port link traps support on the Switch:

```
DES-1210-28/ME:5# disable snmp fiber_port_link traps
Command: disable snmp fiber_port_link traps
```

```
Success!
```

```
DES-1210-28/ME:5#
```

enable snmp firmware_upgrade_state traps

Purpose	To enable SNMP firmware upgrade state traps.
Syntax	enable snmp firmware_upgrade_state traps
Description	The enable snmp firmware_upgrade_state traps command enables SNMP firmware upgrade state traps support on the Switch. After enables the SNMP firmware upgrade state traps support, the Switch will send out a trap to the SNMP manage host when the firmware upgrade is succeed or fail.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable SNMP firmware upgrade state traps support on the Switch:

```
DES-1210-28/ME:5# enable snmp firmware_upgrade_state traps
Command: enable snmp firmware_upgrade_state traps

Success!

DES-1210-28/ME:5#
```

disable snmp firmware_upgrade_state traps

Purpose	To disable SNMP firmware upgrade state traps.
Syntax	disable snmp firmware_upgrade_state traps
Description	The disable snmp firmware_upgrade_state traps command disables SNMP firmware upgrade state traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable SNMP firmware upgrade state traps support on the Switch:

```
DES-1210-28/ME:5# disable snmp firmware_upgrade_state traps
Command disable enable snmp firmware_upgrade_state traps

Success!

DES-1210-28/ME:5#
```

enable snmp LBD traps

Purpose	To enable SNMP LBD traps.
---------	---------------------------

Syntax	enable snmp LBD traps
Description	The enable snmp LBD traps command enables SNMP LBD traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable SNMP LBD traps support on the Switch:

```
DES-1210-28/ME:5# enable snmp LBD traps
Command: enable snmp LBD traps
```

```
Success!
```

```
DES-1210-28/ME:5#
```

disable snmp LBD traps

Purpose	To disable SNMP LBD traps.
Syntax	disable snmp LBD traps
Description	The disable snmp LBD traps command disables SNMP LBD traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To disable SNMP LBD traps support on the Switch:

```
DES-1210-28/ME:5# disable snmp LBD traps
Command: disable snmp LBD traps
```

```
Success!
```

```
DES-1210-28/ME:5#
```

enable snmp port_security_violation traps

Purpose	To enable SNMP port security violation traps.
Syntax	enable snmp port_security_violation traps
Description	The enable snmp port_security_violation traps command enables SNMP port security violation traps on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable SNMP port security violation traps support on the Switch:

```
DES-1210-28/ME:5# enable snmp port_security_violation traps
```

Command: enable snmp port_security_violation traps

Success!

DES-1210-28/ME:5#

disable snmp port_security_violation traps

Purpose	To disable SNMP port security violation traps.
Syntax	disable snmp port_security_violation traps
Description	The disable snmp port_security_violation traps command disables SNMP port security violation traps on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable SNMP port security violation traps support on the Switch:

DES-1210-28/ME:5# disable snmp port_security_violation traps

Command: disable snmp port_security_violation traps

Success!

DES-1210-28/ME:5#

enable snmp rstpport_state_change traps

Purpose	To enable SNMP rstp port state change traps support on the Switch.
Syntax	enable snmp rstpport_state_change traps
Description	The enable snmp rstpport_state_change traps command enables SNMP rstp port state change traps support on the Switch. After enables the SNMP RSTP port state change traps support, the Switch will send out a trap when the state of RSTP port is changed.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable SNMP RSTP port state change traps support on the Switch:

DES-1210-28/ME:5# enable snmp rstpport_state_change traps

Command: enable snmp rstpport_state_change traps

Success!

DES-1210-28/ME:5#

disable snmp rstpport_state_change traps

Purpose	To disable SNMP RSTP port state change traps.
Syntax	disable snmp rstpport_state_change traps
Description	The disable snmp rstpport_state_change traps command disables SNMP RSTP port state change traps on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable SNMP RSTP port state change traps support on the Switch:

```
DES-1210-28/ME:5# disable snmp rstpport_state_change traps
```

```
Command: disable snmp rstpport_state_change traps
```

```
Success!
```

```
DES-1210-28/ME:5#
```

enable snmp system_device_bootup traps

Purpose	To enable SNMP system device bootup traps support on the Switch.
Syntax	enable snmp system_device_bootup traps
Description	The enable snmp system_device_bootup traps command enables SNMP system device bootup traps support on the Switch. After enables the SNMP system device bootup traps support, the Switch will send out a trap to the SNMP manage host when the device is power on.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the SNMP system device bootup traps on the Switch:

```
DES-1210-28/ME:5# enable snmp system_device_bootup traps
```

```
Command: enable snmp system_device_bootup traps
```

```
Success!
```

```
DES-1210-28/ME:5#
```

disable snmp system_device_bootup traps

Purpose	To disable SNMP system device bootup traps support on the Switch.
Syntax	disable snmp system_device_bootup traps
Description	The disable snmp system_device_bootup traps command disables SNMP system device bootup traps support on the Switch.

Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the SNMP system device bootup traps on the Switch:

```
DES-1210-28/ME:5# disable snmp system_device_bootup traps
Command: disable snmp system_device_bootup traps

Success!

DES-1210-28/ME:5#
```

enable snmp twistedpair_port_link traps

Purpose	To enable SNMP twisted pair ports link traps support on the Switch.
Syntax	enable snmp twistedpair_port_link traps
Description	The enable snmp twistedpair_port_link traps command enables SNMP twisted pair ports link traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the SNMP twisted pair ports link traps on the Switch:

```
DES-1210-28/ME:5# enable snmp twistedpair_port_link traps
Command: enable snmp twistedpair_port_link traps

Success!

DES-1210-28/ME:5#
```

disable snmp twistedpair_port_link traps

Purpose	To disable SNMP twisted pair ports link traps support on the Switch.
Syntax	disable snmp twistedpair_port_link traps
Description	The disable snmp twistedpair_port_link traps command enables SNMP twisted pair ports link traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the SNMP twisted pair ports link traps on the Switch:

```
DES-1210-28/ME:5# disable snmp twistedpair_port_link traps
Command: disable snmp twistedpair_port_link traps
```

Success!

DES-1210-28/ME:5#

enable snmp duplicate_IP_detected traps

Purpose	To enable SNMP duplicate IP detected traps support on the Switch.
Syntax	enable snmp duplicate_IP_detected traps
Description	The enable snmp duplicate_IP_detected traps command enables SNMP duplicate IP detected traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the SNMP duplicate_IP_detected traps on the Switch:

DES-1210-28/ME:5# enable snmp duplicate_IP_detected traps

Command: enable snmp duplicate_IP_detected traps

Success!

DES-1210-28/ME:5#

disable snmp duplicate_IP_detected traps

Purpose	To disable SNMP duplicate IP detected traps support on the Switch.
Syntax	disable snmp duplicate_IP_detected traps
Description	The disable snmp duplicate_IP_detected traps command disables SNMP duplicate IP detected traps support on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the SNMP duplicate_IP_detected traps on the Switch:

DES-1210-28/ME:5# disable snmp duplicate_IP_detected traps

Command: disable snmp duplicate_IP_detected traps

Success!

DES-1210-28/ME:5#

DOWNLOAD/UPLOAD COMMANDS

The Download/Upload commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
download	[configuration <ipaddr> <path_filename 64> startup] [firmware <ipaddr> <string 64>]
upload	[[firmware <ipaddr> <path_filename 64>] [cfg_toTFTP <ipaddr> <path_filename 64> config_id <value 1-2>] [log_toTFTP <ipaddr> <path_filename 64>]]

Each command is listed in detail, as follows:

download	
Purpose	To download and install a firmware, boot, or switch configuration file from a TFTP server.
Syntax	download [configuration <ipaddr> <path_filename 64> startup] [firmware <ipaddr> <string 64>]
Description	The download command downloads a firmware, boot, or switch configuration file from a TFTP server.
Parameters	<p><i>configuration</i> – Downloads a switch configuration file from a TFTP server.</p> <p><ipaddr> – The IP address of the TFTP server.</p> <p><path_filename 64> – The DOS path and filename of the switch configuration file, up to 64 characters, on the TFTP server. For example, C:\31xx.had.</p> <p><i>startup</i> – Indicates the Configuration file is to be downloaded to the startup config.</p> <p><i>firmware</i> – Downloads and installs firmware on the Switch from a TFTP server.</p> <p><string 64> – The DOS path and filename of the firmware file, up to 64 characters, on the TFTP server. For example, C:\31xx.had.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To download a firmware file:

```
DES-1210-28/ME:5# download firmware 1.1.1.23 1\des_1210-28me.ros
Command: download firmware 1.1.1.23 1\des_1210-28me.ros
01-Jan-2000 01:19:48 %COPY-I-FILECOPY: Files Copy – source URL tftp://1.1.1.23 /1\
des_1210-28me.ros destination URL Unit all flash://image
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
```

```

!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!01-Jan-2000 01:22:49 %COPY-W-TRAP:
The copy operation was completed successfully
!
3920460 bytes copied in 00:03:01 [hh:mm:ss]

DES-1210-28/ME:5#
    
```

To download a configuration file:

```

DES-1210-28/ME:5# download configuration 10.48.74.121 c:\cfg\setting.txt
Overwrite file [startup-config] ?[Yes/press any key for no]....
01-Jan-200003:19:46%COPY-I-FILECPY:FilesCopy-source URL tftp://10.48.74.121/1.txt
destination
URL flash://startup-config
Success.

Success.

.....01-Jan-2000 03:18:40 %COPY-N-TRAP: The copy operation was completed
successfully!
Copy: 267 bytes copied in 00:00:08 [hh:mm:ss]
DES-1210-28/ME:5#
    
```

upload	
Purpose	To upload the current switch settings to a TFTP server.
Syntax	upload [[firmware <ipaddr> <path_filename 64>] [cfg_toTFTP <ipaddr> <path_filename 64> config_id <value 1-2>] [log_toTFTP <ipaddr> <path_filename 64>]]
Description	The upload command uploads the Switch's current settings to a TFTP server.
Parameters	<i>firmware</i> - Specifies that the Switch's current firmware are to be uploaded to the TFTP server. <ipaddr> - The IP address of the TFTP server. The TFTP server must be on the same IP subnet as the Switch. <path_filename 64> - The location of the Switch configuration file on the TFTP server. config_id <value 1-2> - Specifies the config id which to be uploaded.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

```

DES-1210-28/ME:5# upload log_toTFTP 1.1.1.23 des-1210-28me.ros
Command: upload log_toTFTP 1.1.1.23 des-1210-28me.ros
01-Jan-2000 01:26:11 %COPY-I-FILECPY: Files Copy - source
URL running-config destination URL tftp://1.1.1.23/1/running-
    
```

```
config
```

```
...01-Jan-2000 01:26:16 %COPY-W-TRAP: The copy operation  
was completed success fully!
```

```
158 bytes copied in 00:00:05 [hh:mm:ss]
```

```
DES-1210-28/ME:5#
```

DHCP RELAY COMMANDS

The DHCP Relay commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable dhcp_relay	
disable dhcp_relay	
config dhcp_relay add ipif system	<ipaddr>
config dhcp_relay delete ipif system	<ipaddr>
config dhcp_relay	hops <value 1-16>
config dhcp_relay option_82	[check [enable disable] policy [drop keep replace] remote_id [default user_define <string 32>] state [enable disable]]
show dhcp_relay	{ipif}
enable dhcp_local_relay	
disable dhcp_local_relay	
config dhcp_local_relay vlan	<vlan_name> vlanid <vidlist>] state[enable disable]
show dhcp_local_relay	

Each command is listed in detail, as follows:

enable dhcp_relay	
Purpose	To enable DHCP Relay server on the Switch
Syntax	enable dhcp_relay
Description	The enable dhcp_relay command sets the DHCP Relay to be globally enabled on the Switch and on all existing VLANs.
Parameters	None.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To enable DHCP Relay on the Switch:

```
DES-1210-28/ME:5# enable dhcp_relay
Command: enable dhcp_relay
```

```
Success!
```

```
DES-1210-28/ME:5#
```

disable dhcp_relay

Purpose	To disable DHCP Relay server on the Switch
Syntax	disable dhcp_relay
Description	The disable dhcp_relay command sets the DHCP Relay to be globally disabled on the Switch and on all existing VLANs.
Parameters	None.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To disable DHCP Relay on the Switch:

```
DES-1210-28/ME:5# disable dhcp_relay
Command: disable dhcp_relay

Success!

DES-1210-28/ME:5#
```

config dhcp_relay add ipif system

Purpose	To define a DHCP server as a DHCP Relay server
Syntax	config dhcp_relay add ipif system <ipaddr>
Description	The config dhcp_relay add ipif system command adds DHCP servers as DHCP Relay servers.
Parameters	<ipaddr> – The IP address of the DHCP server. Up to 4 servers can be defined.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To add a DHCP server as a DHCP Relay server:

```
DES-1210-28/ME:5# config dhcp_relay add ipif System 10.6.150.49
Command: config dhcp_relay add ipif System 10.6.150.49

Success!

DES-1210-28/ME:5#
```

config dhcp_relay delete ipif system

Purpose	To delete a DHCP server from the DHCP Relay server list.
Syntax	config dhcp_relay delete ipif system <ipaddr>
Description	The config dhcp_relay delete ipif system command deletes a DHCP servers defined as a DHCP Relay server.
Parameters	<ipaddr> – The IP address of the DHCP server.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To remove a DHCP server from the DHCP Relay server list:

```
DES-1210-28/ME:5# config dhcp_relay delete ipif System 10.6.150.49
Command: config dhcp_relay delete ipif System 10.6.150.49

Success!

DES-1210-28/ME:5#
```

config dhcp_relay

Purpose	To delete a DHCP server from the DHCP Relay server list.
Syntax	config dhcp_relay hops <value 1-16>
Description	The config dhcp_relay hops command configures the DHCP/BOOTP relay feature.
Parameters	<i>hops <value 1-16></i> – Specifies the maximum number of relay agent hops that the DHCP packets can cross.
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To configure the DHCP relay on the Switch:

```
DES-1210-28/ME:5# config dhcp_relay hops 12
Command: config dhcp_relay hops 12

Success!

DES-1210-28/ME:5#
```


config dhcp_relay option_82

Purpose	To configure the check, policy and state of DHCP relay agent information option 82 of the Switch.
Syntax	config dhcp_relay option_82 [check [enable disable] policy [drop keep replace] remote_id [default user_define <string 32>] state [enable disable]]
Description	The config dhcp_relay option_82 is used to configure the check, policy and state of DHCP relay agent information option 82 of the Switch
Parameters	<p><i>check</i>: used to configure the check of DHCP relay agent information option 82 of the Switch.</p> <p><i>enable</i> – When the field is toggled to enable, the relay agent will check the validity of the packet's option 82 field. If the switch receives a packet that contains the option 82 field from a DHCP client, the switch drops the packet because it is invalid. In packets received from DHCP servers, the relay agent will drop invalid messages.</p> <p><i>disable</i> – When the field is toggled to disable, the relay agent will not check the validity of the packet's option 82 field.</p> <p><i>policy</i>: used to configure the re-forwarding policy of DHCP relay agent information option 82 of the Switch.</p> <p><i>replace</i> – The option 82 field will be replaced if the option 82 field already exists in the packet received from the DHCP client.</p> <p><i>drop</i> – The packet will be dropped if the option 82 field already exists in the packet received from the DHCP client.</p> <p><i>keep</i> – The option 82 field will be retained if the option 82 field already exists in the packet received from the DHCP client.</p> <p><i>state</i>: used to configure the state of DHCP relay agent information option 82 of the Switch.</p> <p><i>enable</i> – When this field is toggled to Enabled the relay agent will insert and remove DHCP relay information (option 82 field) in messages between DHCP server and client. When the relay agent receives the DHCP request, it adds the option 82 information, and the IP address of the relay agent (if the relay agent is configured), to the packet. Once the option 82 information has been added to the packet it is sent on to the DHCP server. When the DHCP server receives the packet, if the server is capable of option 82, it can implement policies like restricting the number of IP addresses that can be assigned to a single remote ID or circuit ID. Then the DHCP server echoes the option 82 field in the DHCP reply. The DHCP server unicasts the reply to the back to the relay agent if the request was relayed to the server by the relay agent. The switch verifies that it originally inserted the option 82 data. Finally, the relay agent removes the option 82 field and forwards the packet to the switch port that connects to the DHCP client that sent the DHCP request.</p> <p><i>disable</i> – If the field is toggled to disable the relay agent will not insert and remove DHCP relay information (option 82 field) in messages between DHCP servers and clients, and the check and policy settings will have no effect.</p>
Restrictions	Only Administrator or operate-level users can issue this command.

Example usage:

To disable the DHCP relay option 82 on the Switch:

```
DES-1210-28/ME:5# config dhcp_relay option_82 state disable
Command: config dhcp_relay option_82 state disable
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show dhcp_relay

Purpose	To display the DHCP Relay settings on the Switch.
Syntax	show dhcp_relay {ipif}
Description	The show dhcp_relay command displays the DHCP Relay status and list of servers defined as DHCP Relay servers on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display DHCP Relay settings:

```
DES-1210-28/ME:5# show dhcp_relay
Command: show dhcp_relay
```

```
DHCP/BOOTP Relay Status      : Disabled
DHCP/BOOTP Hops Count Limit  : 4
DHCP/BOOTP Relay Time Threshold : 0
DHCP Relay Agent Information Option 82 State : Disabled
DHCP Relay Agent Information Option 82 Check : Disabled
DHCP Relay Agent Information Option 82 Policy : Replace
DHCP Relay Agent Information Option 82 ID    : 00-B2-FD-DA-EE-EB
```

```
Interface  Server 1      Server 2      Server 3      Server 4
-----  -
```

```
DES-1210-28/ME:5#
```

enable dhcp_local_relay

Purpose	To enable the DHCP local relay feature globally
Syntax	enable dhcp_local_relay
Description	The enable dhcp_local_relay command enables the DHCP local relay feature on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command

Example usage:

To enable the DHCP Local Relay:

```
DES-1210-28/ME:5# enable dhcp_local_relay
Command: enable dhcp_local_relay
```

```
Success
DES-1210-28/ME:5#
```

disable dhcp_local_relay

Purpose	To disable the DHCP local relay feature globally
Syntax	disable dhcp_local_relay
Description	The disable dhcp_local_relay command disables the DHCP local relay feature on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the DHCP Local Relay:

```
DES-1210-28/ME:5# disable dhcp_local_relay
Command: disable dhcp_local_relay
```

```
Success
DES-1210-28/ME:5#
```

config dhcp_local_relay vlan

Purpose	To specify which VLAN's the feature works on.
Syntax	config dhcp_local_relay vlan <vlan_name> vlanid <vidlist> state[enable disable]
Description	Each VLAN which was added to the DHCP Local Relay list participates in the DHCP Local Relay process – Option 82 is added to DHCP requests on this VLAN, and Removed from DHCP Replies on this VLAN.
Parameters	<i>vlan_name</i> – the VLAN name identifier <i>vlanid <vidlist></i> – The VLAN tag identifier <i>state [enable disable]</i> – enable or disable of the DHCP Local Relay status by VLAN name or VLAN ID.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the VLAN ID10 from VLAN of DHCP Local Relay:

```
DES-1210-28/ME:5# config dhcp_local_relay vlan vlanid 10 state disable
Command: config dhcp_local_relay vlan vlanid 10 state disable
```

```

Success
DES-1210-28/ME:5#

```

show dhcp_local_relay

Purpose	To display which VLAN's the feature works on.
Syntax	show dhcp_local_relay
Description	Each VLAN which was added to the DHCP Local Relay list participates in the DHCP Local Relay process – Option 82 is added to DHCP requests on this VLAN, and Removed from DHCP Replies on this VLAN.
Parameters	None.
Restrictions	None.

Example usage:

To display the DHCP local relay information on the Switch:

```

DES-1210-28/ME:5# show dhcp_local_relay
Command: show dhcp_local_relay

DHCP/BOOTP Local Relay Status : Disabled
DHCP/BOOTP Local Relay VID List :

DES-1210-28/ME:5#

```

GRATUITOUS ARP COMMANDS

The Gratuitous ARP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config gratuitous_arp send ipif_status_up	[enable disable]
config gratuitous_arp send dup_ip_detected	[enable disable]
config gratuitous_arp learning	[enable disable]
enable gratuitous_arp	[log trap]
disable gratuitous_arp	[log trap]
show gratuitous_arp	
config gratuitous_arp send periodically interval	<integer 0-65535>

Each command is listed in detail, as follows:

config gratuitous_arp send ipif_status_up	
Purpose	Used to enable or disable the sending of gratuitous ARP requests while the IP interface status is up.
Syntax	config gratuitous_arp send ipif_status_up [enable disable]
Description	The config gratuitous_arp send ipif_status_up command is used to enable or disable the sending of gratuitous ARP request packets while the IPIF interface is up. This is used to automatically announce the interface's IP address to other nodes. By default, the state is enabled, and only one gratuitous ARP packet will be broadcast.
Parameters	<i>enable</i> – Enable the sending of gratuitous ARP when the IPIF status is up. <i>disable</i> – Disable the sending of gratuitous ARP when the IPIF status is up.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable a gratuitous ARP request:

```
DES-1210-28/ME:5# config gratuitous_arp send ipif_status_up enable
Command: config gratuitous_arp send ipif_status_up enable
```

```
Success!
DES-1210-28/ME:5#
```

config gratuitous_arp send dup_ip_detected

Purpose	Used to enable or disable the sending of gratuitous ARP requests while duplicate IP addresses are detected.
Syntax	config gratuitous_arp send send dup_ip_detected [enable disable]
Description	The config gratuitous_arp send send dup_ip_detected command is used to enable or disable the sending of gratuitous ARP request packets while duplicate IPs are detected. By default, the state is enabled.
Parameters	<i>enable</i> – Enable the sending of gratuitous ARP when a duplicate IP is detected. <i>disable</i> – Disable the sending of gratuitous ARP when a duplicate IP is detected.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable gratuitous ARP request when a duplicate IP is detected:

```
DES-1210-28/ME:5# config gratuitous_arp send dup_ip_detected
enable
Command: config gratuitous_arp send dup_ip_detected enable

Success!
DES-1210-28/ME:5#
```

config gratuitous_arp learning

Purpose	Used to enable or disable the learning of ARP entries in ARP cache based on the received gratuitous ARP packets.
Syntax	config gratuitous_arp send learning [enable disable]
Description	Normally, the system will only learn the ARP reply packet or a normal ARP request packet that asks for the MAC address that corresponds to the system's IP address. The config gratuitous_arp send learning command is used to enable or disable the learning of ARP entries in ARP cache based on the received gratuitous ARP packet. The gratuitous ARP packet is sent by a source IP address that is identical to the IP that the packet is queries for. Note that, with gratuitous ARP learning, the system will not learn new entries but only do the update on the ARP table based on the received gratuitous ARP packet. By default, the state is enabled.
Parameters	<i>enable</i> – Enable the learning of ARP entries based on received gratuitous ARP packets. <i>disable</i> – Disable the learning of ARP entries based on received gratuitous ARP packets.

Restrictions	Only Administrator or operator-level users can issue this command.
--------------	--

Example usage:

To enable learning of ARP entries based on the received gratuitous ARP packets:

```
DES-1210-28/ME:5# config gratuitous_arp learning enable
Command: config gratuitous_arp learning enable
```

```
Success!
DES-1210-28/ME:5#
```

enable gratuitous_arp

Purpose	Used to enable the gratuitous ARP trap and log.
Syntax	enable gratuitous_arp [log trap]
Description	The enable gratuitous_arp command is used to enable gratuitous ARP trap and log states. The Switch can trap or log the IP conflict event to inform the administrator. By default, the trap is disabled and event log is enabled.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the System's interface gratuitous ARP trap:

```
DES-1210-28/ME:5# enable gratuitous_arp trap
Command: enable gratuitous_arp trap
```

```
Success!
DES-1210-28/ME:5#
```

disable gratuitous_arp

Purpose	Used to disable the gratuitous ARP trap and log.
Syntax	disable gratuitous_arp [log trap]
Description	The disable gratuitous_arp command is used to disable gratuitous ARP trap and log states. The Switch can trap and log the IP conflict event to inform the administrator. By default, the trap is disabled and event log is enabled.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the System's interface gratuitous ARP trap:

```
DES-1210-28/ME:5# disable gratuitous_arp trap
```

Command: disable gratuitous_arp trap

Success!

DES-1210-28/ME:5#

show gratuitous_arp

Purpose	Used to display the gratuitous ARP configuration.
Syntax	show gratuitous_arp
Description	The show gratuitous_arp command is used to display the gratuitous ARP configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display gratuitous ARP log and trap states:

```
DES-1210-28/ME:5# show gratuitous_arp
Command: show gratuitous_arp

Send on IPIF status up      : Enabled
Send on Duplicate_IP_Detected : Enabled
Gratuitous ARP Learning     : Enabled

IP Interface Name           : System
Gratuitous ARP Trap         : Enabled
Gratuitous ARP Log          : Disabled
Gratuitous ARP Periodical Send Interval : 0

DES-1210-28/ME:5#
```

config gratuitous_arp send periodically interval

Purpose	Used to configure the interval for periodical sending of gratuitous ARP request packets.
Syntax	config gratuitous_arp send periodically interval <integer 0-65535>
Description	The config gratuitous_arp send periodically interval command is used to configure the interval for periodical sending of gratuitous ARP request packets. By default, the interval is 0.
Parameters	<integer 0-65535> – Periodically send gratuitous ARP interval time in seconds. 0 means it will not send gratuitous ARP periodically.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure gratuitous ARP intervals for the Switch:


```
DES-1210-28/ME:5# config gratuitous_arp send periodically interval 100
```

```
Command: config gratuitous_arp send periodically interval 100
```

```
Success!
```

```
DES-1210-28/ME:5#
```

NETWORK MONITORING COMMANDS

The Network Monitoring commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
show packet ports	<portlist>
show error ports	<portlist>
show utilization	[ports {<portlist>} cpu mem]
clear counters	
clear log	
show log	{index <value 1-500> - <value 1-500>}
enable syslog	
disable syslog	
show syslog	
create syslog host	<index 1-4> ipaddress <ipaddr> {severity [informational warning all] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number>}
config syslog host	[all <index 1-4>] {severity [informational warning all] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number> ipaddress <ipaddr>}
delete syslog host	[<index 1-4> all]
show syslog host	{<index 1-4>}
cable diagnostic port	[<portlist> all]

Each command is listed in detail, as follows:

show packet ports	
Purpose	To display statistics about the packets sent and received in frames per second by the Switch.
Syntax	show packet ports <portlist>
Description	The show packet ports command displays statistics about packets sent and received by ports specified in the port list. The results are separated into three tables, labeled A, B, and C in the window below. Table A is relevant to the size of the packets, Table B is relevant to the type of packets and Table C is relevant to the type of frame associated with these packets.
Parameters	<portlist> – A port or range of ports whose statistics are to be displayed.

Restrictions	None.
--------------	-------

Example usage:

To display the packets analysis for port 1:

```
DES-1210-28/ME:5# show packet ports 1
Command: show packet ports 1

Port Number : 1
Frame Size  Frame Counts  Frames/sec  Frame Type  Total  Total/sec
-----
64          0          0          RX Bytes   0      0
65-127     0          0          RX Frames  0      0
128-255    0          0
256-511    0          0          TX Bytes   0      0
512-1023   0          0          TX Frames  0      0
1024-1518  0          0

Unicast RX  0          0
Multicast RX 0          0
Broadcast RX 0          0

CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh
```

show error ports

Purpose	To display the error statistics for a port or a range of ports.
Syntax	show error ports <portlist>
Description	The show error ports command displays all of the packet error statistics collected and logged by the Switch for a given port list.
Parameters	<i><portlist></i> – A port or range of ports whose error statistics are to be displayed.
Restrictions	None.

Example usage:

To display the errors of port 2:

```
DES-1210-28/ME:5# show errors port 1
Command: show error ports 1

Port Number : 1
RX Frames
-----
CRC Error    0
Undersize    0
Oversize     0
Fragment     8
TX Frames
-----
Excessive Deferral  0
CRC Error           0
Late Collision      0
Excessive Collision  0
```

Jabber	0	Single Collision	0
Drop Pkts	0	Collision	0
DES-1210-28/ME:5#			

show utilization

Purpose	To display real-time port utilization statistics.
Syntax	show utilization [ports {<portlist>} cpu mem]
Description	The show utilization command displays the real-time utilization statistics for ports in bits per second (bps) for the Switch, and for the CPU in percentage..
Parameters	<p><i>ports</i> – Entering this parameter will display the current port utilization of the Switch.</p> <p><i><portlist></i> – Specifies a range of ports to be displayed.</p> <p><i>cpu</i> – Entering this parameter will display the current CPU utilization of the Switch.</p> <p><i>mem</i> – Entering this parameter will display the current memory utilization of the Switch.</p>
Restrictions	None.

To display the port 2 utilization statistics:

```
DES-1210-28/ME:5# show utilization ports 2
Command: show utilization ports 2
 2  0  0  0

Port TX/sec RX/sec Util
-----
 2  0  0  0

CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh
DES-1210-28/ME:5#
```

To display the cpu utilization statistics:

```
DES-1210-28/ME:5# show utilization cpu
Command: show utilization cpu
Five Seconds - 6 % One Minute - 6 % Five Minutes - 6 %
Five Seconds - 7 % One Minute - 6 % Five Minutes - 6 %
Five Seconds - 7 % One Minute - 6 % Five Minutes - 6 %

CPU Utilization :
-----
Five Seconds - 7 % One Minute - 6 % Five Minutes - 6 %
```

CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh

DES-1210-28/ME:5#

clear counters

Purpose	To clear the Switch's statistics counters.
Syntax	clear counters
Description	The clear counters command clears the counters used by the Switch to compile statistics.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To clear the counters:

```
DES-1210-28/ME:5# clear counters
```

```
Success.
```

```
DES-1210-28/ME:5#
```

clear log

Purpose	To clear the Switch's history log.
Syntax	clear log
Description	The clear log command clears the Switch's history log.
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To clear the log information:

```
DES-1210-28/ME:5# clear log
```

```
Command: clear log
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show log

Purpose	To display the Switch history log.
Syntax	show log {index <value 1-500> - <value 1-500>}
Description	The show log command displays the contents of the Switch's history log.
Parameters	<i>index <value 1-500></i> – The number of entries in the history log to display.

Restrictions	None.
--------------	-------

Example usage:

To display the Switch history log:

```
DES-1210-28/ME:5# show log
Command: show log
Index      Time                Log Text
-----
1          03-Jan-2000 17:48:21 %AAA-I-CONNECT: User CLI session for user admin over
telnet , source 10.6.150.34 destination 10.6.41.37 ACCEPTED

2          03-Jan-2000 17:48:02 %AAA-I-DISCONNECT: User CLI session for user admin o
ver telnet , source 10.6.150.34 destination 10.6.41.37 TERMINATED. The Telnet/
SSH session may still be connected.

DES-1210-28/ME:5#
```

enable syslog

Purpose	To enable the system log to be sent to a remote host.
Syntax	enable syslog
Description	The enable syslog command enables the system log to be sent to a remote host.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the syslog function on the Switch:

```
DES-1210-28/ME:5# enable syslog
Command: enable syslog

Success!

DES-1210-28/ME:5#
```

disable syslog

Purpose	To disable the system log from being sent to a remote host.
Syntax	disable syslog
Description	The disable syslog command disables the system log from being sent to a remote host.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the syslog function on the Switch:

```
DES-1210-28/ME:5# disable syslog
```

Command: disable syslog

Success!

DES-1210-28/ME:5#

show syslog

Purpose	To display the syslog protocol status.
Syntax	show syslog
Description	The show syslog command displays the syslog status (enabled or disabled).
Parameters	None.
Restrictions	None.

Example usage:

To display the current status of the syslog function:

DES-1210-28/ME:5# show syslog

Command: show syslog

Syslog Global State: Enabled

DES-1210-28/ME:5#

create syslog host

Purpose	To create a new syslog host.										
Syntax	create syslog host <index 1-4> ipaddress <ipaddr> {severity [informational warning all] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port <udp_port_number>}										
Description	The create syslog host command creates a new syslog host.										
Parameters	<p><i>all</i> – Specifies that the command is to be applied to all hosts.</p> <p><i><index 1-4></i> – The syslog host index id. There are four available indices, numbered 1 to 4.</p> <p><i>ipaddress <ipaddr></i> – The IP address of the remote host to which syslog messages are to be sent.</p> <p><i>severity</i> – The message severity level indicator. These are described in the table below (Bold font indicates that the corresponding severity level is currently supported on the Switch):</p> <table border="1"> <thead> <tr> <th>Numerical Code</th> <th>Severity</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Emergency: system is unusable</td> </tr> <tr> <td>1</td> <td>Alert: action must be taken immediately</td> </tr> <tr> <td>2</td> <td>Critical: critical conditions</td> </tr> <tr> <td>3</td> <td>Error: error conditions</td> </tr> </tbody> </table>	Numerical Code	Severity	0	Emergency: system is unusable	1	Alert: action must be taken immediately	2	Critical: critical conditions	3	Error: error conditions
Numerical Code	Severity										
0	Emergency: system is unusable										
1	Alert: action must be taken immediately										
2	Critical: critical conditions										
3	Error: error conditions										

- | | |
|----------|--|
| 4 | Warning: warning conditions |
| 5 | Notice: normal but significant condition |
| 6 | Informational: informational messages |
| 7 | Debug: debug-level messages |

informational – Specifies that informational messages are to be sent to the remote host. This corresponds to number 6 from the list above.

warning – Specifies that warning messages are to be sent to the remote host. This corresponds to number 4 from the list above.

all – Specifies that all of the currently supported syslog messages that are generated by the Switch are to be sent to the remote host.

facility – Some of the operating system daemons and processes have been assigned Facility values. Processes and daemons that have not been explicitly assigned a Facility may use any of the 'local use' facilities or they may use the 'user-level' Facility. Those Facilities that have been designated are shown in the table below (Bold font indicates the facility values that the Switch currently supports):

Numerical Code	Facility
0	kernel messages
1	user-level messages
2	mail system
3	system daemons
4	security/authorization messages
5	messages generated internally by syslog
6	line printer subsystem
7	network news subsystem
8	UUCP subsystem
9	clock daemon
10	security/authorization messages
11	FTP daemon
12	NTP subsystem
13	log audit
14	log alert
15	clock daemon
16	local use 0 (local0)
17	local use 1 (local1)
18	local use 2 (local2)
19	local use 3 (local3)
20	local use 4 (local4)
21	local use 5 (local5)
22	local use 6 (local6)
23	local use 7 (local7)

local0 – Specifies that local use 0 messages are to be sent to the remote host. This corresponds to number 16 from the list above.

<p><i>local1</i> – Specifies that local use 1 messages are to be sent to the remote host. This corresponds to number 17 from the list above.</p> <p><i>local2</i> – Specifies that local use 2 messages are to be sent to the remote host. This corresponds to number 18 from the list above.</p> <p><i>local3</i> – Specifies that local use 3 messages are to be sent to the remote host. This corresponds to number 19 from the list above.</p> <p><i>local4</i> – Specifies that local use 4 messages are to be sent to the remote host. This corresponds to number 20 from the list above.</p> <p><i>local5</i> – Specifies that local use 5 messages are to be sent to the remote host. This corresponds to number 21 from the list above.</p> <p><i>local6</i> – Specifies that local use 6 messages are to be sent to the remote host. This corresponds to number 22 from the list above.</p> <p><i>local7</i> – Specifies that local use 7 messages is sent to the remote host. This corresponds to number 23 from the list above.</p> <p><i>udp_port</i> <<i>udp_port_number</i>> – Specifies the UDP port number that the syslog protocol is to use to send messages to the remote host.</p> <p><i>state</i> [<i>enable</i> <i>disable</i>] – Allows the sending of syslog messages to the remote host, specified above, to be enabled and disabled.</p> <p>Restrictions Only Administrator or operator-level users can issue this command.</p>

Example usage:

To create syslog host:

```
DES-1210-28/ME:5# create syslog host 1 ipaddress 1.1.2.1 severity all state
enable
Command: create syslog host 1 ipaddress 1.1.2.1 severity all state enable

Success!

DES-1210-28/ME:5#
```

config syslog host

Purpose	To configure the syslog protocol to send system log data to a remote host.				
Syntax	config syslog host [all < index 1-4 >] { severity [informational warning all] facility [local0 local1 local2 local3 local4 local5 local6 local7] udp_port < udp_port_number 1-65535 > ipaddress < ipaddr >}				
Description	The config syslog host command configures the syslog protocol to send system log information to a remote host.				
Parameters	<p><i>all</i> – Specifies that the command applies to all hosts.</p> <p><<i>index 1-4</i>> – Specifies that the command applies to an index of hosts. There are four available indices, numbered 1 to 4.</p> <p><i>ipaddress</i> <<i>ipaddr</i>> – The IP address of the remote host to which syslog messages are to be sent.</p> <p><i>severity</i> – The message severity level indicator. These are described in the following table (Bold font indicates that the corresponding severity level is currently supported on the Switch):</p> <table style="margin-left: 40px; border: none;"> <thead> <tr> <th style="text-align: left;">Numerical Code</th> <th style="text-align: left;">Severity</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	Numerical Code	Severity		
Numerical Code	Severity				

0	Emergency: system is unusable
1	Alert: action must be taken immediately
2	Critical: critical conditions
3	Error: error conditions
4	Warning: warning conditions
5	Notice: normal but significant condition
6	Informational: informational messages
7	Debug: debug-level messages

informational – Specifies that informational messages are to be sent to the remote host. This corresponds to number 6 from the list above.

warning – Specifies that warning messages are to be sent to the remote host. This corresponds to number 4 from the list above.

all – Specifies that all of the currently supported syslog messages that are generated by the Switch are to be sent to the remote host.

facility – Some of the operating system daemons and processes have been assigned Facility values. Processes and daemons that have not been explicitly assigned a Facility may use any of the 'local use' facilities or they may use the 'user-level' Facility. Those Facilities that have been designated are shown in the following:

Bold font indicates the facility values that the Switch currently supports.

Numerical Code	Facility
0	kernel messages
1	user-level messages
2	mail system
3	system daemons
4	security/authorization messages
5	messages generated internally by syslog
6	line printer subsystem
7	network news subsystem
8	UUCP subsystem
9	clock daemon
10	security/authorization messages
11	FTP daemon
12	NTP subsystem
13	log audit
14	log alert
15	clock daemon
16	local use 0 (local0)
17	local use 1 (local1)
18	local use 2 (local2)
19	local use 3 (local3)
20	local use 4 (local4)

21	local use 5 (local5)
22	local use 6 (local6)
23	local use 7 (local7)

local0 – Specifies that local use 0 messages are to be sent to the remote host. This corresponds to number 16 from the list above.

local1 – Specifies that local use 1 messages are to be sent to the remote host. This corresponds to number 17 from the list above.

local2 – Specifies that local use 2 messages are to be sent to the remote host. This corresponds to number 18 from the list above.

local3 – Specifies that local use 3 messages are to be sent to the remote host. This corresponds to number 19 from the list above.

local4 – Specifies that local use 4 messages are to be sent to the remote host. This corresponds to number 20 from the list above.

local5 – Specifies that local use 5 messages are to be sent to the remote host. This corresponds to number 21 from the list above.

local6 – Specifies that local use 6 messages are to be sent to the remote host. This corresponds to number 22 from the list above.

local7 – Specifies that local use 7 messages are to be sent to the remote host. This corresponds to number 23 from the list above.

udp_port <udp_port_number 1-65535> – Specifies the UDP port number that the syslog protocol is to use to send messages to the remote host.

ipaddress <ipaddr> – Specifies the IP address of the remote host to which syslog messages are to be sent.

state [*enable* | *disable*] – Allows the sending of syslog messages to the remote host, specified above, to be enabled and disabled.

Restrictions Only Administrator or operator-level users can issue this command.

Example usage:

To configure a syslog host:

```
DES-1210-28/ME:5# config syslog host 1 severity all facility local0
Command: config syslog host 1 severity all facility local0
```

Success.

```
DES-1210-28/ME:5#
```

delete syslog host

Purpose	To remove a previously configured syslog host from the Switch.
Syntax	delete syslog host [<index 1-4> all]
Description	The delete syslog host command removes a previously configured syslog host from the Switch.
Parameters	<index 1-4> – The syslog host index id. There are four available indices, numbered 1 to 4. all – Specifies that the command applies to all hosts.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a previously configured syslog host:

```
DES-1210-28/ME:5# delete syslog host all
Command: delete syslog host all
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show syslog host

Purpose	To display the syslog hosts currently configured on the Switch.
Syntax	show syslog host {<index 1-4>}
Description	The show syslog host command displays the syslog hosts that are currently configured on the Switch.
Parameters	<index 1-4> – The syslog host index id. There are four available indices, numbered 1 to 4.
Restrictions	None.

Example usage:

To show Syslog host information:

```
DES-1210-28/ME:5# show syslog host
Command: show syslog host
```

Host ID	Host IP Address	Severity	Facility	UDP Port	Status
1	1.1.2.1	All	Local0	514	Enabled

```
Total Entries : 1
```

```
DES-1210-28/ME:5#
```

cable diagnostic port

Purpose	To determine if there are any errors on the copper cables and the position where the errors may have occurred.
Syntax	cable diagnostic port [<portlist> all]
Description	The cable diagnostic port command is used to determine if there are any errors on the copper cables and the position where the errors may have occurred. Cable length is detected as following range: <50m, 50~80, 80~100, >100m. Deviation is +/-5 meters, therefore "No Cable" may be displayed under "Test Result," when the cable used is less than 5 m in length. The Fault Distance will show "No Cable", whether the fiber is connected to the port or not.
Parameters	<portlist> – A port or range of ports to be configured. all – Specifies all ports on the Switch are to be configured.
Restrictions	None.

Example usage:

To determine the copper cables and position of port 3 on the Switch:

DES-1210-28/ME:5# cable diagnostic port 3

Command: cable diagnostic port 3

Perform Cable Diagnostics ...

Port	Type	Link Status	Test Result	Fault Distance (meters)	Length(M)
----	----	-----	-----	-----	-----
3	FE	Link Down	Pair1:N/A Pair2:OPEN Pair3:N/A Pair4:N/A	Pair1:No Cable Pair2:1 Pair3:N/A Pair4:N/A	N/A

DES-1210-28/ME:5#

SPANNING TREE COMMANDS

The Spanning Tree commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config stp	{maxage <value 6-40> hellotime <value 1-10> forwarddelay <value 4-30> txholdcount <value 1-10>}
config stp ports	<portlist> {externalcost [auto <value 1-200000000>] edge [auto true false] p2p [true false auto] state [enable disable] fbpdu [enable disable] migrate [yes no] priority <value 0-240> restricted_role [true false] restricted_tcn [true false] }
config stp version	[mstp rstp stp]
config stp fbpdu	[enable disable]
config stp priority	<value 0-61440> instance_id <value 0-15>
enable stp	
disable stp	
show stp	
show stp ports	{<portlist>}
show stp instance	<value 0-15>}
show stp mst_config_id	
create stp instance_id	<value 1-15> [add_vlan <vidlist> remove_vlan <vidlist>]
delete stp instance_id	<value 1-15>
config stp mst_config_id	[revision_level <int 0-65535> name <string 32>]
config stp mst_ports	<portlist> instance_id <value 0-15> {internalCost [auto value 1-200000000] priority <value 0-240>}

Each command is listed in detail, as follows:

config stp	
Purpose	To setup STP, RSTP and MSTP on the Switch.
Syntax	config stp {maxage <value 6-40> hellotime <value 1-10> forwarddelay <value 4-30> txholdcount <value 1-10>}
Description	The config stp command configures the Spanning Tree Protocol (STP) for the entire switch. All commands here are implemented for the STP version that is currently set on the Switch.
Parameters	<i>maxage</i> <value 6-40> - This value may be set to ensure that old information does not endlessly circulate through redundant paths in

the network, preventing the effective propagation of the new information. Set by the Root Bridge, this value aids in determining that the Switch has spanning tree configuration values consistent with other devices on the bridged LAN. If the value ages out and a BPDU has still not been received from the Root Bridge, the Switch starts sending its own BPDU to all other switches for permission to become the Root Bridge. If your switch has the lowest priority, it becomes the Root Bridge. The user may choose a time between 6 and 40 seconds. The default value is 20.

maxhops <value 1-20> – The number of hops between devices in a spanning tree region before the BPDU (bridge protocol data unit) packet sent by the Switch will be discarded. Each switch on the hop count will reduce the hop count by one until the value reaches zero. The Switch will then discard the BPDU packet and the information held for the port will age out. The value may be between 1 and 20. The default is 20.

hellotime <value 1-10> – The user may set the time interval between transmission of configuration messages by the root device in STP, or by the designated router, thus stating that the Switch is still functioning. The value may be between 1 and 10 seconds. The default value is 2 seconds.

forwarddelay <value 4-30> – The amount of time (in seconds) that the root device will wait before changing from Blocking to Listening, and from Listening to Learning states. The value may be between 4 and 30 seconds. The default is 15 seconds.

fbpdu [enable | disable] – Allows the forwarding of STP BPDU packets from other network devices when STP is disabled on the Switch. The default is disable.

Restrictions

Only administrator or operator-level users can issue this command.

Example usage:

To configure STP with maxage 18 and hellotime 2:

```
DES-1210-28/ME:5# config stp maxage 18 hellotime 2
```

```
Command: config stp maxage 18 hellotime 2
```

```
Success.
```

```
DES-1210-28/ME:5#
```

config stp ports

Purpose	To setup STP on the port level.
Syntax	config stp ports <portlist> {externalcost [auto <value 1-200000000>] edge [auto true false] p2p [true false auto] state [enable disable] fbpdu [enable disable] migrate [yes no] priority <value 0-240> restricted_role [true false] restricted_tcn [true false] }
Description	The config stp ports command configures STP for a group of ports.
Parameters	<p><portlist> – A port or range of ports to be configured. The port list is specified by listing switch number and the beginning port number on that switch, separated by a colon. Then the highest port number of the range is specified. The beginning and end of the port list range are separated by a dash.</p> <p><i>externalCost</i> – Defines a metric that indicates the relative cost of forwarding packets to the specified port list. Port cost can be set</p>

automatically or as a metric value. The default value is *auto*.

- *auto* – Automatically sets the speed for forwarding packets to the specified port(s) in the list for optimal efficiency. Default port cost: 10Mbps port = 2000000. 100Mbps port = 200000. Gigabit port = 20000. Port-channel = 20000.
- *<value 1-200000000>* - Defines a value between 1 and 200000000 to determine the external cost. The lower the number, the greater the probability the port will be chosen to forward packets.

edge [auto | true | false] – *true* designates the port as an edge port. Edge ports cannot create loops, however an edge port can lose edge port status if a topology change creates a potential for a loop. An edge port normally should not receive BPDU packets. If a BPDU packet is received it automatically loses edge port status. *false* indicates that the port does not have edge port status. The default setting for this parameter is *false*.

p2p [true | false | auto] – *true* indicates a point-to-point (P2P) link. P2P ports transition to a forwarding state rapidly thus benefiting from RSTP. A *p2p* value of *false* indicates that the port cannot have *p2p* status. *auto* allows the port to have *p2p* status whenever possible and operate as if the *p2p* status were *true*. (A port that operates in full-duplex is assumed to be point-to-point, while a half-duplex port is considered as a shared port). If the port cannot maintain this status (for example if the port is forced to half-duplex operation) the *p2p* status changes to operate as if the *p2p* value were *false*. The default setting for this parameter is *auto*.

state [enable | disable] – Allows STP to be enabled or disabled for the ports specified in the port list. The default is *enable*.

fbpdu [enable | disable | system] – If enabled - allows the forwarding of STP BPDU packets from other network devices. *Disable* – blocking STP BPDU packets from other network devices. *System* – indicates that port will behave as global switch's *fbpdu* value configured. *fbpdu* value valid only when STP port state is disabled or global STP state is disabled. The default is *system*.

migrate [yes | no] – Setting this parameter as “yes” will set the ports to send out BPDU packets to other bridges, requesting information on their STP setting if the Switch is configured for RSTP, the port will be capable to migrate from 802.1D STP to 802.1w RSTP. If the Switch is configured for MSTP, the port is capable of migrating from 802.1D STP to 802.1s MSTP. RSTP and MSTP can coexist with standard STP, however the benefits of RSTP and MSTP are not realized on a port where and 802.1D network connects to and 802.1w or 802.1s enabled network. Migration should be set as *yes* on ports connected to network stations or segments that are capable of being upgraded to 802.1w RSTP or 802.1s MSTP on all or some portion of the segment.

priority <value 0-240> – Specifies the priority. The range is from 0 to 240.

restricted_role [true | false] – To decide if this is to be selected as the Root Port. The default value is *false*.

restricted_tcn [true | false] – To decide if this port is to propagate topology change. The default value is *false*.

Restrictions

Only administrator or operator-level users can issue this command.

Example usage:

To configure STP with path cost 19 and state enable for ports 1-3:


```
DES-1210-28/ME:5# config stp ports 1-3 externalcost 19 state enable
Command: config stp ports 1-3 externalcost 19 state enable
```

```
Success.
DES-1210-28/ME:5#
```

config stp version

Purpose	To globally set the version of STP on the Switch.
Syntax	config stp version [mstp rstp stp]
Description	The config stp version command sets the version of the spanning tree to be implemented on the Switch.
Parameters	<p><i>mstp</i> – Sets the Multiple Spanning Tree Protocol (MSTP) globally on the Switch.</p> <p><i>rstp</i> – Sets the Rapid Spanning Tree Protocol (RSTP) globally on the Switch.</p> <p><i>stp</i> – Sets the Spanning Tree Protocol (STP) globally on the Switch.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To set the Switch globally for the Multiple Spanning Tree Protocol (MSTP):

```
DES-1210-28/ME:5# config stp version mstp
Command: config stp version mstp
```

```
Success.
DES-1210-28/ME:5#
```

config stp fbpdu

Purpose	To globally set the fbpdu of STP on the Switch.
Syntax	config stp fbpdu [enable disable]
Description	The config stp fbpdu command allows the forwarding of STP BPDU packets from other network devices when STP is disabled on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To set the Switch globally for the Spanning Tree Protocol (STP) fbpdu enable:

```
DES-1210-28/ME:5# config stp fbpdu enable
Command: config stp fbpdu enable
```

```
Success.
DES-1210-28/ME:5#
```

config stp priority

Purpose	To update the STP instance configuration.
Syntax	config stp priority <value 0-61440> instance_id <value 0-15>
Description	The config stp priority command updates the STP instance configuration settings on the Switch. The MSTP uses the priority in selecting the root bridge, root port and designated port. Assigning higher priorities to STP regions instructs the Switch to give precedence to the selected instance_id for forwarding packets. A lower value indicates a higher priority.
Parameters	<i>priority <value 0-61440></i> - The priority for a specified <i>instance_id</i> for forwarding packets. The value may be between 0 and 61440, and must be divisible by 4096. A lower value indicates a higher priority. <i>instance_id <value 0-15></i> - The value of the previously configured instance id for which the user wishes to set the priority value. An instance_id of 0 denotes the default instance_id (CIST) internally set on the Switch.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To set the priority value for instance_id 2 as 4096:

```
DES-1210-28/ME:5# config stp priority 4096 instance_id 2
Command: config stp priority 4096 instance_id 2

Success.

DES-1210-28/ME:5#
```

enable stp

Purpose	To globally enable STP on the Switch.
Syntax	enable stp
Description	The enable stp command sets the Spanning Tree Protocol to be globally enabled on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable STP, globally, on the Switch:

```
DES-1210-28/ME:5# enable stp
Command: enable stp

Success.

DES-1210-28/ME:5#
```

disable stp

Purpose	To globally disable STP on the Switch.
Syntax	disable stp

Description	The disable stp command sets the Spanning Tree Protocol to be globally disabled on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable STP on the Switch:

```
DES-1210-28/ME:5# disable stp
Command: disable stp

Success.
DES-1210-28/ME:5#
```

show stp

Purpose	To display the Switch's current STP configuration.
Syntax	show stp
Description	The show stp command displays the Switch's current STP configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display the status of STP on the Switch:

Status 1: STP enabled with STP compatible version

```
STP Bridge Global Settings
-----
STP Status           : Enabled
STP Version          : STP compatible
Bridge Priority       : 32768
Max Age              : 8
Hello Time           : 2
Forward Delay        : 15
TX Hold Count        : 6
Forward BPDU         : Enabled
Root Cost            : 0
Root Maximum Age     : 8
Root Forward Delay   : 15
Root Port            : 0
Root Bridge          : 80:00:00:B2:FD:DA:EE:EB

DES-1210-28/ME:5#
```

Status 2: STP enabled for RSTP

```
STP Bridge Global Settings
-----
```

```

STP Status : Enabled
STP Version : RSTP
Bridge Priority : 32768
Max Age : 8
Hello Time : 2
Forward Delay : 15
TX Hold Count : 6
Forward BPDU : Enabled
Root Cost : 0
Root Maximum Age : 8
Root Forward Delay : 15
Root Port : 0
Root Bridge : 80:00:00:B2:FD:DA:EE:EB

DES-1210-28/ME:5#

```

Status 3: STP enabled for MSTP

```

STP Bridge Global Settings
-----
STP Status : Enabled
STP Version : MSTP
Bridge Priority : 32768
Max Age : 8
Hello Time : 2
Forward Delay : 15
TX Hold Count : 6
Forward BPDU : Enabled
Root Cost : 0
Root Maximum Age : 8
Root Forward Delay : 15
Root Port : 0
Root Bridge : 80:00:00:B2:FD:DA:EE:EB

DES-1210-28/ME:5#

```

show stp ports

Purpose	To display the Switch's current instance_id configuration.
Syntax	show stp ports {<portlist>}
Description	The show stp ports command displays the STP Instance Settings and STP Instance Operational Status currently implemented on the Switch.
Parameters	<i><portlist></i> – A port or range of ports to be configured. The port list is specified by listing switch number and the beginning port number on that switch, separated by a colon. Then the highest port number of the range is specified. The beginning and end of the port list range are separated by a dash.

Restrictions	None.
--------------	-------

Example usage:

To show stp port 1 on switch one:

```
DES-1210-28/ME:5# show stp ports 1
Command: show stp ports 1

MSTP    Port Information
-----  -----
Port Index:1 , Port STP:Enabled ,   P2P:Auto ,
External PathCost : 19 ,   Edge Port:Auto ,
Port RestrictedRole:False ,   Port RestrictedTCN:False
Port Priority:128 ,   Port Forward BPDU:Enabled ,
MSTI Designated Bridge          Internal PathCost Prio Status   Role
-----  -----  ---  -----  -----
0      80:00:00:B2:FD:DA:EE:EB 200000          128 Disabled Disabled

DES-1210-28/ME:5#
```

show stp instance

Purpose	To display the Switch's STP instance configuration
Syntax	show stp instance {<value 0-15>}
Description	The show stp instance_id command displays the Switch's current STP Instance Settings and the STP Instance Operational Status.
Parameters	<value 0-15> - The value of the previously configured instance_id on the Switch. The value may be between 0 and 15. An entry of 0 displays the STP configuration for the CIST internally set on the Switch.
Restrictions	None.

Example usage:

To display the STP instance configuration for instance 0 (the internal CIST) on the Switch:

```
DES-1210-28/ME:5# show stp instance 0
Command: show stp instance 0

## MST00
Bridge   Address 00:b2:fd:da:ee:eb   Priority 32768
Root     Address 00:b2:fd:da:ee:eb   Priority 32768
        We are the Root for CST
        Port 0      , path cost 0
IST Root Address 00:b2:fd:da:ee:eb   Priority 32768
        Path cost 0
Configured Forward delay 15, Max age 18, Max hops 20
Operational Forward delay 15, Max age 18

Interface Role    Sts    Cost  Prio.Nbr  Type
```

```

-----  ---  ----  -----  ----
DES-1210-28/ME:5#

```

show stp mst_config_id

Purpose	To display the MSTP configuration identification.
Syntax	show stp mst_config_id
Description	The show stp mst_config_id command displays the Switch's current MSTP configuration identification.
Parameters	None.
Restrictions	None.

Example usage:

To show the MSTP configuration identification currently set on the Switch:

```

DES-1210-28/ME:5# show stp mst_config_id
Command: show stp mst_config_id

Name      [00-B2-FD-DA-EE-EB]
Revision  0
Instance  Vlans mapped
-----  -----
0         1-1024,1025-2048,2049-3072,3073-4094
-----  -----

DES-1210-28/ME:5#

```

create stp instance_id

Purpose	To create instance ID on the Swiwtch.
Syntax	create stp instance_id <value 1-15> [add_vlan <vidlist> remove_vlan <vidlist>]
Description	The create stp instance_id command creates an instance ID of STP on the Switch.
Parameters	<value 1-15> - The value of the instance ID to be create. <vidlist> - Specifies to add VLAN or delete VLAN of the specified VID.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To create instance id 2:

```

DES-1210-28/ME:5# create stp instance_id 1 add_vlan 2
Command: create stp instance_id 1 add_vlan 2

Success.

DES-1210-28/ME:5#

```

delete stp instance_id

Purpose	To delete instance ID on the Swiwtch.
Syntax	delete stp instance_id <value 1-15>
Description	The delete stp instance_id command removes the instance ID of STP on the Switch.
Parameters	<value 1-15> - The value of the instance ID to be removed.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To remove instance id 2:

```
DES-1210-28/ME:5# delete stp instance_id 2
Command: delete stp instance_id 2

Success.

DES-1210-28/ME:5#
```

config stp mst_config_id

Purpose	To update the MSTP configuration identification.
Syntax	config stp mst_config_id [revision_level <int 0-65535> name <string 32>]
Description	The config stp mst_config_id command uniquely identifies the MSTP configuration currently configured on the Switch. Information entered here is attached to BPDU packets as an identifier for the MSTP region to which it belongs. Switches having the same revision_level, name and identical vlans mapped for STP instance_ids are considered to be part of the same MSTP region.
Parameters	<i>revision_level</i> <int 0-65535>- The MSTP configuration revision number. The value may be between 0 and 65535. This value, along with the name and identical vlans mapped for STP instance_ids identifies the MSTP region configured on the Switch. The default setting is 0. <i>name</i> <string 32> - A string of up to 32 alphanumeric characters to uniquely identify the MSTP region on the Switch. This name, along with the revision_level value and identical vlans mapped for STP instance_ids identifies the MSTP region configured on the Switch. If no name is entered, the default name is the MAC address of the device.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the MSTP region of the Switch with revision_level 10 and the name 'Trinity':

```
DES-1210-28/ME:5# config stp mst_config_id name Trinity revision_level 10
Command: config stp mst_config_id name Trinity revision_level 10

Success.

DES-1210-28/ME:5#
```

config stp mst_ports

Purpose	To update the port configuration for a MSTP instance.
Syntax	config stp mst_ports <portlist> instance_id <value 0-15> {internalCost [auto value 1-200000000] priority <value 0-240>}
Description	The config stp mst_ports command updates the port configuration for a STP instance_id. If a loop occurs, the MSTP function uses the port cost to select an interface to put into the forwarding state (if the switch isn't Root). If the switch is Root, then higher priority value for interfaces will influence on selected ports to be forwarding first at connected network devices. In instances where the priority value is identical, the MSTP function implements the lowest port number into the forwarding state and other interfaces are blocked. Remember that lower priority values mean higher priorities for forwarding packets.
Parameters	<p><i><portlist></i> – A port or range of ports to be configured. The port list is specified by listing switch number and the beginning port number on that switch, separated by a colon. Then the highest port number of the range is specified. The beginning and end of the port list range are separated by a dash.</p> <p><i>instance_id <value 0-15></i> - The value may be between 0 and 15. An entry of 0 denotes the CIST (Common and Internal Spanning Tree).</p> <p><i>internalCost</i> – The relative cost of forwarding packets to specified ports when an interface is selected within an STP instance. The default setting is auto. There are two options:</p> <ul style="list-style-type: none"> • <i>auto</i> – Specifies setting the quickest route automatically and optimally for an interface. The default value is derived from the media speed of the interface. • <i>value 1-200000000</i> – Specifies setting the quickest route when a loop occurs. The value may be in the range of 1-200000000. A lower internalCost represents a quicker transmission. <p><i>priority <value 0-240></i> - The priority for the port interface The value may be between 0 and 240. A lower number denotes a higher priority. A higher priority designates the interface to forward packets first.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To designate ports 1 through 5 with instance ID 2, to have an auto internalCost and a priority of 16:

```
DES-1210-28/ME:5# config stp mst_ports 1-5 instance_id 2 internalCost auto
priority 16
Command: config stp mst_ports 1-5 instance_id 2 internalCost auto priority 16

Success.

DES-1210-28/ME:5#
```


FORWARDING DATABASE COMMANDS

The Forwarding Database commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create fdb	<vlan_name 32> <macaddr> port <port 1-28>
create multicast_fdb	<int 1-4094><macaddr>
config multicast_fdb	<integer 1-4094> <macaddr> [add delete] <portlist>
config fdb aging_time	<sec 10-600>
delete fdb	<vlan_name 32> <macaddr>
enable flood_fdb	
disable flood_fdb	
show flood_fdb	
clear flood_fdb	
show multicast_fdb	{vlan <vlan_name 32> mac_address <macaddr>}
show fdb	{port <port 1-28> vlan <vlan_name 32> mac_address <macaddr> static aging_time}
config multicast filter	<portlist> [forward filter]
show multicast filter port_mode	
create auto_fdb	<ipaddr>
delete auto_fdb	<ipaddr>

Each command is listed in detail, as follows:

create fdb	
Purpose	To create a static entry in the unicast MAC address forwarding table (database)
Syntax	create fdb <vlan_name 32> <macaddr> port <port 1-28>
Description	The create fdb command creates a static entry in the Switch's unicast MAC address forwarding database.
Parameters	<p><vlan_name 32> – The name of the VLAN on which the MAC address resides.</p> <p><macaddr> – The MAC address to be added to the forwarding table.</p> <p>port <port 1-28> – The port number corresponding to the MAC destination address. The Switch will always forward traffic to the specified device through this port.</p>

Restrictions	Only Administrator or operator-level users can issue this command.
--------------	--

Example usage:

To create a unicast MAC FDB entry:

```
DES-1210-28/ME:5# create fdb default 00-00-00-00-01-02 port 2
Command: create fdb default 00-00-00-00-01-02 port 2

Success
DES-1210-28/ME:5#
```

create multicast_fdb

Purpose	To create a static entry in the multicast MAC address forwarding table (database).
Syntax	create multicast_fdb <int 1-4094><macaddr>
Description	The create multicast_fdb command creates a static entry in the multicast MAC address forwarding table (database).
Parameters	<integer 1-4094> - The item of the VLAN on which the MAC address resides. The range is between 1 and 4094. <macaddr> - The MAC address to be added to the forwarding table.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create multicast MAC forwarding:

```
DES-1210-28/ME:5# create multicast_fdb 1 00-00-00-01-02-03
Command: create multicast_fdb 1 00-00-00-01-02-03

Success.
DES-1210-28/ME:5#
```

config multicast_fdb

Purpose	To configure the Switch's multicast MAC address forwarding database.
Syntax	config multicast_fdb <integer 1-4094> <macaddr> [add delete] <portlist>
Description	The config multicast_fdb command configures the multicast MAC address forwarding table.
Parameters	<integer 1-4094> - The item of the VLAN on which the MAC address resides. The range is between 1 and 4094. <macaddr> - The MAC address to be configured to the forwarding table. <i>add</i> - Specifies that the MAC address is to be added to the forwarding table. Delete will remove the MAC address from the forwarding table. <i>delete</i> - Specifies that the MAC address is to be removed from the forwarding table. <portlist> - A port or range of ports to be configured.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure multicast MAC forwarding:

```
DES-1210-28/ME:5# config multicast_fdb 1 00-00-00-01-02-03
Command: config multicast_fdb 1 00-00-00-01-02-03

Success.

DES-1210-28/ME:5#
```

config fdb aging_time

Purpose	To set the aging time of the forwarding database.
Syntax	config fdb aging_time <sec 10-600>
Description	The config fdb aging_time command sets the aging time of the forwarding database. The aging time affects the learning process of the Switch. Dynamic forwarding table entries, which are made up of the source MAC addresses and their associated port numbers, are deleted from the table if they are not accessed within the aging time. The aging time can be from 0 to 630 minutes with a default value of 5 minutes. A very long aging time can result in dynamic forwarding table entries that are out-of-date or no longer exist. This may cause incorrect packet forwarding decisions by the Switch. If the aging time is too short however, many entries may be aged out too soon. This will result in a high percentage of received packets whose source addresses cannot be found in the forwarding table, in which case the Switch will broadcast the packet to all ports, negating many of the benefits of having a Switch.
Parameters	<sec 10-600> – The aging time for the MAC address forwarding database value, in seconds.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To set the fdb aging time:

```
DES-1210-28/ME:5# config fdb aging_time 300
Command: config fdb aging_time 300

Success.

DES-1210-28/ME:5#
```

delete fdb

Purpose	To delete an entry in the Switch's forwarding database.
Syntax	delete fdb <vlan_name 32> <macaddr>
Description	The delete fdb command deletes an entry in the Switch's MAC address forwarding database.
Parameters	<vlan_name 32> – The name of the VLAN on which the MAC address resides. <macaddr> – The MAC address to be removed from the forwarding table.

Restrictions	Only Administrator or operator-level users can issue this command.
--------------	--

Example usage:

To delete a permanent FDB entry:

DES-1210-28/ME:5# delete fdb default 00-00-00-00-01-02 Command: delete fdb default 00-00-00-00-01-02 Success DES-1210-28/ME:5#

enable flood_fdb

Purpose	To enable the Switch's forwarding database on the Switch.
Syntax	enable flood_fdb
Description	The enable flood_fdb command enables dynamically learned entries from the Switch's forwarding database. ³⁴
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable FDB dynamic entries:

DES-1210-28/ME:5# enable flood_fdb Command: enable flood_fdb Success. DES-1210-28/ME:5#
--

disable flood_fdb

Purpose	To disable the Switch's forwarding database on the Switch.
Syntax	disable flood_fdb
Description	The disable flood_fdb command disables dynamically learned entries from the Switch's forwarding database.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable FDB dynamic entries:

DES-1210-28/ME:5# disable flood_fdb Command: disable flood_fdb Success. DES-1210-28/ME:5#
--

show flood_fdb

Purpose	To display the Switch's forwarding database on the Switch.
Syntax	show flood_fdb
Description	The show flood_fdb command displays dynamically learned entries from the Switch's forwarding database.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To display FDB dynamic entries:

```
DES-1210-28/ME:5# show flood_fdb
Command: show flood_fdb

Flooding FDB State : Enabled

VID   MAC Address   Port
----   -
DES-1210-28/ME:5#
```

clear flood_fdb

Purpose	To clear the Switch's forwarding database of all dynamically learned MAC addresses.
Syntax	clear flood_fdb
Description	The clear flood_fdb command clears dynamically learned entries from the Switch's forwarding database.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To clear all FDB dynamic entries:

```
DES-1210-28/ME:5# clear flood_fdb
Command: clear flood_fdb

Success.
DES-1210-28/ME:5#
```

show multicast_fdb

Purpose	To display the contents of the Switch's multicast forwarding database.
Syntax	show multicast_fdb {vlan <vlan_name 32> mac_address <macaddr>}
Description	The show multicast_fdb command displays the current contents of the Switch's multicast MAC address forwarding database.

Parameters	<i>vlan</i> < <i>vlan_name</i> 32> – The name of the VLAN on which the MAC address resides. <i>mac_address</i> < <i>macaddr</i> > – The MAC address that will be added to the forwarding table.
Restrictions	None.

Example usage:

To display multicast MAC address table:

```
DES-1210-28/ME:5# show multicast_fdb
Command: show multicast_fdb

Static Multicast Table
-----

Total Mac Addresses displayed: 0

DES-1210-28/ME:5#
```

show fdb

Purpose	To display the current unicast MAC address forwarding database.
Syntax	show fdb {port <port 1-28> vlan <vlan_name 32> mac_address <macaddr> static aging_time}
Description	The show fdb command displays the current contents of the Switch's forwarding database.
Parameters	< <i>port 1-28</i> > – The port number corresponding to the MAC destination address. The Switch always forwards traffic to the specified device through this port. < <i>vlan_name 32</i> > – The name of the VLAN on which the MAC address resides. < <i>macaddr</i> > – The MAC address entry in the forwarding table. <i>static</i> – Specifies that static MAC address entries are to be displayed. <i>aging_time</i> – Displays the aging time for the MAC address forwarding database.
Restrictions	None.

Example usage:

To display unicast MAC address table:

```
DES-1210-28/ME:5# show fdb port 3
Command: show fdb port 3

VID VLAN Name          MAC Address          Port Type
----
1  default              00-00-01-01-02-03 3  Permanent

Total Entries : 1
```

```
DES-1210-28/ME:5#
```

To display the aging time:

```
DES-1210-28/ME:5# show fdb aging_time
Command: show fdb aging_time

Unicast MAC Address Aging Time = 300 (seconds)

DES-1210-28/ME:5#
```

config multicast filter

Purpose	To configure multicast filtering.
Syntax	config multicast filter <portlist> [forward filter]
Description	The config multicast filtering_mode command enables filtering of multicast addresses.
Parameters	<i><portlist></i> - A port or range of ports to be configured. <i>forward</i> - Forwards unregistered multicast packets. <i>filter</i> - Filter unregistered multicast packets.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure multicast filtering

```
DES-1210-28/ME:5# config multicast filter 3-5 forward
Command: config multicast filter 3-5 forward

Success!
DES-1210-28/ME:5#
```

show multicast filter port_mode

Purpose	To display multicast filtering settings on the Switch.
Syntax	show multicast filter port_mode
Description	The show multicast filter port_mode command displays the multicast filtering settings.
Parameters	None.
Restrictions	None.

Example usage:

To show multicast filtering settings:

```
DES-1210-28/ME:5# show multicast filter port_mode
Command: show multicast filter port_mode

Port    Multicast Filtering Mode
-----  -----
1       Forward Unregistered Groups
2       Forward Unregistered Groups
```

```

3 Forward Unregistered Groups
4 Forward Unregistered Groups
5 Forward Unregistered Groups
6 Forward Unregistered Groups
7 Forward Unregistered Groups
8 Forward Unregistered Groups
9 Forward Unregistered Groups
10 Forward Unregistered Groups
11 Forward Unregistered Groups
12 Forward Unregistered Groups
13 Forward Unregistered Groups
14 Forward Unregistered Groups
15 Forward Unregistered Groups
16 Forward Unregistered Groups
17 Forward Unregistered Groups
18 Forward Unregistered Groups
CTRL+C ESC q Quit SPACE n Next Page ENTER Next Entry a ALL

```

create auto_fdb

Purpose	To create a static entry in the auto forwarding table (database).
Syntax	create auto_fdb <ipaddr>
Description	The create auto_fdb command creates a static entry in the multicast MAC address forwarding table (database).
Parameters	<ipaddr> – The IP address to be added to the auto forwarding table.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create auto forwarding table:

```

DES-1210-28/ME:5# create auto_fdb 172.21.47.13
Command: create auto_fdb 172.21.47.13

Success.
DES-1210-28/ME:5#

```

delete auto_fdb

Purpose	To delete a static entry in the auto forwarding table (database).
Syntax	delete auto_fdb <ipaddr>
Description	The delete auto_fdb command removes a static entry in the multicast MAC address forwarding table (database).
Parameters	<ipaddr> – The IP address to be deleted from the auto forwarding table.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete auto forwarding table:


```
DES-1210-28/ME:5# delete auto_fdb 172.21.47.13
```

```
Command: delete auto_fdb 172.21.47.13
```

```
Success.
```

```
DES-1210-28/ME:5#
```

BROADCAST STORM CONTROL COMMANDS

The Broadcast Storm Control commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config traffic control	[<portlist> all] {[action [drop shutdown] countdown [0 <minutes 5-30>] broadcast multicast unicast threshold <value 64- 1024000> time_interval <time_interval 5-30>]} [enable disable]
show traffic control	{<portlist>}
config traffic trap	[storm_cleared storm_occured both none]

Each command is listed in detail, as follows:

config traffic control	
Purpose	To configure broadcast / multicast / unknown unicast traffic control.
Syntax	config traffic control [<portlist> all] {[action [drop shutdown] countdown [0 <minutes 5-30>] broadcast multicast unicast threshold <value 64 - 1024000> time_interval <time_interval 5-30>]} [enable disable]
Description	The config traffic control command configures broadcast, multicast and unknown unicast storm control.
Parameters	<p><portlist> - A port or range of ports to be configured.</p> <p><i>all</i> - Specifies all ports on the Switch are to be configured.</p> <p><i>action</i> [drop shutdown] - Specifies the traffic control action to be drop or shutdown. A traffic control trap is active only when the control action is configured as "shutdown". If the control action is "drop", there will no traps issue while storm event is detected.</p> <p><i>countdown</i> [0 <minutes 5-30>] - Specifies the countdown time of traffic control.</p> <p><i>storm_type</i> - The type of broadcast storm for which to configure the traffic control. The options are:</p> <ul style="list-style-type: none"> • <i>broadcast</i> - Enables broadcast storm control only. • <i>multicast</i> - Enables broadcast and multicast storm control. • <i>unicast</i> - Enables broadcast and unicast storm control. <p><i>threshold</i> <value 64-1024000> - The upper threshold at which the specified traffic control is switched on. The value is the number of broadcast/multicast/dlf packets, in Kbps, received by the Switch that will trigger the storm traffic control measures. The value ranges in size from 64 to 1024000 Kbps. The default setting is 64 Kbit/sec.</p> <p><time_interval 5-30> - Specifies the time interval of traffic control.</p> <p>[enable disable] - Enables or disables the specified storm type.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure traffic control and enable broadcast storm control system wide:

```
DES-1210-28/ME:5# config traffic control all multicast enable unicast disable br
oadcast enable threshold 65
Command: config traffic control all multicast enable unicast disable broadcast
enable threshold 65

Success.

DES-1210-28/ME:5#
```

show traffic control

Purpose	To display current traffic control settings.
Syntax	show traffic control {<portlist>}
Description	The show traffic control command displays the current storm traffic control configuration on the Switch.
Parameters	<portlist> - A port or range of ports whose settings are to be displayed.
Restrictions	None.

Example usage:

To display traffic control setting for ports 1-5:

```
DES-1210-28/ME:5# show traffic control 1-5
Command: show traffic control 1-5

Port  Thres  Broadcast  Multicast  Unicast
  hold   Storm    Storm      Storm
-----  -
1      65      Enabled   Enabled    Disabled
2      65      Enabled   Enabled    Disabled
3      65      Enabled   Enabled    Disabled
4      65      Enabled   Enabled    Disabled
5      65      Enabled   Enabled    Disabled

Total Entries : 5

DES-1210-28/ME:5#
```

config traffic trap

Purpose	To configure the traffic control trap on the Switch.
Syntax	config traffic trap [storm_cleared storm_occured both none]
Description	The config traffic trap command configures the current storm traffic trap configuration on the Switch.
Parameters	<i>storm_cleared</i> – A notification will be generated when a storm event

	<p>is cleared.</p> <p><i>storm_occured</i> – A notification will be generated when a storm event is detected.</p> <p><i>both</i> – A notification will be generated both when a storm event is detected and cleared.</p> <p><i>none</i> – No notification will be generated when storm event is detected or cleared.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure traffic trap setting:

```
DES-1210-28/ME:5# config traffic trap storm_cleared
Command: config traffic trap storm_cleared

Success.

DES-1210-28/ME:5#
```

QOS COMMANDS

The QoS commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config scheduling	<class_id 0-3> weight <value 0-55>
show scheduling	
config bandwidth_control	[<portlist> all] {rx_rate [no_limit <value 64-1024000>] tx_rate [no_limit <value 64-1024000>]}
show bandwidth_control	[<portlist> all]
config cos mac_mapping	destination_addr <macaddr> class <class_id 0-3>
show cos mac_mapping	{destination_addr <macaddr>}
delete cos mac_mapping	destination_addr <macaddr>
config cos ip_mapping	destination_ip <ipaddr> class <class_id 0-3>
show cos ip_mapping	{destination_ip <ipaddr>}
delete cos ip_mapping	destination_ip <ipaddr>
config cos mapping	port [<portlist> all] [802.1p dscp_tos none]
show cos mapping	{port <portlist>}
config cos protocol_mapping	protocol <ip_protocol 1-255> class <class_id 0-3>
show cos protocol_mapping	{protocol <ip_protocol 1-255>}
delete cos protocol_mapping	protocol <ip_protocol 1-255>
config cos vlanid_mapping	vid <vlanid 1-4094> class <class_id 0-3>
show cos vlanid_mapping	{vid <vlanid 1-4094>}
delete cos vlanid_mapping	vid <vlanid 1-4094>
config cos tos	value <value 0-7> class <class_id 0-3>
show cos tos	{value <value 0-7>}
config cos tcp_port_mapping	destination_port <value 0-65535> class <class_id 0-3>
show cos	{destination_port <value 0-65535>}

Command	Parameter
tcp_port_mapping	
delete cos tcp_port_mapping	destination_port <value 0-65535>
config cos udp_port_mapping	destination_port <value 0-65535> class <class_id 0-3>
show cos udp_port_mapping	{destination_port <value 0-65535>}
delete cos udp_port_mapping	destination_port <value 0-65535>
config 802.1p user_priority	<priority 0-7> <class_id 0-3>
show 802.1p user_priority	
config 802.1p default_priority	[<portlist> all] <priority 0-7>
show 802.1p default_priority	{<portlist>}
config scheduling_mechanism	[strict wrr]
show scheduling_mechanism	
config dscp mode	
config dscp_mapping	dscp_value <value 0-63> class <class_id 0-3>
show dscp_mapping	{dscp_value <value 0-63>}

Each command is listed in detail, as follows:

config scheduling	
Purpose	To configure traffic scheduling for each of the Switch's QoS queues.
Syntax	config scheduling <class_id 0-3> weight <value 0-55>
Description	<p>The config scheduling command configures traffic scheduling for each of the Switch's QoS queues.</p> <p>The Switch contains four hardware classes of service. Incoming packets must be mapped to one of these four hardware queues. This command is used to specify the rotation by which these four hardware queues are emptied.</p> <p>The Switch's default (if the config scheduling command is not used) is to empty the hardware queues in order – from the highest priority queue (hardware class 3) to the lowest priority queue (hardware class 0). Each hardware queue transmits all of the packets in its buffer before allowing the next lower priority queue to transmit its packets. When the lowest hardware priority queue has finished transmitting all of its packets, the highest hardware priority queue can again transmit any packets it may have received.</p>

	<p>The <code>max_packets</code> parameter allows the user to specify the maximum number of packets a given hardware priority queue can transmit before allowing the next lowest hardware priority queue to begin transmitting its packets. A value between 0 and 15 can be specified. For example, if a value of 3 is specified for all the queues, then the highest hardware priority queue (number 3) will be allowed to transmit 3 packets – then the next lowest hardware priority queue (number 2) will be allowed to transmit 3 packets, and so on, until all of the queues have transmitted 3 packets. The process will then repeat.</p>
Parameters	<p><code><class_id 0-3></code> – The hardware classes of service to which the config scheduling command is to be applied. The four hardware classes of service are identified by number (from 0 to 3) with class 3 having the highest priority.</p> <p><code>weight <value 0-55></code> – Specifies the weight of packets the above specified priority class of service is allowed to transmit before allowing the next lower priority class of service to transmit its packets. The value may be between 0 and 55. The default value is 1 for <code>class_id 0</code>, 2 for <code>class_id 1</code>, 4 for <code>class_id 2</code>, and 8 for <code>class_id 3</code>.</p>
Restrictions	<p>Only administrator or operator level users can issue this command. This command is usable only if the device was configured to work in round robin scheduling (config scheduling_mechanism)</p>

Example usage:

To configure traffic scheduling:

```
DES-1210-28/ME:5# config scheduling 1 weight 10
```

```
Command: config scheduling 1 weight 10
```

```
Success
```

```
DES-1210-28/ME:5#
```

show scheduling

Purpose	To display the currently configured traffic scheduling on the Switch.
Syntax	show scheduling
Description	The show scheduling command displays the current configuration for the maximum number of packets (<i>max_packet</i>) value assigned to the four priority classes of service on the Switch. The Switch empties the four hardware queues in order, from the highest priority (class 3) to the lowest priority (class 0).
Parameters	None.
Restrictions	None.

Example usage:

To display the current scheduling configuration:

```
DES-1210-28/ME:5# show scheduling
```

```
Command: show scheduling
```

```
QOS Output Scheduling
```

```
Class ID  Weight
```

```

-----
Class-0  strict
Class-1  strict
Class-2  strict
Class-3  strict

DES-1210-28/ME:5#

```

config bandwidth_control

Purpose	To configure bandwidth control on the Switch.
Syntax	config bandwidth control [<portlist> all] {rx_rate [no_limit <value 64-1024000>] tx_rate [no_limit <value 64-1024000>]}
Description	The config bandwidth_control command defines bandwidth control.
Parameters	<p><i>portlist</i> - A port or range of ports to be configured.</p> <p><i>all</i> - Specifies that the config bandwidth_control command applies to all ports on the Switch.</p> <p><i>rx_rate</i> - Enables ingress rate limiting</p> <ul style="list-style-type: none"> <i>no_limit</i> – Indicates no limit is defined. <i><value 64-1024000></i> – Indicates a range between 64-1024000 kbps. <p><i>tx_rate</i> – Enables egress rate limiting.</p> <ul style="list-style-type: none"> <i>no_limit</i> – Indicates no limit is defined. <i><value 64-1000000></i> – Indicates a range between 64-1024000 kbps.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure bandwidth control configuration:

```

DES-1210-28/ME:5# config bandwidth_control all rx_rate no_limit tx_rate
no_limit
Command: config bandwidth_control all rx_rate no_limit tx_rate no_limit

Success

DES-1210-28/ME:5#

```

show bandwidth_control

Purpose	To display bandwidth control settings on the Switch.
Syntax	show bandwidth control [<portlist> all]
Description	The show bandwidth_control command displays bandwidth control.
Parameters	<p><i><portlist></i> – A port or range of ports to be configured.</p> <p><i>all</i> – Specifies that the show bandwidth_control command applies to all ports on the Switch.</p>
Restrictions	None.

Example usage:

To display the bandwidth control configuration:

```
DES-1210-28/ME:5# show bandwidth_control
Command: show bandwidth_control

Port  RX Rate  Tx Rate
----  -
1     no_limit  no_limit
2     no_limit  no_limit
3     no_limit  no_limit
4     no_limit  no_limit
5     no_limit  no_limit
6     no_limit  no_limit
7     no_limit  no_limit
8     no_limit  no_limit
9     no_limit  no_limit
10    no_limit  no_limit

Total entries : 10

DES-1210-28/ME:5#
```

config cos mac_mapping

Purpose	To configure the CoS MAC mapping method.
Syntax	config cos mac_mapping destination_addr <macaddr> class <class_id 0-3>
Description	The config cos mac_mapping command is used to configure the CoS MAC mapping method on the Switch.
Parameters	<macaddr> - Specifies the MAC address to be mapped. For example, 01:00:5E:00:00:00. <class_id 0-3> - Specifies the number of the Switch's hardware priority queue.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the CoS mac mapping on the Switch:

```
DES-1210-28/ME:5# config cos mac_mapping destination_addr 00-01-c2-11-22-33 class 2
Command: config cos mac_mapping destination_addr 00-01-c2-11-22-33 class 2

Success!

DES-1210-28/ME:5#
```

show cos mac_mapping

Purpose	To display the CoS MAC mapping method.
Syntax	show cos mac_mapping {destination_addr <macaddr>}
Description	The show cos mac_mapping command is used to display the CoS MAC mapping method on the Switch.
Parameters	<macaddr> - Specifies the MAC address to be removed.
Restrictions	None.

Example usage:

To display the CoS mac mapping on the Switch:

```
DES-1210-28/ME:5# show cos mac_mapping
Command: show cos mac_mapping

MAC ADDRESS          Class
-----
00-01-C2-11-22-33   2

DES-1210-28/ME:5#
```

delete cos mac_mapping

Purpose	To remove the CoS MAC mapping method.
Syntax	delete cos mac_mapping destination_addr <macaddr>
Description	The delete cos mac_mapping command is used to delete the CoS MAC mapping method on the Switch.
Parameters	<macaddr> - Specifies the MAC address to be removed.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete the CoS mac mapping on the Switch:

```
DES-1210-28/ME:5# delete cos mac_mapping destination_addr 00-01-c2-11-22-33
Command: delete cos mac_mapping destination_addr 00-01-c2-11-22-33

Success!

DES-1210-28/ME:5#
```

config cos ip_mapping

Purpose	To configure the CoS IP mapping method.
Syntax	config cos ip_mapping destination_ip <ipaddr> class <class_id 0-3>
Description	The config cos ip_mapping command is used to configure the CoS

	IP mapping method on the Switch.
Parameters	< <i>ipaddr</i> > - Specifies the IP address to be mapped. For example, 10.90.90.99. < <i>class_id 0-3</i> > - Specifies the number of the Switch's hardware priority queue.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the CoS IP mapping on the Switch:

```
DES-1210-28/ME:5# config cos ip_mapping destination_ip 10.0.0.56 class 1
Command: config cos ip_mapping destination_ip 10.0.0.56 class 1
```

Success!

```
DES-1210-28/ME:5#
```

show cos ip_mapping

Purpose	To display the CoS IP mapping method.
Syntax	show cos ip_mapping {destination_ip <ipaddr>}
Description	The show cos ip_mapping command is used to display the CoS MAC mapping method on the Switch.
Parameters	< <i>ipaddr</i> > - Specifies the IP address to be displayed. For example, 10.90.90.99.
Restrictions	None.

Example usage:

To display the CoS ip mapping on the Switch:

```
DES-1210-28/ME:5# show cos ip_mapping
Command: show cos ip_mapping
```

```
IP ADDRESS          Class
-----
10.0.0.56          1
```

```
DES-1210-28/ME:5#
```

delete cos ip_mapping

Purpose	To remove the CoS IP mapping method.
Syntax	delete cos ip_mapping destination_ip <ipaddr>
Description	The delete cos ip_mapping command is used to delete the CoS IP mapping method on the Switch.
Parameters	< <i>ipaddr</i> > - Specifies the IP address to be removed.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete the CoS ip mapping on the Switch:

```
DES-1210-28/ME:5# delete cos ip_mapping destination_ip 10.0.0.56
Command: delete cos ip_mapping destination_ip 10.0.0.56

Success!

DES-1210-28/ME:5#
```

config cos mapping

Purpose	To configure the method of which incoming packets will be identified for the CoS to port mapping feature.
Syntax	config cos mapping port [<portlist> all] [802.1p dscp_tos none]
Description	The config cos mapping port command is used to configure the method of which incoming packets will be identified for the CoS to port mapping feature on the Switch.
Parameters	<portlist> - A port or range of ports to be configured. all - Specifies all ports to be configured on the Switch. [802.1p dscp none] – Specified which incoming packets will be identified for the CoS.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the CoS mapping on the Switch:

```
DES-1210-28/ME:5# config cos mapping port all 802.1p
Command: config cos mapping port all 802.1p

Success

DES-1210-28/ME:5#
```

show cos mapping

Purpose	To display the information regarding CoS mapping enabled ports and their mapping method.
Syntax	show cos mapping {port <portlist>}
Description	The show cos mapping command displays the information regarding CoS mapping enabled ports and their mapping method.
Parameters	<portlist> - A port or range of ports to be displayed.
Restrictions	None.

Example usage:

To display the CoS mapping on the Switch:

```
DES-1210-28/ME:5# show cos mapping port 1-5
```

Command: show cos mapping port 1-5

Port	Port_Priority	Ethernet_Priority	IP_Priority
1	off	802.1p	DSCP
2	off	802.1p	DSCP
3	off	802.1p	DSCP
4	off	802.1p	DSCP
5	off	802.1p	DSCP

DES-1210-28/ME:5#

config cos protocol_mapping

Purpose	To configure the CoS protocol mapping method on the Switch.
Syntax	config cos protocol_mapping protocol <ip_protocol 1-255> class <class_id 0-3>
Description	The config cos protocol_mapping command is used to configure the CoS protocol mapping method on the Switch.
Parameters	<ip_protocol 1-255> - Specifies the protocol IP to be mapped. <class_id 0-3> - Specifies the number of the Switch's hardware priority queue
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the CoS mapping on the Switch:

```
DES-1210-28/ME:5# config cos protocol_mapping protocol 10 class 1
Command: config cos protocol_mapping protocol 10 class 1
```

Success!

```
DES-1210-28/ME:5#
```

show cos protocol_mapping

Purpose	To display the CoS protocol mapping information between an incoming packet's 802.1p priority value.
Syntax	show cos protocol_mapping {protocol <ip_protocol 1-255>}
Description	The show cos protocol_mapping command is used to display the CoS protocol mapping information between an incoming packet's 802.1p priority value.
Parameters	<ip_protocol 1-255> - Specifies the mapped protocol IP to be displayed.
Restrictions	None.

Example usage:

To display the CoS protocol mapping on the Switch:

```
DES-1210-28/ME:5# show cos protocol_mapping
```

```
Command: show cos protocol_mapping
```

```
IP Protocol      Class
-----
10                1
```

```
DES-1210-28/ME:5#
```

delete cos protocol_mapping

Purpose	To delete the CoS protocol mapping between an incoming packet's 802.1p priority value.
Syntax	delete cos protocol_mapping protocol <ip_protocol 1-255>
Description	The delete cos protocol_mapping command is used to delete the CoS protocol mapping between an incoming packet's 802.1p priority value.
Parameters	<ip_protocol 1-255> - Specifies the mapped protocol IP to be deleted.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete the CoS protocol mapping on the Switch:

```
DES-1210-28/ME:5# delete cos protocol_mapping protocol 10
```

```
Command: delete cos protocol_mapping protocol 10
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config cos vlanid_mapping

Purpose	To configure the CoS VLAN id mapping method on the Switch.
Syntax	config cos vlanid_mapping vid <vlanid 1-4094> class <class_id 0-3>
Description	The config cos vlanid_mapping command is used to configure the CoS VLAN id mapping method on the Switch.
Parameters	<vlanid 1-4094> - Specifies the vlan id to be mapped. <class_id 0-3> - Specifies the number of the Switch's hardware priority queue.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure a CoS VLAN id mapping on the Switch:

```
DES-1210-28/ME:5# config cos vlanid_mapping vid 100 class 2
```

```
Command: config cos vlanid_mapping vid 100 class 2
```

Success!

DES-1210-28/ME:5#

show cos vlanid_mapping

Purpose	To display the CoS VLAN id mapping information between an incoming packet's 802.1p priority value.
Syntax	show cos vlanid_mapping {vid <vlanid 1-4094>}
Description	The show cos vlanid_mapping command is used to display the CoS VLAN id mapping information between an incoming packet's 802.1p priority value.
Parameters	<vlanid 1-4094> - Specifies the mapped vlan id information to be displayed.
Restrictions	None.

Example usage:

To display the CoS VLAN id mapping on the Switch:

```
DES-1210-28/ME:5# show cos vlanid_mapping
Command: show cos vlanid_mapping

VLAN ID          Class
-----
100              2

DES-1210-28/ME:5#
```

delete cos vlanid_mapping

Purpose	To delete the mapping between an incoming packet's 802.1p priority value.
Syntax	delete cos vlanid_mapping vid <vlanid 1-4094>
Description	The delete cos vlanid_mapping command is used to delete the mapping between an incoming packet's 802.1p priority value.
Parameters	<vlanid 1-4094> - Specifies the mapped vlan id information to be deleted.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To deleted the CoS VLAN id mapping on the Switch:

```
DES-1210-28/ME:5# delete cos vlanid_mapping vid 100
Command: delete cos vlanid_mapping vid 100

Success!
```

```
DES-1210-28/ME:5#
```

config cos tos

Purpose	To configure the CoS tos on the Switch.
Syntax	config cos tos value <value 0-7> class <class_id 0-3>
Description	The config cos tos command is used to configure the CoS tos on the Switch.
Parameters	<value 0-7> - Specifies the value of the Switch's tos queue. <class_id 0-3> - Specifies the number of the Switch's hardware priority queue.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure a CoS tos on the Switch:

```
DES-1210-28/ME:5# config cos tos value 1 class 1
Command: config cos tos value 1 class 1
```

Success

```
DES-1210-28/ME:5#
```

show cos tos

Purpose	To display the CoS tos mapping information between an incoming packet's 802.1p priority value.
Syntax	show cos tos {value <value 0-7>}
Description	The show cos tos command is used to display the CoS tos mapping information.
Parameters	<value 0-7> - Specifies the value of the Switch's tos queue.
Restrictions	None.

Example usage:

To display the CoS tos mapping on the Switch:

```
DES-1210-28/ME:5# show cos tos
Command: show cos tos
```

```
TOS  Class
-----
```

```
0    0
1    1
2    0
3    0
4    0
5    0
```



```
6    0
7    0
```

```
DES-1210-28/ME:5#
```

config cos tcp_port_mapping

Purpose	To configure the CoS TCP port mapping on the Switch.
Syntax	config cos tcp_port_mapping destination_port <value 0-65535> class <class_id 0-3>
Description	The config cos tcp_port_mapping command is used to configure the CoS TCP port mapping on the Switch.
Parameters	<value 0-65535> - Specifies the tcp port number to be mapped. <class_id 0-3> - Specifies the number of the Switch's hardware priority queue.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the CoS TCP port mapping on the Switch:

```
DES-1210-28/ME:5# config cos tcp_port_mapping destination_port 500
class 1
Command: config cos tcp_port_mapping destination_port 500 class 1

Success!

DES-1210-28/ME:5#
```

show cos tcp_port_mapping

Purpose	To displays the CoS TCP port mapping information on the Switch.
Syntax	show cos tcp_port_mapping {destination_port <value 0-65535>}
Description	The show cos tcp_port_mapping command is used to display the CoS TCP port mapping information on the Switch.
Parameters	<value 0-65535> - Specifies the mapped tcp port information to be displayed.
Restrictions	None.

Example usage:

To display the CoS TCP port mapping on the Switch:

```
DES-1210-28/ME:5# show cos tcp_port_mapping
Command: show cos tcp_port_mapping

TCP Port      Class
-----
500           1
```

DES-1210-28/ME:5#

delete cos tcp_port_mapping

Purpose	To delete the CoS TCP port mapping information on the Switch.
Syntax	delete cos tcp_port_mapping destination_port <value 0-65535>
Description	The delete cos tcp_port_mapping command is used to delete the CoS TCP port mapping information on the Switch.
Parameters	<value 0-65535> - Specifies the mapped tcp port information to be deleted.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete the CoS TCP port mapping on the Switch:

```
DES-1210-28/ME:5# delete cos tcp_port_mapping destination_port 500
Command: delete cos tcp_port_mapping destination_port 500

Success!

DES-1210-28/ME:5#
```

config cos udp_port_mapping

Purpose	To configure the CoS UDP port mapping on the Switch.
Syntax	config cos udp_port_mapping destination_port <value 0-65535> class <class_id 0-3>
Description	The config cos udp_port_mapping command is used to configure the CoS UDP port mapping on the Switch.
Parameters	<value 0-65535> - Specifies the udp port number to be mapped. <class_id 0-3> - Specifies the number of the Switch's hardware priority queue.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the CoS UDP port mapping on the Switch:

```
DES-1210-28/ME:5# config cos udp_port_mapping destination_port 500
class 2
Command: config cos udp_port_mapping destination_port 500 class 2

Success!

DES-1210-28/ME:5#
```

show cos udp_port_mapping

Purpose	To displays the CoS UDP port mapping information on the Switch.
---------	---

Syntax	show cos udp_port_mapping {destination_port <value 0-65535>}
Description	The show cos udp_port_mapping command is used to display the CoS UDP port mapping information on the Switch.
Parameters	<value 0-65535> - Specifies the mapped udp port information to be displayed.
Restrictions	None.

Example usage:

To display the CoS UDP port mapping on the Switch:

```
DES-1210-28/ME:5# show cos udp_port_mapping
Command: show cos udp_port_mapping

UDP Port      Class
-----
500           2

DES-1210-28/ME:5#
```

delete cos udp_port_mapping

Purpose	To delete the CoS UDP port mapping information on the Switch.
Syntax	delete cos udp_port_mapping destination_port <value 0-65535>
Description	The delete udp tcp_port_mapping command is used to delete the CoS TCP port mapping information on the Switch.
Parameters	<value 0-65535> - Specifies the mapped udp port information to be deleted.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete the CoS UDP port mapping on the Switch:

```
DES-1210-28/ME:5# delete cos udp_port_mapping destination_port 500
Command: delete cos udp_port_mapping destination_port 500

Success!

DES-1210-28/ME:5#
```

config 802.1p user_priority

Purpose	To map the 802.1p user priority of an incoming packet to one of the four hardware classes of service available on the Switch.
Syntax	config 802.1p user_priority <priority 0-7> <class_id 0-3>
Description	The config 802.1p user_priority command configures the way the Switch maps an incoming packet, based on its 802.1p user priority tag, to one of the four hardware priority classes of service available

	on the Switch. The Switch's default is to map the incoming 802.1p priority values to the four hardware classes of service according to the following chart:																											
	<table border="1"> <thead> <tr> <th>802.1p value</th> <th>Switch Priority Queue</th> <th>Switch Priority Queue(stack)</th> </tr> </thead> <tbody> <tr><td>0</td><td>1</td><td>0</td></tr> <tr><td>1</td><td>0</td><td>0</td></tr> <tr><td>2</td><td>0</td><td>0</td></tr> <tr><td>3</td><td>1</td><td>0</td></tr> <tr><td>4</td><td>2</td><td>1</td></tr> <tr><td>5</td><td>2</td><td>1</td></tr> <tr><td>6</td><td>3</td><td>2</td></tr> <tr><td>7</td><td>3</td><td>2</td></tr> </tbody> </table>	802.1p value	Switch Priority Queue	Switch Priority Queue(stack)	0	1	0	1	0	0	2	0	0	3	1	0	4	2	1	5	2	1	6	3	2	7	3	2
802.1p value	Switch Priority Queue	Switch Priority Queue(stack)																										
0	1	0																										
1	0	0																										
2	0	0																										
3	1	0																										
4	2	1																										
5	2	1																										
6	3	2																										
7	3	2																										
Parameters	<p><i><priority 0-7></i> – The 802.1p priority value (0 to 7) to map to one of the Switch's four hardware priority classes of service.</p> <p><i><class_id 0-3></i> – The Switch's hardware priority class of service (0 to 3) to map to the 802.1p priority value specified above.</p>																											
Restrictions	Only administrator or operator level users can issue this command.																											

Example usage:

To configure 802.1p user priority on the Switch:

```
DES-1210-28/ME:5# config 802.1p user_priority 2 0
Command: config 802.1p user_priority 2 0

Success

DES-1210-28/ME:5#
```

show 802.1p user_priority

Purpose	To display the current mapping between an incoming packet's 802.1p priority value and one of the Switch's eight hardware priority classes of service.
Syntax	show 802.1p user_priority
Description	The show 802.1p user_priority command displays the current mapping of an incoming packet's 802.1p priority value to one of the Switch's four hardware priority queues.
Parameters	None.
Restrictions	None.

Example usage:

To show 802.1p user priority:

```
DES-1210-28/ME:5# show 802.1p user_priority
Command: show 802.1p user_priority

QOS Class of Traffic

Priority-0 -> <Class-1>
```

```

Priority-1 -> <Class-0>
Priority-2 -> <Class-0>
Priority-3 -> <Class-1>
Priority-4 -> <Class-2>
Priority-5 -> <Class-2>
Priority-6 -> <Class-3>
Priority-7 -> <Class-3>

```

```
DES-1210-28/ME:5#
```

config 802.1p default_priority

Purpose	To assign an 802.1p priority tag to an incoming untagged packet that has no 802.1p priority tag.
Syntax	config 802.1p default_priority [<portlist> all] <priority 0-7>
Description	The config 802.1p default_priority command specifies the 802.1p priority value an untagged, incoming packet is assigned before being forwarded to its destination.
Parameters	<p><portlist> – A port or range of ports to be configured.</p> <p>all – Specifies that the config 802.1p default_priority command applies to all ports on the Switch.</p> <p><priority 0-7> – The 802.1p priority value that an untagged, incoming packet is granted before being forwarded to its destination.</p>
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To configure 802.1p default priority on the Switch:

```
DES-1210-28/ME:5# config 802.1p default_priority all 4
Command: config 802.1p default_priority all 4
```

```
Success
```

```
DES-1210-28/ME:5#
```

show 802.1p default_priority

Purpose	To display the currently configured 802.1p priority value that is assigned to an incoming, untagged packet before being forwarded to its destination.
Syntax	show 802.1p default_priority {<portlist>}
Description	The show 802.1p default_priority command displays the currently configured 802.1p priority value that is assigned to an incoming, untagged packet before being forwarded to its destination.
Parameters	<portlist> – A port or range of ports to be displayed.
Restrictions	None.

Example usage:

To display the current port 1-5 802.1p default priority configuration on the Switch:

```
DES-1210-28/ME:5# show 802.1p default_priority 1-5
```

Command: show 802.1p default_priority 1-5

Port	Default Priority	Effective Priority
1	0	4
2	0	4
3	0	4
4	0	4
5	0	4

DES-1210-28/ME:5#

config scheduling_mechanism

Purpose	To configure the scheduling mechanism for the QoS function.
Syntax	config scheduling_mechanism [strict wrr]
Description	<p>The config scheduling_mechanism command configures the scheduling mechanism for the QoS function. It allows the user to select between a round robin (WRR) and a strict mechanism for emptying the priority classes of service of the QoS function. The Switch contains four hardware priority classes of service. Incoming packets must be mapped to one of these four hardware priority classes of service, or queues. This command is used to specify the rotation by which these four hardware priority queues are emptied.</p> <p>The Switch's default is to empty the four hardware priority queues in order – from the highest priority hardware queue (class 3) to the lowest priority hardware queue (class 0). Each queue will transmit all of the packets in its buffer before allowing the next lower priority queue to transmit its packets. A lower priority hardware queue will be pre-empted from emptying its queue if a packet is received on a higher priority hardware queue. The packet received on the higher priority hardware queue transmits its packet before allowing the lower priority hardware queue to resume clearing its queue.</p>
Parameters	<p><i>strict</i> – Specifies that the highest class of service is the first to be processed. That is, the highest class of service should finish emptying before the others begin.</p> <p><i>wrr</i> – Specifies that the priority classes of service are to empty packets in a weighted roundrobin (WRR) order.</p>
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To configure the traffic scheduling mechanism for each COS queue:

DES-1210-28/ME:5# config scheduling_mechanism strict

Command: config scheduling_mechanism strict

Success

DES-1210-28/ME:5#

show scheduling_mechanism

Purpose	To display the current traffic scheduling mechanisms in use on the Switch.
Syntax	show scheduling_mechanism
Description	The show scheduling_mechanism command displays the current traffic scheduling mechanisms in use on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To show the scheduling mechanism:

```
DES-1210-28/ME:5# show scheduling_mechanism
Command: show scheduling_mechanism

QOS Scheduling_mechanism

scheduling_mechanism : Strict Priority

DES-1210-28/ME:5#
```

config dscp mode

Purpose	To enable setting the DSCP User Priority
Syntax	config dscp mode
Description	The config dscp mode command enables the DSCP mode on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable the DSCP mode:

```
DES-1210-28/ME:5# config dscp mode
Command: config dscp mode

DSCP mode success!

Success

DES-1210-28/ME:5#
```

config dscp_mapping

Purpose	To enable setting the DSCP User Priority
Syntax	config dscp_mapping dscp_value <value 0-63> class <class_id 0-3>
Description	The config dscp_mapping command enables mapping the DSCP

	value (the priority) to a specific queue (the class_id).
Parameters	<i><value 0-63></i> –The selected value of priority. The value may be between 0 and 63. <i><class_id 0-3></i> – The class_id (queue) mapped to the priority. The value may be between 0 and 3
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the DSCP mapping with value 10 and class 2:

```
DES-1210-28/ME:5# config dscp_mapping dscp_value 10 class 2
Command: config dscp_mapping dscp_value 10 class 2
```

Success

```
DES-1210-28/ME:5#
```

show dscp_mapping

Purpose	To display the setting of DSCP mapping.
Syntax	show dscp_mapping {dscp_value <value 0-63>}
Description	The show dscp_mapping command displays the mapping of DSCP value.
Parameters	<i>dscp_value <value 0-63></i> - The selected value of priority will be dispalyed. The value may be between 0 and 63.
Restrictions	None.

Example usage:

To display the DSCP mapping with value 10:

```
DES-1210-28/ME:5# show dscp_mapping dscp_value 10
Command: show dscp_mapping dscp_value 10
```

```
DSCP  Class
-----
```

```
10    2
```

```
DES-1210-28/ME:5#
```


RMON COMMANDS

The RMON commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable rmon	
disable rmon	
create rmon alarm	<alarm_index 1-65535> <OID_variable 255> <interval 1-2147482647> [absolute delta] rising-threshold <value 0-2147483647> <rising_event_index 1-65535> falling-threshold <value 0-2147483647> <falling_event_index 1-65535> {[owner <owner_string 127>]}
delete rmon alarm	<alarm_index 1-65535>
create rmon collection stats	<stats_index 1-65535> port <ifindex> owner <owner_string 127>
delete rmon collection stats	<stats_index 1-65535>
create rmon collection history	<hist_index 1-65535> port <ifindex> {buckets <buckets_req 1-50> interval <interval 1-3600> owner <owner_string 127>}
delete rmon collection history	<hist_index 1-65535>
create rmon event	<event_index 1-65535> description <desc_string 127> {[log owner <owner_string 127> trap <community_string 127>]}
delete rmon event	<event_index 1-65535>
show rmon	

Each command is listed in detail, as follows:

enable rmon	
Purpose	To enable remote monitoring (RMON) status for the SNMP function.
Syntax	enable rmon
Description	The enable rmon command enables remote monitoring (RMON) status for the SNMP function on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the RMON feature on the Switch:

```
DES-1210-28/ME:5# enable rmon
Command: enable rmon
```

```

Success!
DES-1210-28/ME:5#

```

disable rmon

Purpose	To disable remote monitoring (RMON) status for the SNMP function.
Syntax	disable rmon
Description	The disable rmon command disables remote monitoring (RMON) status for the SNMP function on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the RMON feature on the Switch:

```

DES-1210-28/ME:5# disable rmon
Command: disable rmon

Success!
DES-1210-28/ME:5#

```

create rmon alarm

Purpose	To allow the user to configure the network alarms. Network alarms occur when a network problem, or event, is detected.
Syntax	create rmon alarm <alarm_index 1-65535> <OID_variable 255> <interval 1-2147482647> [absolute delta] rising-threshold <value 0-2147483647> <rising_event_index 1-65535> falling-threshold <value 0-2147483647> <falling_event_index 1-65535> {[owner <owner_string 127>]}
Description	The create rmon alarm command allows the user to configure the network alarms. Network alarms occur when a network problem, or event, is detected.
Parameters	<p><i><alarm_index></i> – Specifies the alarm number.</p> <p><i><OID_variable 255></i> – Specifies the MIB variable value.</p> <p><i><interval 1-2147482647></i> – Specifies the alarm interval time in seconds.</p> <p><i>[absolute delta]</i> – Specifies the sampling method for the selected variable and comparing the value against the thresholds. The possible values are absolute and delta:</p> <ul style="list-style-type: none"> <i>absolute</i> –Compares the values directly with the thresholds at the end of the sampling interval. <i>delta</i> –Subtracts the last sampled value from the current value. The difference in the values is compared to the threshold. <p><i>rising-threshold <value 0-2147483647></i> – Specifies the rising counter value that triggers the rising threshold alarm.</p>

	<p><i><rising_event_index 1-65535></i> – Specifies the event that triggers the specific alarm.</p> <p><i>falling-threshold <value 0-2147483647></i> – Specifies the falling counter value that triggers the falling threshold alarm.</p> <p><i><falling_event_index 1-65535></i> – Specifies the event that triggers the specific alarm. The possible field values are user defined RMON events.</p> <p><i>owner <owner_string 127></i> – Specifies the device or user that defined the alarm.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a RMON alarm on the Switch:

```
DES-1210-28/ME:5# create rmon alarm 20 1 absolute rising-threshold
200 2falling-threshold 100 1 owner dlink
Command: create rmon alarm 20 1 absolute rising-threshold 200
2falling-threshold 100 1 owner dlink

Success!
DES-1210-28/ME:5#
```

delete rmon alarm

Purpose	To remove the network alarms.
Syntax	delete rmon alarm <alarm_index 1-65535>
Description	The delete rmon alarm command removes the network alarms.
Parameters	<i><alarm_index 1-65535></i> – Specifies the alarm number to be removed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a RMON alarm on the Switch:

```
DES-1210-28/ME:5# delete rmon alarm 100
Command: delete rmon alarm 100

Success!
DES-1210-28/ME:5#
```

create rmon collection stats

Purpose	To allow user to configure the rmon stats settings on the Switch.
Syntax	create rmon collection stats <stats_index 1-65535> port <ifindex> owner <owner_string 127>
Description	The create rmon collection stats command allows user to configure the rmon stats settings on the Switch.
Parameters	<i><stats_index 1-65535></i> – Specifies the stats number. <i>port <ifindex></i> – Specifies the port from which the RMON information

was taken.

owner <*owner_string* 127> - Specifies the device or user that defined the stats.

Restrictions

Only Administrator or operator-level users can issue this command.

Example usage:

To create a RMON collection stats on the Switch:

```
DES-1210-28/ME:5# create rmon collection stats 100 port 2 owner dlink
Command: create rmon collection stats 100 port 2 owner dlink
```

Success!

```
DES-1210-28/ME:5#
```

delete rmon collection stats

Purpose	To remove the network collection stats.
Syntax	delete rmon collection stats <stats_index 1-65535>
Description	The delete rmon collection stats command removes the network collection stats on the Switch.
Parameters	< <i>stats_index</i> 1-65535> - Specifies the stats number to be removed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a RMON collection stats on the Switch:

```
DES-1210-28/ME:5# delete rmon collection stats 2
Command: delete rmon collection stats 2
```

Success!

```
DES-1210-28/ME:5#
```

create rmon collection history

Purpose	To allow user to configure the rmon history settings on the Switch.
Syntax	create rmon collection history <hist_index 1-65535> port <ifindex> {buckets <buckets_req 1-50> interval <interval 1-3600> owner <owner_string 127>}
Description	The create rmon collection history command allows user to configure the rmon history settings on the Switch.
Parameters	< <i>hist_index</i> 1-65535> - Indicates the history control entry number. <i>port</i> < <i>ifindex</i> > - Specifies the port from which the RMON information was taken. <i>buckets</i> < <i>buckets_req</i> 1-50> - Specifies the number of buckets that the device saves. <i>interval</i> < <i>interval</i> 1-3600> - Specifies in seconds the time period that samplings are taken from the ports. The field range is 1-3600. The default is 1800 seconds (equal to 30 minutes). <i>owner</i> < <i>owner_string</i> 127> - Specifies the RMON station or user

	that requested the RMON information.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a RMON collection history on the Switch:

```
DES-1210-28/ME:5# create rmon collection history 120 port 2 buckets 25
Command: create rmon collection history 120 port 2 buckets 25

Success!
DES-1210-28/ME:5#
```

delete rmon collection history

Purpose	To remove the network collection history.
Syntax	delete rmon collection history <hist_index 1-65535>
Description	The delete rmon collection history command removes the network collection history on the Switch.
Parameters	<hist_index 1-65535> – Specifies the alarm history number to be removed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a RMON collection history on the Switch:

```
DES-1210-28/ME:5# delete rmon collection history 2
Command: delete rmon collection history 2

Success!
DES-1210-28/ME:5#
```

create rmon event

Purpose	To provide user to configure the settings of rmon event on the Switch.
Syntax	create rmon event <event_index 1-65535> description <desc_string 127> {[log owner <owner_string 127> trap <community_string 127>]}
Description	The create rmon event command allows user to provides user to configure the settings of rmon event on the Switch.
Parameters	<event_index 1-65535> – Specifies the event number. description <desc_string 127> – Specifies the user-defined event description. log – Indicates that the event is a log entry. owner <owner_string 127> – Specifies the time that the event occurred. trap <community_string 127> – Specifies the community to which the event belongs.

Restrictions	Only Administrator or operator-level users can issue this command.
--------------	--

Example usage:

To create a RMON collection history on the Switch:

```
DES-1210-28/ME:5# create rmon event 125 description linkrmon owner
dlink
Command: create rmon event 125 description linkrmon owner dlink

Success!
DES-1210-28/ME:5#
```

delete rmon event

Purpose	To remove the network event.
Syntax	delete rmon event <event_index 1-65535>
Description	The delete rmon event command removes the network event on the Switch.
Parameters	<i><event_index 1-65535></i> - Specifies the event number to be removed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a RMON event on the Switch:

```
DES-1210-28/ME:5# delete rmon event 2
Command: delete rmon event 2

Success!
DES-1210-28/ME:5#
```

show rmon

Purpose	To display remote monitoring (RMON) status for the SNMP function.
Syntax	show rmon
Description	The show rmon command displays remote monitoring (RMON) status for the SNMP function on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the RMON feature on the Switch:

```
DES-1210-28/ME:5# show rmon
Command: show rmon

RMON is enabled
```

Success!
DES-1210-28/ME:5#

PORT MIRRORING COMMANDS

The Port Mirroring commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable mirror	
disable mirror	
config mirror target	<short 1-28> [add delete] source ports <portlist> [both rx tx]
delete mirror	target <port> source <port>
show mirror	

Each command is listed in detail, as follows:

enable mirror

Purpose	Used to enable a previously entered port mirroring configuration.
Syntax	enable mirror
Description	The enable mirror command, combined with the disable mirror command below, allows the user to enter a port mirroring configuration into the Switch, and then turn the port mirroring on and off without having to modify the port mirroring configuration.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the mirroring feature:

```
DES-1210-28/ME:5# enable mirror
Command: enable mirror

Success

DES-1210-28/ME:5#
```

disable mirror

Purpose	Used to disable a previously entered port mirroring configuration.
Syntax	disable mirror
Description	The disable mirror command, combined with the enable mirror command above, allows the user to enter a port mirroring configuration into the Switch, and then turn the port mirroring on and off without having to modify the port mirroring configuration.

Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable mirroring configurations:

```
DES-1210-28/ME:5# disable mirror
Command: disable mirror

Success

DES-1210-28/ME:5#
```

config mirror target

Purpose	To configure a mirror port – source port pair on the Switch.
Syntax	config mirror target <short 1-28> [add delete] source ports <portlist> [both rx tx]
Description	The config mirror target command allows a port to have all of its traffic also sent to a designated port, where a network sniffer or other device can monitor the network traffic. In addition, one can specify that only traffic received by or sent by one or both is mirrored to the target port.
Parameters	<p><i>target <short 1-28></i> – Specifies the port that mirrors traffic forwarding.</p> <p><i>[add delete]</i> – Specifies to add or delete the target port.</p> <p><i>source ports <portlist></i> – Specifies the port or ports being mirrored. This cannot include the target port.</p> <p><i>rx</i> – Allows mirroring of packets received by (flowing into) the source port.</p> <p><i>tx</i> – Allows mirroring of packets sent to (flowing out of) the source port.</p> <p><i>both</i> – Allows mirroring of all the packets received or sent by the source port.</p> <p><i>Comment:</i> The user can define up to 8 source ports and one destination port. One source port can be configured each time using one CLI command, So in order to configure multiple source ports, multiple CLI commands should be used.</p>
Restrictions	A target port cannot be listed as a source port. Only Administrator or operator-level users can issue this command.

Example usage:

To add the mirroring ports:

```
DES-1210-28/ME:5# config mirror target 8 add source ports 1-5 both
Command: config mirror target 8 add source ports 1-5 both

Success

DES-1210-28/ME:5#
```

show mirror

Purpose	To show the current port mirroring configuration on the Switch.
Syntax	show mirror
Description	The show mirror command displays the current port mirroring configuration on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display mirroring configuration:

```
DES-1210-28/ME:5# show mirror
```

```
Command: show mirror
```

```
Port Mirror is enabled
```

```
Target Port : Fa0/8
```

```
Source Port : Fa0/1
```

```
Direction   : Both
```

```
Target Port : Fa0/8
```

```
Source Port : Fa0/2
```

```
Direction   : Both
```

```
Target Port : Fa0/8
```

```
Source Port : Fa0/3
```

```
Direction   : Both
```

```
Target Port : Fa0/8
```

```
Source Port : Fa0/4
```

```
Direction   : Both
```

```
Target Port : Fa0/8
```

```
Source Port : Fa0/5
```

```
Direction   : Both
```

```
DES-1210-28/ME:5#
```

VLAN COMMANDS

The VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create vlan	<string 20> {tag <int 2-4094> type_1q_vlan_advertisement}
delete vlan	[<vlan_name 20> vlanid <int 2-4094>]
config vlan	[<vlan_name 20> vlanid <vlanid 1-4094>] [[add [tagged untagged forbidden] delete] <portlist> {advertisement [enable disable]}]
config gvrp	[<portlist> all] state [enable disable] { ingress_checking [enable disable] acceptable_frame [Tagged_Only All_Frames] pvid <vlanid 1-4094>}
config pvid	<int 1-4094> ports <portlist>
config gvrp timer	[join_timer <sec 10-100000> leave_timer <sec 10-100000> leave-all_timer <sec 10-100000>]
enable gvrp	
disable gvrp	
show vlan	{<int 1-4094>}
show gvrp	{<portlist>}
show gvrp timer	
enable vlan_trunk	
disable vlan_trunk	
show vlan_trunk	
config vlan_trunk ports	[<portlist> all] state [enable disable]
enable asymmetric_vlan	
disable asymmetric_vlan	
show asymmetric_vlan	
enable management vlan	
disable management vlan	
config management vlan	<string 32>
show management vlan	

Each command is listed in detail, as follows:

create vlan

Purpose	To create a VLAN on the Switch.
Syntax	create vlan <string 20> {tag <int 2-4094> type_1q_vlan_advertisement}
Description	The create vlan command creates a VLAN on the Switch.
Parameters	<p><i><string 20></i> – The name of the VLAN to be created.</p> <p><i>tag <int 2-4094></i> – The VLAN ID of the VLAN to be created. The allowed values range from 2 to 4094.</p> <p><i>type_1q_vlan_advertisement</i> – Specifies the 1q vlan advertisement on the Switch.</p>
Restrictions	<p>Each VLAN name can be up to 32 characters. If the VLAN is not given a tag, it will be a port-based VLAN.</p> <p>Only administrator or operator-level users can issue this command.</p>

Example usage:

To create a VLAN v1, tag 3:

```
DES-1210-28/ME:5# create vlan v1 tag 3
Command: create vlan v1 tag 3

Success
DES-1210-28/ME:5#
```

delete vlan

Purpose	To delete a previously configured VLAN on the Switch.
Syntax	delete vlan [<vlan_name 20> vlanid <int 2-4094>]
Description	The delete vlan command deletes a previously configured VLAN on the Switch.
Parameters	<p><i><vlan_name 20></i> – The name of the VLAN to be deleted.</p> <p><i>vlan_id <int 2-4092></i> – The VLAN of the VLAN to be deleted.</p>
Restrictions	<p>Only administrator or operator-level users can issue this command.</p> <p>A user is required to disable Guest VLAN before deleting a VLAN.</p>

Example usage:

To remove a vlan which VLAN ID is 2:

```
DES-1210-28/ME:5# delete vlan vlanid 2
Command: delete vlan vlanid 2

Success
DES-1210-28/ME:5#
```

config vlan

Purpose	To add additional ports to a previously configured VLAN and to modify a VLAN name.
Syntax	config vlan [<vlan_name 20> vlanid <vlanid 1-4094>] [[add

	[tagged untagged forbidden] delete] <portlist> {advertisement [enable disable]}
Description	The config vlan command allows the user to add or delete ports to the port list of a previously configured VLAN. You can specify the additional ports as tagging, untagging, or forbidden. The default is to assign the ports as untagged.
Parameters	<p><i><vlan_name 20></i> – The name of the VLAN to be configure.</p> <p><i>vlanid <vlan_id 1-4094 ></i> – The ID of the VLAN to which to add ports.</p> <p><i>add</i> – Specifies that ports are to be added to a previously created vlan.</p> <p><i>delete</i> - Specifies that ports are to be deleted from a previously created vlan.</p> <p><i>tagged</i> – Specifies the additional ports as tagged.</p> <p><i>untagged</i> – Specifies the additional ports as untagged.</p> <p><i>forbidden</i> – Specifies the additional ports as forbidden.</p> <p><i><portlist></i> – A port or range of ports to be added to or deleted from the VLAN.</p> <p><i>advertisement [enable disable]</i> – Specifies that the vlan advertisement is enabled or disabled.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To add ports 4 through 8 as tagged ports to the VLAN 3:

```
DES-1210-28/ME:5# config vlan vlanid 3 add tagged 4-8
```

```
Command: config vlan vlanid 3 add tagged 4-8
```

```
Success
```

```
DES-1210-28/ME:5#
```

config gvrp

Purpose	To configure configures the Group VLAN Registration Protocol on the Switch. The user can configure ingress checking and acceptable frame tagged only, the sending and receiving of GVRP information, and the Port VLAN ID (PVID).
Syntax	config gvrp [<portlist> all] state [enable disable] { ingress_checking [enable disable] acceptable_frame [Tagged_Only All_Frames] pvid <vlanid 1-4094>}
Description	The config gvrp command configures the Group VLAN Registration Protocol on the Switch. The user can configure ingress checking and acceptable frame tagged only, the sending and receiving of GVRP information, and the Port VLAN ID (PVID).
Parameters	<p><i><portlist></i> – A port or range of ports for which to configure GVRP.</p> <p><i>all</i> – configure GVRP on ports.</p> <p><i>state [enable disable]</i> - enable and disable GVRP</p> <p><i>ingress_checking [enable disable]</i> – Enables or disables ingress checking for the specified port list.</p> <p><i>acceptable_frame [tagged_only admit_all]</i> – Defines the type of frame accepted. Acceptable frames can be limited to tagged frames only (<i>tagged_only</i>) or can accept tagged and untagged (<i>admit_all</i>).</p>

	<i>pvid</i> <vlanid 1-4094> – Specifies the default VLAN associated with the port, by VLAN ID.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To set the ingress checking status:

```
DES-1210-28/ME:5# config gvrp all ingress_checking enable
Command: config gvrp all ingress_checking enable

Success.

DES-1210-28/ME:5#
```

config pvid

Purpose	To configure the pvid on the Switch.
Syntax	config pvid <int 1-4094> ports <portlist>
Description	The config pvid command configures the Group VLAN Registration Protocol on the Switch.
Parameters	<int 1-4094> – Specifies the PVID to be configured. <portlist> – A port or range of ports which user want to configure with.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the PVID on the Switch:

```
DES-1210-28/ME:5# config pvid 1 ports 2
Command: config pvid 1 ports 2

Success.

DES-1210-28/ME:5#
```

config gvrp timer

Purpose	To configure GVRP on the Switch.
Syntax	config gvrp timer [join_timer <sec 10-100000> leave_timer <sec 10-100000> leave-all_timer <sec 10-100000>]
Description	The config gvrp timer command configures the Group VLAN Registration Protocol on the Switch. The user can configure ingress checking and acceptable frame tagged only, the sending and receiving of GVRP information, and the Port VLAN ID (PVID).
Parameters	<i>join_timer</i> <sec 10-100000> – Specifies the join time for the GVRP on the Switch. The time range is from 10 to 100000 seconds. <i>leave_timer</i> <sec 10-100000> – Specifies the leave time for the GVRP on the Switch. The time range is from 10 to 100000 seconds. <i>leave-all_timer</i> <sec 10-100000> – Specifies the leave all time for the GVRP on the Switch. The time range is from 10 to 100000 seconds.

Restrictions	Only administrator or operator-level users can issue this command.
--------------	--

Example usage:

To set the GVRP packet join time:

```
DES-1210-28/ME:5# config gvrp timer join_timer 100
Command: config gvrp timer join_timer 100

Success.

DES-1210-28/ME:5#
```

enable gvrp

Purpose	To enable GVRP on the Switch.
Syntax	enable gvrp
Description	The enable gvrp command, along with the disable gvrp command below, is used to enable and disable GVRP on the Switch, without changing the GVRP configuration on the ports and the LAGs.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable the generic VLAN Registration Protocol (GVRP):

```
DES-1210-28/ME:5# enable gvrp
Command: enable gvrp

Success.
DES-1210-28/ME:5#
DES-1210-28/ME:5#
```

disable gvrp

Purpose	To disable GVRP on the Switch.
Syntax	disable gvrp
Description	The disable gvrp command, along with the enable gvrp command above, is used to enable and disable GVRP on the Switch, without changing the GVRP configuration on the ports and the LAGs.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable the Generic VLAN Registration Protocol (GVRP):

```
DES-1210-28/ME:5# disable gvrp
Command: disable gvrp

Success.

DES-1210-28/ME:5#
```

show vlan

Purpose	To display the current VLAN configuration on the Switch
Syntax	show vlan {<int 1-4094>}
Description	The show vlan command displays summary information about each VLAN including the VLAN ID, VLAN name, the Tagging/Untagging status, and the Member/Non-member/Forbidden status of each port that is a member of the VLAN.
Parameters	<int 1-4094> – Specify the VLAN id to be displayed.
Restrictions	None.

Example usage:

To display the Switch's current VLAN settings:

```
DES-1210-28/ME:5# show vlan
Command: show vlan

VID          : 1      VLAN NAME    : default
VLAN Type    : Static
VLAN Advertisement : Disabled
Member Ports : 1-28
Untagged Ports : 1-28
Forbidden Ports :

VID          : 3      VLAN NAME    : v1
VLAN Type    : Static
VLAN Advertisement : Disabled
Member Ports :
Untagged Ports :
Forbidden Ports :

DES-1210-28/ME:5#
```

show gvrp

Purpose	To display the GVRP status for a port list or port channel on the Switch.
Syntax	show gvrp {<portlist>}
Description	The show gvrp command displays the GVRP status for a port list or a port channel on the Switch.
Parameters	<portlist> – Specifies a port or range of ports for which the GVRP status is to be displayed.
Restrictions	None.

Example usage:

To display GVRP port 5~8 status:

```
DES-1210-28/ME:5# show gvrp 5-8
Command: show gvrp 5-8
```


Global GVRP : Enable

Port	PVID	GVRP State	Ingress Checking	Acceptable Frame Type
----	----	-----	-----	-----
5	1	Enable	Enable	All Frames
6	1	Enable	Enable	All Frames
7	1	Enable	Enable	All Frames
8	1	Enable	Enable	All Frames

Total Entries : 4

DES-1210-28/ME:5#

show gvrp timer

Purpose	To display the GVRP timer information on the Switch.
Syntax	show gvrp timer
Description	The show gvrp command displays the GVRP timer on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display GVRP timer information:

DES-1210-28/ME:5# show gvrp timer

Command: show gvrp timer

Garp Timer Info (in milli seconds)

Join-time	Leave-time	Leave-all-time
-----	-----	-----
100	600	10000

DES-1210-28/ME:5#

enable vlan_trunk

Purpose	To enable VLAN trunking on the switch.
Syntax	enable vlan_trunk
Description	The enable vlan_trunk command, along with the disable vlan_trunk command below, is used to enable and disable VLAN trunking on the Switch, without changing the VLAN trunking configuration on the ports.
Parameters	<i>None.</i>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable `vlan_trunk` on the switch:

```
DES-1210-28/ME:5#enable vlan_trunk
Command: enable vlan_trunk

Success.
DES-1210-28/ME:5#
```

disable vlan_trunk

Purpose	To disable VLAN Trunking on the switch.
Syntax	disable vlan_trunk
Description	The disable vlan_trunk command, along with the enable vlan_trunk command below, is used to disable and enable VLAN Trunking on the Switch, without changing the VLAN Trunking configuration on the ports.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable `vlan_trunk` on the switch:

```
DES-1210-28/ME:5# disable vlan_trunk
Command: disable vlan_trunk

Success.
DES-1210-28/ME:5#
```

show vlan_trunk

Purpose	To display the current VLAN Trunking configuration on the Switch
Syntax	show vlan_trunk
Description	The show vlan_trunk command displays summary information about VLAN trunking status and configured ports.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To display the Switch's current `VLAN_trunk` settings:

```
DES-1210-28/ME:5# show vlan_trunk
Command: show vlan_trunk

VLAN Trunk Status   :Enable
Member Ports       :None

DES-1210-28/ME:5#
```

config vlan_trunk ports

Purpose	To configure VLAN Trunking port settings on the Switch.
Syntax	config vlan_trunk ports [<portlist> all] state [enable disable]
Description	The config vlan_trunk ports command configures the VLAN trunking port settings on the Switch. The user can enable VLAN Trunking and define ports to be added to the VLAN Trunking settings.
Parameters	[<portlist> all] – A port, range of ports or all ports for which to configure VLAN Trunking. state [enable disable] – enable and disable VLAN trunking.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To define VLAN Trunking:

```
DES-1210-28/ME:5# config vlan_trunk ports all state enable
Command: config vlan_trunk ports all state enable

success
DES-1210-28/ME:5#
```

enable asymmetric_vlan

Purpose	To enable Asymmetric VLAN on the switch.
Syntax	enable asymmetric_vlan
Description	The enable asymmetric_vlan command, along with the disable enable asymmetric_vlan command below, is used to enable and disable Asymmetric VLAN on the Switch
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable Asymmetric VLAN on the switch:

```
DES-1210-28/ME:5# enable asymmetric_vlan
Command: enable asymmetric_vlan

Success
DES-1210-28/ME:5#
```

disable asymmetric_vlan

Purpose	To disable Asymmetric VLAN on the switch.
Syntax	disable asymmetric_vlan
Description	The disable asymmetric_vlan command, along with the enable asymmetric_vlan command below, is used to disable and enable Asymmetric VLAN on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable `asymmetric_vlan` on the switch:

```
DES-1210-28/ME:5# disable asymmetric_vlan
Command: disable asymmetric_vlan

Success
DES-1210-28/ME:5#
```

show asymmetric_vlan

Purpose	To display the Asymmetric VLAN status on the Switch.
Syntax	show asymmetric_vlan
Description	The show asymmetric_vlan command displays the Asymmetric VLAN status on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display Asymmetric VLAN status:

```
DES-1210-28/ME:5# show asymmetric_vlan
Command: show asymmetric_vlan

Asymmetric VLAN : Enable
DES-1210-28/ME:5#
```

enable management vlan

Purpose	To enable the management VLAN on the Switch.
Syntax	enable management vlan
Description	The enable management vlan command enables the management VLAN on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable management VLAN on the switch:

```
DES-1210-28/ME:5# enable management vlan
Command: enable management vlan

success
DES-1210-28/ME:5#
```

disable management vlan

Purpose	To disable the management VLAN on the Switch.
Syntax	disable management vlan

Description	The disable management vlan command disables the management VLAN on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable management VLAN on the switch:

```
DES-1210-28/ME:5# disable management vlan
Command: disable management vlan

success
DES-1210-28/ME:5#
```

config management vlan

Purpose	To configure the management VLAN on the Switch.
Syntax	config management vlan <string 32>
Description	The config management vlan command configures the management VLAN on the Switch.
Parameters	<string 32> – Specifies the management VLAN name on the Switch.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the management VLAN on the switch:

```
DES-1210-28/ME:5# config management vlan default
Command: config management vlan default

success
DES-1210-28/ME:5#
```

show management vlan

Purpose	To display the management VLAN on the Switch.
Syntax	show management vlan
Description	The show management vlan command displays the management VLAN information on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the management VLAN on the switch:

```
DES-1210-28/ME:5# show management vlan
Command: show management vlan
```

management vlan is enable

management vlan id : 1

management vlan name: default

DES-1210-28/ME:5#

Q-IN-Q COMMANDS

The Link Aggregation commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable qinq	
disable qinq	
show qinq	{ports [<portlist> all]}
config qinq ports	[<portlist> all] {role [nni uni] outer_tpid <hex 0x1 - 0xffff> trust_cvid [enable disable] vlan_translation [enable disable] }
create vlan_translation	[add replace] cvid <vidlist> svid <vlanid 1-4094>
show vlan_translation	cvid {<vidlist>}
delete vlan_translation	cvid [<vidlist> all]

Each command is listed in detail, as follows:

enable qinq	
Purpose	To enable the Q-in-Q mode.
Syntax	enable qinq
Description	<p>The enable qinq command creates a used to enable the Q-in-Q mode.</p> <p>When Q-in-Q is enabled, all network port roles will be NNI port and their outer TPID will be set to 88a8. All existing static VLANs will run as SP-VLAN. All dynamically learned L2 address will be cleared. GVRP and STP need to be disabled manually.</p> <p>If you need to run GVRP on the Switch, firstly enable GVRP manually. The default setting of Q-in-Q is disabled.</p>
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To enable Q-in-Q:

```
DES-1210-28/ME:5# enable qinq
Command: enable qinq
```

```
Success!
```

```
DES-1210-28/ME:5#
```

disable qinq

Purpose	To disable the Q-in-Q mode.
Syntax	disable qinq
Description	The disable qinq command creates a used to disable the Q-in-Q mode. All dynamically learned L2 address will be cleared. All dynamically registered VLAN entries will be cleared, GVRP will be disabled. If you need to run GVRP on the Switch, firstly enable GVRP manually. All existing SP-VLANs will run as static 1Q VLANs. The default setting of Q-in-Q is disabled.
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To disable Q-in-Q:

```
DES-1210-28/ME:5# disable qinq
Command: disable qinq

Success!

DES-1210-28/ME:5#
```

show qinq

Purpose	To show global Q-in-Q and port Q-in-Q mode status.
Syntax	show qinq {ports [<portlist> all]}
Description	The show qinq command is used to show the global Q-in-Q status, including: port role in Q-in-Q mode and port outer TPID.
Parameters	<portlist> - Specifies a range of ports to be displayed. If no parameter is specified, the system will display all Q-in-Q port information. <i>all</i> - Specifies all ports to be displayed.
Restrictions	None.

Example usage:

To show the Q-in-Q status for ports 1 to 4:

```
DES-1210-28/ME:5# show qinq ports 1-4
Command: show qinq ports 1-4

Port Role Outer TPID Trust_CVID VLAN Translation
-----
1  UNI 0x8100  Enable  Disable
2  UNI 0x8100  Enable  Disable
3  UNI 0x8100  Enable  Disable
4  UNI 0x8100  Enable  Disable
```


DES-1210-28/ME:5#

config qinq ports

Purpose	Used to configure Q-in-Q ports.
Syntax	config qinq ports [<portlist> all] {role [nni uni] outer_tpid <hex 0x1 - 0xffff> trust_cvid [enable disable] vlan_translation [enable disable] }
Description	The config qinq ports command is used to configure the port level setting for the Q-in-Q VLAN function. This setting is not effective when the Q-in-Q mode is disabled.
Parameters	<p><portlist> - A range of ports to configure.</p> <p><i>all</i> – Specifies all ports to be configure.</p> <p><i>role</i> - Port role in Q-in-Q mode, it can be UNI port or NNI port.</p> <p><i>outer_tpid</i> - TPID in the SP-VLAN tag.</p> <p><i>trust_cvid</i> - For C-Tag packets, trust C-VID determines if S-VID is enabled. Otherwise, the default is disabled.</p> <p><i>vlan_translation</i> - If specified as enabled, the VLAN translation will be performed on the port. The setting is disabled by default.</p>
Restrictions	Only administrator-level users can issue this command.

Example usage:

To configure port list 1 to 4 as NNI port, set outer TPID to 0x88a8:

```
DES-1210-28/ME:5# config qinq ports 1-4 role nni outer_tpid 0x88a8
```

```
Command: config qinq ports 1-4 role nni outer_tpid 0x88a8
```

Warning: The outer TPID will be globally applied to all ports!

Success!

```
DES-1210-28/ME:5#
```

create vlan_translation

Purpose	To create a VLAN translation rule that will be added as a new rule or replace a current rule.
Syntax	create vlan_translation [add replace] cvid <vidlist> svid <vlanid 1-4094>
Description	The create vlan_translation cvid command is used to create a VLAN translation rule to add to or replace the outgoing packet which is single S-tagged (the C-VID changes to S-VID and the packet's TPID changes to an outer TPID).
Parameters	<p><i>cvid</i> – C-VLAN ID of packets that ingress from a UNI port.</p> <p><i>svid</i> – The S-VLAN ID that replaces the C-VLAN ID or is inserted in the packet.</p> <p><vlanid 1-4094> – A VLAN ID between 1 and 4094.</p>
Restrictions	None.

Example usage:

To create a VLAN translation on the Switch:

```
DES-1210-28/ME:5# create vlan_translation add cvid 2 svid 2
Command: create vlan_translation add cvid 2 svid 2

Success!

DES-1210-28/ME:5#
```

show vlan_translation

Purpose	To display the current VLAN translation rules on the Switch.
Syntax	show vlan_translation cvid {<vidlist>}
Description	The show vlan_translation cvid command display the current VLAN translation cvid on the Switch
Parameters	<vidlist> – The Q-in-Q translation rules for the specified C-VID list. .
Restrictions	None.

Example usage:

To display the VLAN translation cvid on the Switch:

```
DES-1210-28/ME:5# show vlan_translation cvid
Command: show vlan_translation cvid

CVID SPVID Action
-----
-----

Total Entries : 0

DES-1210-28/ME:5#
```

delete vlan_translation cvid

Purpose	To delete VLAN translation rules.
Syntax	delete vlan_translation cvid [<vidlist> all]
Description	The delete vlan_translation cvid command is used to delete VLAN translation rules.
Parameters	<vidlist> - Specifies C-VID rules in VLAN translation. all – Specifies all C-VID rules to be deleted.
Restrictions	None.

Example usage:

To delete all C-VID VLAN translation rules:

```
DES-1210-28/ME:5# delete vlan_translation cvid all
Command: delete vlan_translation cvid all
```

Success!

DES-1210-28/ME:5#

LINK AGGREGATION COMMANDS

The Link Aggregation commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create link_aggregation	group_id <value 1-8> {type [lacp static]}
delete link_aggregation	group_id <value 1-8>
config link_aggregation	group_id <value 1-8> master_port <port 1-28> ports <portlist>
show link_aggregation	{group_id <value 1-8> algorithm}

Each command is listed in detail, as follows:

create link_aggregation	
Purpose	To create a link aggregation group on the Switch.
Syntax	create link_aggregation group_id <value 1-8> {type [lacp static]}
Description	The create link_aggregation command creates a link aggregation group with a unique identifier.
Parameters	<p><i>group_id</i> <value 1-8> – Specifies the group ID. The Switch allows up to 8 link aggregation groups to be configured. The group number identifies each of the groups.</p> <p><i>type</i> – Specify the type of link aggregation used for the group. If the type is not specified the default type is <i>static</i>.</p> <ul style="list-style-type: none"> • <i>lacp</i> – This designates the port group as LACP compliant. LACP allows dynamic adjustment to the aggregated port group. LACP compliant ports may be further configured (see config lacp_ports). LACP compliant must be connected to LACP compliant devices. The maximum ports that can be configure in the same LACP are 16. • <i>static</i> – This designates the aggregated port group as static. Static port groups can not be changed as easily as LACP compliant port groups since both linked devices must be manually configured if the configuration of the trunked group is changed. If static link aggregation is used, be sure that both ends of the connection are properly configured and that all ports have the same speed/duplex settings. The maximum ports that can be configure in the same static LAG are 8
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To create a link aggregation group:

```
DES-1210-28/ME:5# create link_aggregation group_id 1
Command: create link_aggregation group_id 1
```

Success.

DES-1210-28/ME:5#

delete link_aggregation

Purpose	To delete a previously configured link aggregation group.
Syntax	delete link_aggregation group_id <value 1-8>
Description	The delete link_aggregation group_id command deletes a previously configured link aggregation group.
Parameters	<i>group_id</i> <value 1-8> – Specifies the group ID. The Switch allows up to 8 link aggregation groups to be configured. The group number identifies each of the groups.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete link aggregation group:

```
DES-1210-28/ME:5# delete link_aggregation group_id 1
Command: delete link_aggregation group_id 1
```

```
LA channel 1 delete successful
DES-1210-28/ME:5#
```

config link_aggregation

Purpose	To configure a previously created link aggregation group.
Syntax	config link_aggregation group_id <value 1-8> master_port <port 1-28> ports <portlist>
Description	The config link_aggregation command configures a link aggregation group created with the create link_aggregation command above.
Parameters	<i>group_id</i> <value 1-8> – Specifies the group ID. The Switch allows up to 8 link aggregation groups to be configured. The group number identifies each of the groups. <i>master_port</i> <port 1-28> – Specifies a list of ports to belong to the link aggregation group. Ports will be listed in only one aggregation group and link aggregation groups can not overlap to each other. The user must configure at list two ports in LAG. <i>ports</i> <portlist> – Specifies a list of ports to belong to the link aggregation group.
Restrictions	Only administrator or operator-level users can issue this command. Link aggregation groups may not overlap.

Example usage:

To define a load-sharing group of ports, group-id 2 with group members ports 1-5:

```
DES-1210-28/ME:5# config link_aggregation group_id 2 master_port 1 ports 1-5
Command: config link_aggregation group_id 2 master_port 1 ports 1-5
```

Success.

DES-1210-28/ME:5#

show link_aggregation

Purpose	To display the current link aggregation configuration on the Switch.
Syntax	show link_aggregation {group_id <value 1-8> algorithm}
Description	The show link_aggregation command displays the current link aggregation configuration of the Switch.
Parameters	<i>group_id</i> <value 1-8> – Specifies the group ID. The Switch allows up to 8 link aggregation groups to be configured. The group number identifies each of the groups. <i>algorithm</i> – shows which hash Algorithm is used for link aggregation distribution.
Restrictions	None.

Example usage:

To display Link Aggregation configuration:

ES-1210-28/ME:5# show link_aggregation

Command: show link_aggregation

LA Module : Disable

DES-1210-28/ME:5#

BASIC IP COMMANDS

The Basic IP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config ipif System	[dhcp dhcp_option12 {clear_hostname hostname <hostname 63>} ipaddress <network_address> gateway <ipaddr>] state [enable disable]
show ipif	

Each command is listed in detail, as follows:

config ipif System	
Purpose	To configure the System IP interface.
Syntax	config ipif System [dhcp dhcp_option12 {clear_hostname hostname <hostname 63>} ipaddress <network_address> gateway <ipaddr>] state [enable disable]
Description	The config ipif System command configures the System IP interface on the Switch.
Parameters	<p><i>system</i> – The IP interface name to be configured. The default IP Interface name on the Switch is 'System'. All IP interface configurations done are executed through this interface name.</p> <p><i>dhcp</i> – Specifies the DHCP protocol for the assignment of an IP address to the Switch to use for the DHCP Protocol.</p> <p><i>hostname <hostname 63></i> – Specifies the host name of DHCP.</p> <p><i>ipaddress <network_address></i> – IP address and netmask of the IP interface to be created. The address and mask information may be specified by using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/16).</p> <p><i>gateway <ipaddr></i> – IP address of gateway to be created.</p> <p><i>state [enable disable]</i> – Enables or disables the IP interface.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the IP interface System:

```
DES-1210-28/ME:5# config ipif System dhcp state disable
Command: config ipif System dhcp state disable

% The IP setting mode change to DHCP will cause CLI disconnect.

Success.
DES-1210-28/ME:5#
```

show ipif

Purpose	To display the configuration of an IP interface on the Switch.
Syntax	show ipif
Description	The show ipif command displays the configuration of an IP interface on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display IP interface settings:

```
DES-1210-28/ME:5# show ipif
Command: show ipif

IP Setting Mode       : DHCP
IP Address            : 0.0.0.0
Subnet Mask           : 0.0.0.0
Default Gateway       : 0.0.0.0
DHCP Option12 State   : Disabled
DHCP Option12 Host Name : DES-1210-28/ME

DES-1210-28/ME:5#
```


BPDU ATTACK PROTECTION COMMANDS

The BPDU Attack Protection commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config bpdu_protection ports	[<portlist> all] [state [enable disable] mode [drop block shutdown]]
config bpdu_protection recovery_timer	[<sec 60-1000000> infinite]
config bpdu_protection	[trap log] [none attack_detected attack_cleared both]
enable bpdu_protection	
disable bpdu_protection	
show bpdu_protection	

Each command is listed in detail, as follows:

config bpdu_protection ports	
Purpose	Used to configure the BPDU Attack Protection state and mode of a port.
Syntax	config bpdu_protection ports [<portlist> all] [state [enable disable] mode [drop block shutdown]]
Description	<p>The config bpdu_protection ports command is used to setup the BPDU Attack Protection function for the ports on the switch.</p> <p>The config bpdu_protection ports command is used to configure the BPDU protection function for ports on the Switch. There are two states of BPDU attack protection function; the normal state and the under attack state. The under attack state has three modes: drop, block, and shutdown modes. A BPDU attack protection enabled port will enter under attack state when it receives an STP BPDU frame, then take action based on the configuration mode. BPDU attack protection can ONLY be used for ports that do not have STP enabled.</p> <p>STP for ports and BPDU attack protection on ports are not compatible. Furthermore BPDU attack protection enabled on a port effectively disables all STP function on the port. Keep in mind the following points regarding this:</p> <p>BPDU attack protection has a higher priority than STP BPDU forwarding (i.e. the fbpdu setting of the config stp command is enabled) when determining how to handle BPDU. That is, when fbpdu is enabled to forward STP BPDU frames AND the BPDU attack protection function is enabled, the port will not forward STP BPDU frames.</p> <p>BPDU attack protection has a higher priority than BPDU tunnel port setting (i.e. config bpdu_tunnel ports command) when determining</p>

	<p>how to handle BPDU. That is, when BPDU tunneling is enabled on a port AND the BPDU attack protection function is enabled, then BPDU tunneling is effectively disabled on the port.</p>
Parameters	<p><i><portlist></i> – Specifies a range of ports to be configured.</p> <p><i>all</i> – Specifies all ports to be configured.</p> <p><i>state [enable disable]</i> – Enable or disable the state of BPDU Attack Protection. The default state is disabled.</p> <p><i>mode</i> – Specifies the BPDU Attack Protection mode. The modes are included:</p> <p><i>drop</i> – Will drop all RX BPDU packets when the port enters under attack state.</p> <p><i>block</i> – Will drop all RX packets (include BPDU and normal packets) when the port enters under attack state.</p> <p><i>shutdown</i> – Will shut down the port when the port enters the under attack state.</p> <p>The RX BPDU Attack Protection takes effect only when the port enters under attack state while in drop and block mode.</p>
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To set the BPDU attack protection port state to enable and drop mode:

```
DES-1210-28/ME:5# config bpdu_protection ports 1 state enable mode drop
Command: config bpdu_protection ports 1 state enable mode drop
```

Success !

```
DES-1210-28/ME:5#
```

config bpdu_protection recovery_timer

Purpose	Used to configure the BPDU Attack Protection recovery timer.
Syntax	config bpdu_protection recovery_timer [<sec 60-1000000> infinite]
Description	The config bpdu_protection recovery_timer command is used to configure the auto-recovery timer. To manually recover the port, the user needs to disable and re-enable the port.
Parameters	<p><i><sec 60-1000000></i> – Specifies the recovery timer. The default value of recovery timer is 60.</p> <p><i>infinite</i> – The port will not be auto recovered.</p>
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To configure the BPDU Attack Protection recovery timer to 120 second for the entire switch:

```
DES-1210-28/ME:5# config bpdu_protection recovery_timer 120
Command: config bpdu_protection recovery_timer 120
```

Success!

```
DES-1210-28/ME:5#
```

config bpdu_protection

Purpose	Used to configure trap and log settings for BPDU attack protection events.
Syntax	config bpdu_protection [trap log] [none attack_detected attack_cleared both]
Description	The config bpdu_protection command to configure the trap and log state for BPDU attack protection and specify the type of event sent or logged.
Parameters	<p><i>trap</i> – Specifies the trap state. The default state is both trap and log.</p> <p><i>log</i> – Specifies the log state. The default state is both trap and log.</p> <p><i>none</i> – Specifies that events will not be logged or trapped for both cases.</p> <p><i>attack_detected</i> – Specifies that events will be logged or trapped when a BPDU attack is detected.</p> <p><i>attack_cleared</i> – Specifies that events will be logged or trapped when the BPDU attack is cleared.</p> <p><i>both</i> – Specifies that events will be logged or trapped for both cases. The default setting for log is both and for trap is none.</p>
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To configure the BPDU Attack Protection recovery timer to 120 second for the entire switch:

```
DES-1210-28/ME:5# config bpdu_protection trap both
```

```
Command: config bpdu_protection trap both
```

```
Success!
```

```
DES-1210-28/ME:5#
```

enable bpdu_protection

Purpose	Used to globally enable BPDU attack protection on the Switch.
Syntax	enable bpdu_protection
Description	<p>The enable bpdu_protection command is used to globally enable BPDU attack protection on the Switch.</p> <p>The BPDU Attack Protection function and Spanning Tree Protocol for ports are mutually exclusive. When the STP function is enabled on a particular port, BPDU Attack Protection cannot be enabled.</p>
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To enable BPDU attack protection on the entire Switch:

```
DES-1210-28/ME:5# enable bpdu_protection
```

```
Command: enable bpdu_protection
```

```
Success!
```

```
DES-1210-28/ME:5#
```

disable bpdu_protection

Purpose	Used to globally disable BPDU attack protection on the Switch.
Syntax	disable bpdu_protection
Description	The disable bpdu_protection command is Use this to disable BPDU attack protection on the entire Switch. Note that if BPDU attack protection is disabled globally, it will also be disabled for ports regardless of the config bpdu_protection ports settings.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable BPDU attack protection on the entire Switch:

```
DES-1210-28/ME:5# disable bpdu_protection
```

```
Command: disable bpdu_protection
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show bpdu_protection

Purpose	Used to display BPDU attack protection settings on the Switch.
Syntax	show bpdu_protection {ports <portlist>}
Description	The show bpdu_protection command is used to view the global or per port BPDU attack protection configuration.
Parameters	<i>ports</i> – Specify to view the BPDU attack protection port configuration. <i><portlist></i> – Specify the ports to display. If none is specified, all ports BPDU attack protection configuration will be listed.
Restrictions	None.

Example usage:

To display global settings for BPDU protection:

DES-1210-28/ME:5# show bpdu_protection

Command: show bpdu_protection

BPDU Protection Global Settings

BPDU Protection Status : Disabled
BPDU Protection Recover Time : 60 seconds
BPDU Protection Trap State : none
BPDU Protection Log State : none

DES-1210-28/ME:5#

MAC NOTIFICATION COMMANDS

The IGMP Snooping commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable mac_notification	
disable mac_notification	
config mac_notification	[interval <int 1-2147483647> historysize <int 1-500>]
config mac_notification ports	[<portlist> all] [enable disable]
show mac_notification	
show mac_notification ports	{<portlist>}

Each command is listed in detail, as follows:

enable mac_notification

Purpose	Used to enable global MAC address table notification on the Switch.
Syntax	enable mac_notification
Description	The enable mac_notification command is used to enable MAC address notification without changing configuration.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To enable MAC notification without changing basic configuration:

```
DES-1210-28/ME:5# enable mac_notification
Command: enable mac_notification

Success.

DES-1210-28/ME:5#
```

disable mac_notification

Purpose	Used to disable global MAC address table notification on the Switch.
Syntax	disable mac_notification
Description	The disable mac_notification command is used to disable MAC

	address notification without changing configuration.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To disable MAC notification without changing basic configuration:

```
DES-1210-28/ME:5# disable mac_notification
Command: disable mac_notification

Success.

DES-1210-28/ME:5#
```

config mac_notification

Purpose	Used to configure MAC address notification.
Syntax	config mac_notification [interval <int 1-2147483647> historysize <int 1-500>]
Description	The config mac_notification command is used to monitor MAC addresses learned and entered into the FDB.
Parameters	<i>interval</i> <int 1-2147483647> – The time in seconds between notifications. The user may choose an interval between 1 and 2147483647 seconds. <i>historysize</i> <1-500> – The maximum number of entries listed in the history log used for notification.
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To configure the Switch's MAC address table notification global settings:

```
DES-1210-28/ME:5# config mac_notification interval 1
Command: config mac_notification interval 1

Success.

DES-1210-28/ME:5#
```

config mac_notification ports

Purpose	Used to configure MAC address notification status settings.
Syntax	config mac_notification ports [<portlist> all] [enable disable]
Description	The config mac_notification ports command is used to monitor MAC addresses learned and entered into the FDB.
Parameters	<portlist> – Specifies a port or range of ports to be configured. <i>all</i> – Entering this command will set all ports on the system. <i>[enable disable]</i> – These commands will enable or disable MAC address table notification on the Switch.
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To enable port 7 for MAC address table notification:

```
DES-1210-28/ME:5# config mac_notification ports 7 enable
Command: config mac_notification ports 7 enable

Success.

DES-1210-28/ME:5#
```

show mac_notification

Purpose	Used to display the Switch's MAC address table notification global settings.
Syntax	show mac_notification
Description	The show mac_notification command is used to display the Switch's MAC address table notification global settings.
Parameters	None.
Restrictions	None.

Example usage:

To view the Switch's MAC address table notification global settings:

```
DES-1210-28/ME:5# show mac_notification
Command: show mac_notification

Global Mac Notification Settings

State          : Enabled
Interval       : 1
History Size   : 1
DES-1210-28/ME:5#
```

show mac_notification ports

Purpose	Used to display the Switch's MAC address table notification status settings.
Syntax	show mac_notification ports {<portlist>}
Description	The show mac_notification ports command is used to display the Switch's MAC address table notification status settings.
Parameters	<portlist> – Specify a port or group of ports to be viewed. Entering this command without the parameter will display the MAC notification table for all ports.
Restrictions	None.

Example usage:

To display all port's MAC address table notification status settings:

```
DES-1210-28/ME:5# show mac_notification ports 1-5
Command: show mac_notification ports 1-5
```


Port	MAC Address Table Notification State
1	Disabled
2	Disabled
3	Disabled
4	Disabled
5	Disabled

DES-1210-28/ME:5#

IGMP SNOOPING COMMANDS

The IGMP Snooping commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config igmp_snooping	[vlan_name <string 20> vlanid <vidlist> all] [host_timeout <sec 130-153025> router_timeout <sec 60-600> leave_timer <sec 1-25> fast_leave [enable disable] state [enable disable]]
config igmp_snooping querier	[vlan_name <string 20> vlanid <vidlist> all] state [enable disable] {querier_version [IGMPv2 IGMPv3]}
config igmp_snooping querier_selection	[vlan_name <string 20> vlanid <vidlist> all] state [enable disable]
config igmp_snooping querier_interval	<integer 60-600>
config igmp_snooping robustness_variable	<integer 2-255>
create igmp_snooping multicast_vlan	<vlan_name 32> <vlanid 2-4094>
config igmp_snooping multicast_vlan	<vlan_name 32> [add delete] [member_port <portlist> source_port <portlist> tag_member_port <portlist>] state [enable disable] {replace_source_ip [none <ipaddr>]}
delete igmp_snooping multicast_vlan	<string 32>
config igmp_snooping multicast_vlan_group	<vlan_name 32> [add delete] <ipaddr>
config igmp_snooping data_driven_learning	[all vlan_name <string 20> vlanid <vidlist>] [enable disable] {aged_out}
config igmp_snooping data_driven_learning	max_learned_entry <integer 1-256>
clear igmp_snooping data_driven_group	[all vlan_name <vlan_name 20> vlanid <integer 1-4094>] [all MCGroupAddr <ipaddr>]
config igmp_snooping max_response_time	<integer 10-25>
config router_ports	[vlan_name <string 20> vlanid <vidlist> all] [add delete] <portlist>
config router_ports_forbidden	[vlan_name <string 20> vlanid <vidlist> all] [add delete] <portlist>
config igmp access_authentication ports	[<portlist> all] state [enable disable]
show igmp access_authentication ports	[<portlist> all]

Command	Parameter
enable igmp_snooping	{multicast_vlan}
disable igmp_snooping	{multicast_vlan}
show igmp_snooping	{vlan <vlan_name 20> vlanid <vidlist> multicast_vlan <vlan_name 32> multicast_vlan_group <vlan_name 32>}
show igmp_snooping group	[all vlan_name <string 20> vlanid <vidlist>] {data_driven}
show igmp_snooping forwarding	{vlan <vlan_name 20>}
show igmp_snooping host	
show router_port	{vlan <vlan_name 20> static dynamic forbidden}

Each command is listed in detail, as follows:

config igmp_snooping	
Purpose	To configure IGMP snooping on the Switch.
Syntax	config igmp_snooping [vlan_name <string 20> vlanid <vidlist> all] [host_timeout <sec 130-153025> router_timeout <sec 60-600> leave_timer <sec 1-25> fast_leave [enable disable] state [enable disable]]
Description	The config igmp_snooping command configures IGMP snooping on the Switch.
Parameters	<p><i>vlan_name <string 20></i> – The name of the VLAN for which IGMP snooping is to be configured.</p> <p><i>vlanid <vidlist></i> – The VLAN id for which IGMP snooping is to be configured.</p> <p><i>all</i> – Specifies all VLAN for which IGMP snooping is to be configured.</p> <p><i>host_timeout <sec 130-153025></i> – Specifies the maximum amount of time a host can be a member of a multicast group without the Switch receiving a host membership report. The default is 260 seconds.</p> <p><i>router_timeout <sec 60-600></i> – Specifies the maximum amount of time a route can be a member of a multicast group without the Switch receiving a host membership report.</p> <p><i>leave_timer <sec 1-25></i> – Leave timer. The default is 10 seconds.</p> <p><i>fast_leave [enable disable]</i> – Enables or disables the fast leave.</p> <p><i>state [enable disable]</i> – Enables or disables IGMP snooping for the specified VLAN.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping:

```
DES-1210-28/ME:5# config igmp_snooping default host_timeout 250 state enable
```

```
Command: config igmp_snooping default host_timeout 250 state enable
```

```
Success !
DES-1210-28/ME:5#
```

config igmp_snooping querier

Purpose	To configure IGMP snooping querier on the Switch.
Syntax	config igmp_snooping querier [vlan_name <string 20> vlanid <vidlist> all] state [enable disable] {querier_version [IGMPv2 IGMPv3]}
Description	The config igmp_snooping querier command enables IGMP snooping querier on a specific VLAN.
Parameters	<p><i>vlan_name</i> <string 20> – The name of the VLAN for which IGMP snooping is to be configured. Up to 20 characters can be used.</p> <p><i>vlanid</i> <vidlist> – The VLAN id for which IGMP snooping is to be configured.</p> <p>all – Specifies all VLAN for which IGMP snooping is to be configured.</p> <p><i>state</i> [enable disable] – Enables/Disables IGMP Snooping Querier.</p> <p><i>querier_version</i> [IGMPv2 IGMPv3] – Specifies the IGMP Querier version on the VLAN.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping:

```
DES-1210-28/ME:5# config igmp_snooping querier vlanid 2 state enable
Command: config igmp_snooping querier vlanid 2 state enable
```

```
Success !
DES-1210-28/ME:5#
```

config igmp_snooping querier_selection

Purpose	To configure IGMP snooping querier selection on the Switch.
Syntax	config igmp_snooping querier_selection [vlan_name <string 20> vlanid <vidlist> all] state [enable disable]
Description	The config igmp_snooping querier_selection command configures IGMP snooping querier selection on a specific VLAN.
Parameters	<p><i>vlan_name</i> <string 20> – The name of the VLAN for which IGMP snooping is to be configured. Up to 20 characters can be used.</p> <p><i>vlanid</i> <vidlist> – The VLAN id for which IGMP snooping is to be configured.</p> <p>all – Specifies all VLAN for which IGMP snooping is to be configured.</p> <p><i>state</i> [enable disable] – Enables/Disables IGMP Snooping Querier.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping querier selection:

```
DES-1210-28/ME:5# config igmp_snooping querier_selection vlanid 2 disable
Command: config igmp_snooping querier_selection vlanid 2 disable
```

```
Success !
DES-1210-28/ME:5#
```

config igmp_snooping querier_interval

Purpose	To configure IGMP snooping querier interval on the Switch.
Syntax	config igmp_snooping querier_interval <integer 60-600>
Description	The config igmp_snooping querier_interval command configures IGMP snooping querier interval on the Switch.
Parameters	<integer 60-600> – The IGMP snooping querier interval of IGMP snooping is to be configured.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping querier interval:

```
DES-1210-28/ME:5# config igmp_snooping query_interval 65
Command: config igmp_snooping query_interval 65
```

```
Success !
DES-1210-28/ME:5#
```

config igmp_snooping robustness_variable

Purpose	To configure IGMP snooping robustness variable on the Switch.
Syntax	config igmp_snooping robustness_variable <integer 2-255>
Description	The config igmp_snooping robustness_variable command configures IGMP snooping robustness variable on the Switch.
Parameters	<integer 2-255> – The IGMP snooping robustness variable of IGMP snooping is to be configured.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping robustness variable:

```
DES-1210-28/ME:5# config igmp_snooping robustness_variable 10
Command: config igmp_snooping robustness_variable 10
```

```
Success !
DES-1210-28/ME:5#
```

create igmp_snooping multicast_vlan

Purpose	To create an IGMP snooping multicast VLAN on the Switch.
Syntax	create igmp_snooping multicast_vlan <vlan_name 32> <vlanid 2-4094>
Description	The create igmp_snooping multicast_vlan command creates an IGMP snooping multicast VLAN on the Switch.
Parameters	<i>vlan <vlan_name 32></i> – The name of the VLAN for which IGMP snooping is to be created. Up to 32 characters can be used. <i><vlanid 2-4092></i> – The ID of the VLAN for which IGMP snooping is to be created. The range is from 2 to 4094.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To create a igmp snooping multicast VLAN:

```
DES-1210-28/ME:5# create igmp_snooping multicast_vlan mvln2 5
Command: create igmp_snooping multicast_vlan mvln2 5
```

Success!

```
DES-1210-28/ME:5#
```

config igmp_snooping multicast_vlan

Purpose	To configure IGMP snooping multicast VLAN on the Switch.
Syntax	config igmp_snooping multicast_vlan <vlan_name 32> [add delete] [member_port <portlist> source_port <portlist> tag_member_port <portlist>] state [enable disable] {replace_source_ip [none <ipaddr>]}
Description	The config igmp_snooping multicast_vlan command enables IGMP snooping multicast VLAN on the Switch.
Parameters	<i>vlan <vlan_name 32></i> – The name of the VLAN for which IGMP snooping is to be configured. Up to 32 characters can be used. <i>[add delete]</i> – Add or delete the specified multicast VLAN of IGMP snooping. <i>member_port <portlist></i> – Specifies a port or a range of ports to be the member port for the multicast VLAN of IGMP snooping. <i>source_port <portlist></i> – Specifies a port or a range of ports to be the source port for the multicast VLAN of IGMP snooping. <i>tag_member_port <portlist></i> – Specifies a port or a range of ports to be the tagged port for the multicast VLAN of IGMP snooping. <i>state [enable disable]</i> – Enables/Disables IGMP Snooping multicast VLAN. <i>replace_source_ip [none <ipaddr>]</i> –
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping multicast VLAN:

```
DES-1210-28/ME:5# config igmp_snooping multicast_vlan default state enable
```

```
Command: config igmp_snooping multicast_vlan default state enable
```

```
Success!
```

```
DES-1210-28/ME:5#
```

delete igmp_snooping multicast_vlan

Purpose	To remove an IGMP snooping multicast VLAN on the Switch.
Syntax	delete igmp_snooping multicast_vlan <string 32>
Description	The delete igmp_snooping multicast_vlan command removes IGMP snooping multicast VLAN on the Switch.
Parameters	<string 32> – Specify the multicast vlan name to be removed on the Switch.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To remove the igmp snooping multicast VLAN 'rd1':

```
DES-1210-28/ME:5# delete igmp_snooping multicast_vlan rd1
```

```
Command: delete igmp_snooping multicast_vlan rd1
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config igmp_snooping multicast_vlan_group

Purpose	To specify that IGMP snooping is to be configured for multicast vlan groups on the Switch.
Syntax	config igmp_snooping multicast_vlan_group <vlan_name 32> [add delete] <ipaddr>
Description	The config igmp_snooping multicast_vlan_group command specifies an IGMP snooping multicast VLAN group on the Switch.
Parameters	<i>vlan <vlan_name 32></i> – The name of the VLAN for which IGMP snooping is to be configured. Up to 32 characters can be used. <i>[add delete]</i> – Specify whether to add or delete ports defined in the following parameter <ipaddr>. <i><ipaddr></i> – Specify the IP address to be configured with the IGMP snooping multicast VLAN group.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping multicast VLAN:

```
DES-1210-28/ME:5# config igmp_snooping multicast_vlan_group default add 10.90.90.99
```

```
Command: config igmp_snooping multicast_vlan_group default add 10.90.90.99
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config igmp_snooping data_driven_learning

Purpose	Used to configure the data driven learning of an IGMP snooping group.
Syntax	config igmp_snooping data_driven_learning [all vlan_name <string 20> vlanid <vidlist>] [enable disable] {aged_out}}
Description	The config igmp_snooping data_driven_learning command configures the IGMP snooping data driven learning on the Switch.
Parameters	<p><i>all</i> – Specifies that all VLANs configured on the Switch will be configured.</p> <p><i>max_learned_entry</i> <integer 1-256> – Specify the max learned entry, the range is from 1 to 256.</p> <p><i>vlan_name</i> <string 20> – The name of the VLAN for which IGMP snooping is to be configured. Up to 20 characters can be used.</p> <p><i>vlanid</i> <vidlist> – Specify the vlan id of the IGMP snooping data driven group on the Switch.</p> <p>[enable disable] – Enables or Disables IGMP snooping data driven learning.</p> <p>{aged_out} – Specifies the age out time to be enabled or disabled of IGMP snooping data driven learning.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping data driven learning on the Switch:

```
DES-1210-28/ME:5# config igmp_snooping data_driven_learning all disable
Command: config igmp_snooping data_driven_learning all disable

Success !
DES-1210-28/ME:5#
```

config igmp_snooping data_driven_learning

Purpose	Used to configure the data driven learning of an IGMP snooping group.
Syntax	config igmp_snooping data_driven_learning max_learned_entry <integer 1-256>
Description	The config igmp_snooping data_driven_learning command configures the max learned entry of IGMP snooping data driven learning on the Switch.
Parameters	<i>max_learned_entry</i> <integer 1-256> – Specify the max learned entry, the range is from 1 to 256.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the igmp snooping data driven learning on the Switch:

```
DES-1210-28/ME:5# config igmp_snooping data_driven_learning
max_learned_entry 10
Command: config igmp_snooping data_driven_learning max_learned_entry 10
```



```
Success !
DES-1210-28/ME:5#
```

clear igmp_snooping data_driven_group

Purpose	To clear the IGMP snooping group learned by data drive.
Syntax	clear igmp_snooping data_driven_group [all <i>vlan_name</i> < <i>vlan_name</i> 20> <i>vlanid</i> < <i>integer</i> 1-4094>] [all MCGroupAddr < <i>ipaddr</i> >]
Description	The config igmp_snooping data_driven_learning command is used to delete the IGMP snooping group learned by data drive. Note that this commands is currently only for layer 2 switches.
Parameters	<i>all</i> – Delete all data driven entries. <i>vlan_name</i> < <i>vlan_name</i> 20> – The name of the VLAN for which IGMP snooping is to be configured. Up to 20 characters can be used. <i>vlanid</i> < <i>integer</i> 1-4094> – Specify the vlan id of the IGMP snooping data driven group on the Switch. < <i>ipaddr</i> > - Specifies the IP address
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To clear the igmp snooping data driven group on the Switch:

```
DES-1210-28/ME:5# clear igmp_snooping data_driven_group all all
Command: clear igmp_snooping data_driven_group all all
```

```
Success !
DES-1210-28/ME:5#
```

config igmp_snooping max_response_time

Purpose	To configure max response time.
Syntax	config igmp_snooping max_response_time < <i>integer</i> 10-25>
Description	The config igmp_snooping max_response_time command configures the max response time for IGMP snooping on the Switch.
Parameters	< <i>integer</i> 10-25> – Specify the max response time for IGMP snooping on the Switch.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the max response time for IGMP snooping:

```
DES-1210-28/ME:5# config igmp_snooping max_response_time 12
Command: config igmp_snooping max_response_time 12
```

```
Success !
DES-1210-28/ME:5#
```

config router_ports

Purpose	To configure ports as router ports.
Syntax	config router_ports [vlan_name <string 20> vlanid <vidlist> all] [add delete] <portlist>
Description	The config router_ports command designates a range of ports as being connected to multicast-enabled routers. This ensures all packets with such a router as its destination will reach the multicast-enabled router – regardless of protocol, etc.
Parameters	<p><i>vlan_name</i> <string 20> – The name of the VLAN on which the router port resides. Up to 20 characters can be used.</p> <p>vlanid <vidlist> – The VLAN id of the VLAN on which the router port resides.</p> <p>all – Specifies all ports on the Switch to be configured.</p> <p>[add delete] – Specifies whether to add or delete ports defined in the following parameter <portlist>, to the router port function.</p> <p><portlist> – A port or range of ports that will be configured as router ports.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To delete the static router port:

```
DES-1210-28/ME:5# config router_ports vlanid 2 delete 2
Command: config router_ports vlanid 2 delete 2
```

```
Success !
DES-1210-28/ME:5#
```

config router_ports_forbidden

Purpose	To deny ports becoming router ports.
Syntax	config router_ports_forbidden [vlan_name <string 20> vlanid <vidlist> all] [add delete] <portlist>
Description	The config router_ports_forbidden command denies a range of ports access to multicast-enabled routers. This ensures all packets with such a router as its destination will not reach the multicast-enabled router – regardless of protocol, etc.
Parameters	<p><i>vlan_name</i> <string 20> – The name of the VLAN on which the router port resides. Up to 20 characters can be used.</p> <p>vlanid <vidlist> – The VLAN id of the VLAN on which the router port resides.</p> <p>all – Specifies all ports on the Switch to be configured.</p> <p>[add delete] – Specifies whether to deny ports defined in the following parameter <portlist>, to the router port function.</p> <p><portlist> – A port or range of ports that will be denied access as router ports.</p>

Restrictions	Only administrator or operator-level users can issue this command.
--------------	--

Example usage:

To deny router ports:

```
DES-1210-28/ME:5# config router_ports_forbidden vlanid 2 add 10-12
Command: config router_ports_forbidden vlanid 2 add 10-12

Success !
DES-1210-28/ME:5#
```

config igmp access_authentication ports

Purpose	To configure the IGMP access authentication on the Switch.
Syntax	config igmp access_authentication ports [<portlist> all] state [enable disable]
Description	The config igmp access_authentication ports command configures the IGMP access authentication on the Switch.
Parameters	<p><i><portlist></i> – A port or range of ports that will be configured as IGMP access authentication ports.</p> <p><i>all</i> – Specify all ports to be configured as IGMP access authentication ports.</p> <p><i>state[enable disable]</i> – Specifies the state for the port to be disabled or enabled.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure authentication port of IGMP:

```
DES-1210-28/ME:5# config igmp access_authentication ports all state enable
Command: config igmp access_authentication ports all state enable

Success !
DES-1210-28/ME:5#
```

show igmp access_authentication ports

Purpose	To display the IGMP access authentication configuration on the Switch.
Syntax	show igmp access_authentication ports [<portlist> all]
Description	The show igmp access_authentication command displays the IGMP access authentication configuration on the Switch.
Parameters	<p><i>all</i> – Specifies all ports to be displayed.</p> <p><i><portlist></i> – A port or range of ports to be displayed on the Switch.</p>
Restrictions	None.

Example usage:

To display the IGMP access authentication:

```
DES-1210-28/ME:5# show igmp access_authentication ports 1-5
```

```
Command: show igmp access_authentication ports 1-5
```

```
Port  Authentication State
```

```
-----
```

```
1      Disabled
```

```
2      Disabled
```

```
3      Disabled
```

```
4      Disabled
```

```
5      Disabled
```

```
DES-1210-28/ME:5#
```

enable igmp_snooping

Purpose	To enable IGMP snooping on the Switch.
Syntax	enable igmp_snooping {multicast_vlan}
Description	The enable igmp_snooping command enables IGMP snooping on the Switch.
Parameters	<i>{multicast_vlan}</i> – Enables the multicast VLAN for IGMP Snooping on the Switch.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable IGMP snooping on the Switch:

```
DES-1210-28/ME:5# enable igmp_snooping
```

```
Command: enable igmp_snooping
```

```
Success !
```

```
DES-1210-28/ME:5#
```

disable igmp_snooping

Purpose	To disable IGMP snooping on the Switch.
Syntax	disable igmp_snooping {multicast_vlan}
Description	The disable igmp_snooping command disables IGMP snooping on the Switch. IGMP snooping can be disabled only if IP multicast routing is not being used. Disabling IGMP snooping allows all IGMP and IP multicast traffic to flood within a given IP interface.
Parameters	<i>{multicast_vlan}</i> – Disables the multicast VLAN for IGMP Snooping on the Switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable IGMP snooping on the Switch:

```
DES-1210-28/ME:5# disable igmp_snooping
```

```
Command: disable igmp_snooping
```

```
Success !
DES-1210-28/ME:5#
```

show igmp_snooping

Purpose	To show the current status of IGMP snooping on the Switch.
Syntax	show igmp_snooping {vlan <vlan_name 20> vlanid <vidlist> multicast_vlan <vlan_name 32> multicast_vlan_group <vlan_name 32>}
Description	The show igmp_snooping command displays the current IGMP snooping configuration on the Switch.
Parameters	<vlan_name 20> – The name of the VLAN for which IGMP snooping configuration is to be displayed. Up to 20 characters can be used. <vidlist> – The vid of the VLAN for which IGMP snooping configuration is to be displayed.
Restrictions	None.

Example usage:

To show igmp snooping:

```
DES-1210-28/ME:5# show igmp_snooping vlan default
Command: show igmp_snooping vlan default
```

```
IGMP Snooping Global State      : Disable
Multicast Router Only           : Disable
Data Driven Learning Max Entries : 64

VLAN Name                       : default
Query Interval                  : 1
Max Response Time               : 10
Robustness Value                : 2
Last Member Query Interval      : 1
Querier State                   : Disable
Querier Role                    : Non-Querier
Querier Select                  : Disable
Querier IP                     : 10.90.90.90
Querier Expiry Time            : 0
State                           : Enable
Fast Leave                     : Disable
Version                        : 3
Data Driven Learning Aged Out   : Disable
```

```
CTRL+C ESC q Quit SPACE n Next Page ENTER Next Entry a ALL
```

show igmp_snooping group

Purpose	To display the current IGMP snooping group configuration on the Switch.
Syntax	show igmp_snooping group [all vlan_name <string 20> vlanid <vidlist>] {data_driven}
Description	The show igmp_snooping group command displays the current IGMP snooping group configuration on the Switch.
Parameters	<p><i>all</i> – To display all IGMP snooping groups on the Switch.</p> <p><i>vlan_name <string 20></i> – The name of the VLAN for which IGMP snooping group configuration information is to be displayed. Up to 20 characters can be used.</p> <p><i>vlanid <vidlist></i> – The ID of the VLAN for which IGMP snooping group configuration information is to be displayed.</p> <p><i>{data_driven}</i> – Specifies to display the data driven of IGMP snooping group.</p>
Restrictions	None.

Example usage:

To show igmp snooping group:

```
DES-1210-28/ME:5# show igmp_snooping group vlan
default
Command: show igmp_snooping group vlan default

Total Entries : 0

DES-1210-28/ME:5#
Reports      : 1
Port Member  : 3,4

Total Entries : 1

DES-1210-28/ME:5#
```

show igmp_snooping forwarding

Purpose	To display the IGMP snooping forwarding table entries on the Switch.
Syntax	show igmp_snooping forwarding {vlan <vlan_name 20>}
Description	The show igmp_snooping forwarding command displays the current IGMP snooping forwarding table entries currently configured on the Switch.
Parameters	<i><vlan_name 20></i> – The name of the VLAN for which IGMP snooping forwarding table information is to be displayed. Up to 32 characters can be used.
Restrictions	None.

Example usage:

To view the IGMP snooping forwarding table for VLAN 'Trinity':

```
DES-1210-28/ME:5# show igmp_snooping forwarding vlan default
```

Command: show igmp_snooping forwarding vlan default

VLAN Name : Trinity
Multicast group : 224.0.0.2
MAC address : 01-00-5E-00-00-02
Port Member : 3,4
Total Entries : 1

DES-1210-28/ME:5#

show igmp_snooping host

Purpose	To display the IGMP snooping host table entries on the Switch.
Syntax	show igmp_snooping host
Description	The show igmp_snooping host command displays the current IGMP snooping forwarding table entries currently configured on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To view the IGMP snooping host table on the Switch:

```
DES-1210-28/ME:5# show igmp_snooping host
Command: show igmp_snooping host

VLAN ID   Group           Port No   IGMP Host
-----   -
Total Entries : 0

DES-1210-28/ME:5#
```

show router_port

Purpose	To display the currently configured router ports on the Switch.
Syntax	show router_port {vlan <vlan_name 20> static dynamic forbidden}
Description	The show router_port command displays the router ports currently configured on the Switch.
Parameters	<i>vlan <vlan_name 20></i> – The name of the VLAN on which the router port resides. Up to 32 characters can be used. <i>static</i> – Displays router ports that have been statically configured. <i>dynamic</i> – Displays router ports that have been dynamically learned. <i>forbidden</i> – Displays router ports that have been forbidden configured.
Restrictions	None.

Example usage:

To display the router ports.

```
DES-1210-28/ME:5# show router_ports
```

```
Command: show router_ports
```

```
VLAN Name          : default
```

```
Static router port  :
```

```
Dynamic router port :
```

```
Forbidden router port :
```

```
Total Entries : 1
```

```
DES-1210-28/ME:5#
```


LIMITED IP MULTICAST ADDRESS COMMANDS

The 802.1X commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create mcast_filter_profile	profile_id <integer 1-24> profile_name <string 32>
config mcast_filter_profile profile_id	<integer 1-24> [add delete] <ip_addr>
config mcast_filter_profile profile_name	<string 32> [add delete] <ip_addr>
delete mcast_filter_profile	[profile_id<integer 1-24> profile_name <string 20>]
show mcast_filter_profile	{profile_id <integer 1-24> profile_name <string 32>}
config limited_multicast_addr ports	<portlist> {[add delete] [profile_id <integer 1-24> profile_name <string 32>] access [permit deny]}
show limited_multicast_addr	ports <portlist>
config max_mcast_group	<portlist> max_group <integer 1-256>
show max_mcast_group	<portlist>

Each command is listed in detail, as follows:

create mcast_filter_profile	
Purpose	To create multicast filtering profile on the Switch.
Syntax	create mcast_filter_profile profile_id <integer 1-24> profile_name <string 32>
Description	The create mcast_filter_profile command displays the multicast filtering profiles settings.
Parameters	<i>profile_id <integer 1-24></i> - Specify the profile id of multicast filter profile on the Switch. <i>profile_name <string 32></i> - Specify the profile name of multicast filter profile on the Switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create multicast filtering profile on the Switch:

```
DES-1210-28/ME:5# create mcast_filter_profile profile_id 1
profile_name rd2
Command: create mcast_filter_profile profile_id 1 profile_name rd2

Add Profile Success!
DES-1210-28/ME:5#
```

config mcast_filter_profile profile_id

Purpose	To configure multicast filtering profile on the Switch.
Syntax	config mcast_filter_profile profile_id <integer 1-24> [add delete] <ip_addr>
Description	The config mcast_filter_profile command displays the multicast filtering profiles settings.
Parameters	<integer 1-24> - Specify the profile id to be added or deleted for the multicast filter. [add delete] – Add or delete the profile id which user specified. <ip_addr> – Specify the IP address.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure multicast filtering profile on the Switch:

```
DES-1210-28/ME:5# config mcast_filter_profile profile_id 1 add
10.1.47.52
Command: config mcast_filter_profile profile_id 1 add 10.1.47.52

Success!
DES-1210-28/ME:5#
```

config mcast_filter_profile profile_name

Purpose	To configure multicast filtering profile on the Switch.
Syntax	config mcast_filter_profile profile_name <string 32> [add delete] <ip_addr>
Description	The config mcast_filter_profile profile_name command displays the multicast filtering profiles settings.
Parameters	<string 32> - The name of the VLAN on which the MAC address resides. [add delete] – Add or delete the profile id which user specified. <ip_addr> – Specify the IP address.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure multicast filtering profile profile name on the Switch:

```
DES-1210-28/ME:5# config mcast_filter_profile profile_name rd2 add
10.1.1.13
Command: config mcast_filter_profile profile_name rd2 add 10.1.1.13
```

```
DES-1210-28/ME:5#
```

delete mcast_filter_profile

Purpose	To delete an entry in the Switch's forwarding database.
Syntax	delete mcast_filter_profile [profile_id <integer 1-24> profile_name <string 20>]
Description	The delete mcast_filter_profile command deletes a profile in the Switch's multicast forwarding filtering database.
Parameters	<i>profile_id</i> <integer 1-24> - The profile id of the VLAN on which the multicast forwarding filtering database resides. <i>profile_name</i> <string 20> - The name of the VLAN on which the multicast forwarding filtering database resides.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a permanent FDB entry:

```
DES-1210-28/ME:5# delete mcast_filter_profile profile_id 1
Command: delete mcast_filter_profile profile_id 1
```

```
Profile id exist! return SUCCESS
DES-1210-28/ME:5#
```

show mcast_filter_profile

Purpose	To display multicast filtering settings on the Switch.
Syntax	show mcast_filter_profile { profile_id <integer 1-24> profile_name <string 32>}
Description	The show mcast_filter_profile command displays the multicast filtering profiles settings.
Parameters	<i>profile_id</i> <integer 1-24> - Specify the profile id of multicast filter profile to be displayed. <i>profile_name</i> <string 32> - Specify the profile name of multicast filter profile to be displayed.
Restrictions	None.

Example usage:

To show multicast filtering profile settings:

```
DES-1210-28/ME:5# show mcast_filter_profile profile_name rd2
Command: show mcast_filter_profile profile_name rd2
```

```
Profile name exist! return SUCCESS
```

```
Profile ID  Name      Multicast Addresses
-----  -

```

2	rd2
DES-1210-28/ME:5#	

config limited_multicast_addr ports

Purpose	To configure the multicast address filtering function a port.
Syntax	config limited_multicast_addr ports <portlist> {[add delete] [profile_id <integer 1-24> profile_name <string 32>] access [permit deny]}
Description	The config limited_multicast_addr ports command is used to configure the multicast address filtering function on a port. When there are no profiles specified with a port, the limited function is not effective.
Parameters	<p><i><portlist></i> – A port or range of port on which the limited multicast address range to be configured has been assigned.</p> <p><i>add</i> – Add a multicast address profile to a port.</p> <p><i>delete</i> – Delete a multicast address profile to a port.</p> <p><i>profile_id <integer 1-24></i> – A profile ID to be added or deleted from a port.</p> <p><i>profile_name <string 32></i> – A profile name to be added or deleted from a port.</p> <p><i>permit</i> – Specifies that the packet that matches the addresses defined in the profiles will be permitted. The default mode is permit.</p> <p><i>deny</i> – Specifies that the packet matches the addresses defined in the profiles will be denied.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure ports 1 and 3 to set the multicast address profile 2::

```
DES-1210-28/ME:5# config limited_multicast_addr ports 1,3 add profile_id 2
Command: config limited_multicast_addr ports 1,3 add profile_id 2
```

```
Success!
DES-1210-28/ME:5#
```

show limited_multicast_addr

Purpose	Used to show the per-port Limited IP multicast address range.
Syntax	show limited_multicast_addr ports <portlist>
Description	The show limited_multicast_addr command is used to show the per-port Limited IP multicast address range.
Parameters	<i><portlist></i> – Used to show the per-port Limited IP multicast address range.
Restrictions	None.

Example usage:

To show the limited multicast address on ports 1 and 3:

```
DES-1210-28/ME:5# show limited_multicast_addr ports 1,3
Command: show limited_multicast_addr ports 1,3
```

Port : 1

Access : deny

Profile ID	Name	Multicast Addresses
2	rd2	

Port : 3

Access : deny

Profile ID	Name	Multicast Addresses
2	rd2	
3		

DES-1210-28/ME:5#

config max_mcast_group ports

Purpose	Used to configure the maximum number of multicast groups that a port can join.
Syntax	config max_mcast_group ports <portlist> max_group <integer 1-256>
Description	The show limited_multicast_addr command is used to configure the maximum number of multicast groups that a port can join.
Parameters	<i><portlist></i> – A range of ports to configure the maximum multicast group. <i>max_group <integer 1-256></i> – Specifies the maximum number of multicast groups. The range is from 1 to 256.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the maximum multicast address groups on ports 1 and 3 as 100:

```
DES-1210-28/ME:5# config max_mcast_group ports 1,3 max_group 100
Command: config max_mcast_group ports 1,3 max_group 100
```

Success!

DES-1210-28/ME:5#

show max_mcast_group ports

Purpose	To display maximum multicast group ports on the Switch.
Syntax	show max_mcast_group ports <portlist>
Description	The show max_mcast_group ports command displays the multicast filtering profiles settings.
Parameters	<i><portlist></i> - Specify a port or range of ports to be displayed.
Restrictions	None.

Example usage:

To show maximum multicast group port 12 settings:

```
DES-1210-28/ME:5# show max_mcast_group ports 12
Command: show max_mcast_group ports 12

Port  MaxMcastGroup
----  -
12    256
DES-1210-28/ME:5#
```

802.1X COMMANDS

The 802.1X commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable 802.1x	
disable 802.1x	
config 802.1x feap	[enable disable]
show 802.1x auth_state	{ports <portlist>}
show 802.1x feap status	
show 802.1x auth_configuration	{ports <portlist>}
config 802.1x auth_parameter ports	<portlist> [default { port_control [force_unauth auto force_auth] quiet_period <sec 0-65535> tx_period <sec 1-65535> supp_timeout <sec 1-65535> server_timeout <sec 1-65535> max_req <value 1-10> reauth_period <sec 1-65535> enable_reauth [enable disable] direction [both in]]}
config 802.1x init	port_based ports [<portlist> all]
config 802.1x auth_protocol	[radius_eap local]
config 802.1x reauth	port_based ports [<portlist> all]
config radius add	<server_index 1-3> <server_ip> [key <passwd 32>] {default auth_port <udp_port_number 1-65535> acct_port <udp_port_number 1-65535>}
config radius delete	<server_index 1-3>
config radius	<server_index 1-3> { key <passwd 32> auth_port <udp_port_number 1-65535> acct_port <udp_port_number 1-65535> ipaddress <server_ip> retransmit <int 1-255> timeout <int 1-255>}
show radius	
config 802.1x auth_mode	[port_based mac_based]
create 802.1x guest vlan	<vlan_name 32>
delete 802.1x guest vlan	<vlan_name 32>
config 802.1x guest_vlan ports	[<portlist> all] state [enable disable]
show 802.1x guest_vlan	

Command	Parameter
create 802.1x user	<username 15>
show 802.1x user	
delete 802.1x user	<username 15>
config 802.1x capability ports	[<portlist> all] [authenticator none]

Each command is listed in detail, as follows:

enable 802.1x

Purpose	To enable the 802.1x server on the Switch.
Syntax	enable 802.1x
Description	The enable 802.1x command enables the 802.1x Port-based Network Access control server application on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable 802.1x switch wide:

```
DES-1210-28/ME:5# enable 802.1x
Command: enable 802.1x

Success!
DES-1210-28/ME:5#
```

disable 802.1x

Purpose	To disable the 802.1x server on the Switch.
Syntax	disable 802.1x
Description	The disable 802.1x command disables the 802.1x Port-based Network Access control server application on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable 802.1x on the Switch:

```
DES-1210-28/ME:5# disable 802.1x
Command: disable 802.1x

Success!
DES-1210-28/ME:5#
```


show 802.1x

Purpose	To display the 802.1x server information on the Switch.
Syntax	show 802.1x
Description	The show 802.1x command displays the 802.1x Port-based Network Access control server application on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display 802.1x on the Switch:

```
DES-1210-28/ME:5# show 802.1x
Command: show 802.1x

802.1X           : Enable
Authentication Mode : Port_base
Authentication Method : Local

Success!
DES-1210-28/ME:5#
```

config 802.1x feap

Purpose	To configure the 802.1x feap on the Switch.
Syntax	config 802.1x feap [enable disable]
Description	The config 802.1x command configure the 802.1x feap on the Switch.
Parameters	<i>[enable disable]</i> – enables or disables the 802.1x feap on the switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure 802.1x feap on the Switch:

```
DES-1210-28/ME:5# config 802.1x feap enable
Command: config 802.1x feap enable

Success.
DES-1210-28/ME:5#
```

show 802.1x auth_state

Purpose	To display the current authentication state of the 802.1x server on the Switch.
Syntax	show 802.1x auth_state {ports <portlist>}
Description	The show 802.1x auth_state command displays the current 802.1x authentication state of the specified ports of the Port-based Network Access Control server application on the Switch. The following details are displayed:

	<p>Port number – Shows the physical port number on the Switch.</p> <p>Auth PAE State: Initialize / Disconnected / Connecting / Authenticating / Authenticated / Held / ForceAuth / ForceUnauth – Shows the current state of the Authenticator PAE.</p> <p>Backend State: Request / Response / Fail / Idle / Initialize / Success / Timeout – Shows the current state of the Backend Authenticator.</p> <p>Port Status: Authorized / Unauthorized – Shows the result of the authentication process. Authorized means that the user was authenticated, and can access the network. Unauthorized means that the user was not authenticated, and cannot access the network.</p>
Parameters	<i>ports <portlist></i> – A port or range of ports whose settings are to be displayed.
Restrictions	None.

Example usage:

To display the 802.1x authentication states for port 1~5 (stacking disabled) for Port-based 802.1x:

```
DES-1210-28/ME:5# show 802.1x auth_state ports 1-5
Command: show 802.1x auth_state ports 1-5
```

Port	Auth PAE State	Backend State	Port Status
1	ForceAuth	Success	Authorized
2	ForceAuth	Success	Authorized
3	ForceAuth	Success	Authorized
4	ForceAuth	Success	Authorized
5	ForceAuth	Success	Authorized

```
DES-1210-28/ME:5#
```

show 802.1x feap status

Purpose	To display the current feap states of the 802.1x on the Switch.
Syntax	show 802.1x feap status
Description	The show 802.1x feap status command displays the current 802.1x feap status on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the 802.1x feap states:

```
DES-1210-28/ME:5# show 802.1x feap status
Command: show 802.1x feap status
```

```
PNAC control packet (eap) is forwarding....
```

```
Success!
```

```
DES-1210-28/ME:5#
```

show 802.1x auth_configuration

Purpose	To display the current configuration of the 802.1x server on the Switch.
Syntax	show 802.1x auth_configuration {ports <portlist>}
Description	<p>The show 802.1x auth_configuration command displays the current configuration of the 802.1x Port-based Network Access Control server application on the Switch.</p> <p>The following details are displayed:</p> <p><i>802.1x</i>: Enabled/Disabled – Shows the current status of 802.1x functions on the Switch.</p> <p><i>Authentication Mode</i>: Port-based/Mac-based/None – Shows the 802.1x authorization mode.</p> <p><i>Authentication Method</i>: Remote/none – Shows the type of authentication protocol suite in use between the Switch and a RADIUS server.</p> <p><i>Port number</i> : Shows the physical port number on the Switch.</p> <p><i>AdminCrDir</i>: Both/In – Shows whether a controlled Port that is unauthorized will exert control over communication in both receiving and transmitting directions, or just the receiving direction.</p> <p><i>OpenCrDir</i>: Both/In – Shows whether a controlled Port that is unauthorized will exert control over communication in both receiving and transmitting directions, or just the receiving direction.</p> <p><i>Port Control</i>: ForceAuth/ForceUnauth/Auto – Shows the administrative control over the port's authorization status. ForceAuth forces the Authenticator of the port to become Authorized. ForceUnauth forces the port to become Unauthorized.</p> <p><i>QuietPeriod</i> : Shows the time interval between authentication failure and the start of a new authentication attempt.</p> <p><i>TxPeriod</i> : Shows the time to wait for a response from a supplicant (user) to send EAP Request/Identity packets.</p> <p><i>SuppTimeout</i> : Shows the time to wait for a response from a supplicant (user) for all EAP packets, except for the Request/Identity packets.</p> <p><i>ServerTimeout</i> : Shows the length of time to wait for a response from a RADIUS server.</p> <p><i>MaxReq</i> : Shows the maximum number of times to retry sending packets to the supplicant.</p> <p><i>ReAuthPeriod</i> : Shows the time interval between successive reauthentications.</p> <p><i>ReAuthenticate</i>: true/false – Shows whether or not to reauthenticate.</p>
Parameters	<i>ports <portlist></i> – Specifies a port or range of ports to be viewed.
Restrictions	None.

Example usage:

To display the 802.1x configurations of port 2:

```
DES-1210-28/ME:5# show 802.1x auth_configuration ports 2
Command: show 802.1x auth_configuration ports 2

Authentication Mode   : Port_base

Port number          : 2
```

```

Capability      : none
AdminCrIDir   : Both
OpenCrIDir    : Both
Port Control  : ForceAuthorized
QuietPeriod   : 60 sec
TxPeriod      : 30 sec
SuppTimeout  : 30 sec
ServerTimeout: 30 sec
MaxReq        : 2 times
ReAuthPeriod : 3600 sec
ReAuthenticate: Disable

```

```
DES-1210-28/ME:5#
```

config 802.1x auth_parameter ports

Purpose	To configure the 802.1x authentication parameters on a range of ports. The default parameter returns all ports in the specified range to their default 802.1x settings.
Syntax	config 802.1x auth_parameter ports <portlist> [default { port_control [force_unauth auto force_auth] quiet_period <sec 0-65535> tx_period <sec 1-65535> supp_timeout <sec 1-65535> server_timeout <sec 1-65535> max_req <value 1-10> reauth_period <sec 1-65535> enable_reauth [enable disable] direction [both in]]]
Description	The config 802.1x auth_parameter ports command configures the 802.1x authentication parameters on a range of ports. The default parameter returns all ports in the specified range to their default 802.1x settings.
Parameters	<p><portlist> – A port or range of ports to be configured.</p> <p><i>all</i> – Specifies all of the ports on the Switch.</p> <p><i>default</i> – Returns all of the ports in the specified range to their 802.1x default settings.</p> <p><i>port_control</i> – Configures the administrative control over the authentication process for the range of ports. The options are:</p> <ul style="list-style-type: none"> • <i>force_auth</i> – Forces the Authenticator for the port to become authorized. Network access is allowed. • <i>auto</i> – Allows the port's status to reflect the outcome of the authentication process. • <i>force_unauth</i> – Forces the Authenticator for the port to become unauthorized. Network access is blocked. <p><i>quiet_period</i> <sec 0-65535> – Configures the time interval between authentication failure and the start of a new authentication attempt.</p> <p><i>tx_period</i> <sec 1-65535> - Configures the time to wait for a response from a supplicant (user) to send EAP Request/Identity packets.</p> <p><i>supp_timeout</i> <sec 1-65535> - Configures the time to wait for a response from a supplicant (user) for all EAP packets, except for the Request/Identity packets.</p> <p><i>server_timeout</i> <sec 1-65535> - Configures the length of time to wait for a response from a RADIUS server.</p>

max_req <value 1-10> – Configures the number of times to retry sending packets to a supplicant (user).

reauth_period <sec 300-4294967295> – Configures the time interval between successive re-authentications.

enable_reauth [*enable* | *disable*] – Determines whether or not the Switch will re-authenticate. Enabled causes re-authentication of users at the time interval specified in the Re-authentication Period field, above.

direction [*both* | *in*] – Sets the administrative-controlled direction to *Both*. If *Both* is selected, control is exerted over both incoming and outgoing traffic through the controlled port selected in the first field. The *In* option is not supported in the present firmware release.

Restrictions Only Administrator or operator-level users can issue this command.

Example usage:

To configure 802.1x authentication parameters for ports 1 – 20:

```
DES-1210-28/ME:5# config 802.1x auth_parameter ports 1-5 direction both
Command: config 802.1x auth_parameter ports 1-5 direction both

Success!
DES-1210-28/ME:5#
```

config 802.1x init

Purpose	To initialize the 802.1x function on a range of ports.
Syntax	config 802.1x init port_based ports [<portlist> all]
Description	The config 802.1x init command initializes the 802.1x functions on a specified range of ports or for specified MAC addresses operating from a specified range of ports.
Parameters	<i>port_based</i> – Instructs the Switch to initialize 802.1x functions based only on the port number. Ports approved for initialization can then be specified. <i>ports</i> < <i>portlist</i> > – A port or range of ports to be configured. <i>all</i> – Specifies all of the ports on the Switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To initialize the authentication state machine of all ports:

```
DES-1210-28/ME:5# config 802.1x init port_based ports all
Command: config 802.1x init port_based ports all

Success.

DES-1210-28/ME:5#
```

config 802.1x auth_protocol

Purpose	To configure the 802.1x authentication protocol on the Switch .
Syntax	config 802.1x auth_protocol [radius_eap local]
Description	The config 802.1x auth_protocol command enables configuration of the authentication protocol.
Parameters	<i>radius_eap</i> – Uses the list of RADIUS EAP servers for authentication. <i>local</i> – Uses no authentication.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the RADIUS (AAA) authentication protocol on the Switch:

```
DES-1210-28/ME:5# config 802.1x auth_protocol local
Command: config 802.1x auth_protocol local

Success.

DES-1210-28/ME:5#
```

config 802.1x reauth

Purpose	To configure the 802.1x re-authentication feature of the Switch.
Syntax	config 802.1x reauth port_based ports [<portlist> all]
Description	The config 802.1x reauth command re-authenticates a previously authenticated device based on port number.
Parameters	<i>port_based</i> – Instructs the Switch to re-authorize 802.1x functions based only on the port number. Ports approved for re-authorization can then be specified. <i>ports <portlist></i> – A port or range of ports to be re-authorized. <i>all</i> – Specifies all of the ports on the Switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure 802.1x reauthentication for ports 1-18:

```
DES-1210-28/ME:5# config 802.1x reauth port_based ports 1-18
Command: config 802.1x reauth port_based ports 1-18

Success.

DES-1210-28/ME:5#
```

config radius add

Purpose	To configure the settings the Switch uses to communicate with a RADIUS server.
Syntax	config radius add <server_index 1-3> <server_ip> [key <passwd

	32>] {default auth_port <udp_port_number 1-65535> acct_port <udp_port_number 1-65535>}
Description	The config radius add command configures the settings the Switch uses to communicate with a RADIUS server.
Parameters	<p><i><server_index 1-3></i> – The index of the RADIUS server.</p> <p><i><server_ip></i> – The IP address of the RADIUS server.</p> <p><i>key</i> – Specifies that a password and encryption key are to be used between the Switch and the RADIUS server.</p> <p><i><passwd 32></i> – The shared-secret key used by the RADIUS server and the Switch. Up to 128 characters can be used.</p> <p><i>default</i> – Uses the default udp port number in both the <i>auth_port</i> and <i>acct_port</i> settings.</p> <p><i>auth_port <udp_port_number 1-65535></i> – The UDP port number for authentication requests. The default is 1812.</p> <p><i>acct_port <udp_port_number 1-65535></i> – The UDP port number for accounting requests. The default is 1813.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the RADIUS server communication settings:

```
DES-1210-28/ME:5# config radius add 1 10.48.74.121 key dlink default
Command: config radius add 1 10.48.74.121 key dlink default
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config radius delete

Purpose	To delete a previously entered RADIUS server configuration.
Syntax	config radius delete <server_index 1-3>
Description	The config radius delete command deletes a previously entered RADIUS server configuration.
Parameters	<i><server_index 1-3></i> – The index of the RADIUS server.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete previously configured RADIUS server communication settings:

```
DES-1210-28/ME:5# config radius delete 1
Command: config radius delete 1
```

```
Success!
```

```
DES-1210-28/ME:5# #
```

config radius

Purpose	To configure the Switch's RADIUS settings.
Syntax	config radius <server_index 1-3> { key <passwd 32> auth_port <udp_port_number 1-65535> acct_port <udp_port_number 1-

	65535> ipaddress <server_ip> retransmit <int 1-255> timeout <int 1-255>}
Description	The config radius command configures the Switch's RADIUS settings.
Parameters	<p><i><server_index 1-3></i> – The index of the RADIUS server.</p> <p><i>key</i> – Specifies that a password and encryption key are to be used between the Switch and the RADIUS server.</p> <ul style="list-style-type: none"> <i><passwd 32></i> – The shared-secret key used by the RADIUS server and the Switch. Up to 128 characters can be used. <p><i>auth_port <udp_port_number 1-65535></i> – The UDP port number for authentication requests. The default is 1812.</p> <p><i>acct_port <udp_port_number 1-65535></i> – The UDP port number for accounting requests. The default is 1813.</p> <p><i>ipaddress <server_ip></i> – The IP address of the RADIUS server.</p> <p><i>retransmit <int 1-255></i> –The number of times the device resends an authentication request when the server does not respond. The value is between 1 and 255.</p> <p><i>timeout <int 1-255></i> –Specifies the connection timeout. The value may be between 1 and 255 seconds.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the RADIUS settings:

```
DES-1210-28/ME:5# config radius 1 key dlink retransmit 10
Command: config radius 1 key dlink retransmit 10

Success!
DES-1210-28/ME:5#
```

show radius

Purpose	To display the current RADIUS configurations on the Switch.
Syntax	show radius
Description	The show radius command displays the current RADIUS configurations on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display RADIUS settings on the Switch:


```

DES-1210-28/ME:5# show radius
Command: show radius

Index Ip Address   Auth-Port Acct-Port Timeout Retransmit Key
-----
1     10.48.74.121   1812     1813     5       10       dlink

Total Entries : 1

Success!
DES-1210-28/ME:5#

```

config 802.1x auth_mode

Purpose	To configure the 802.1x authentication mode on the Switch.
Syntax	config 802.1x auth_mode [port_based mac_based]
Description	The config 802.1x auth_mode command enables either the port-based or MAC-based 802.1x authentication feature on the Switch.
Parameters	<i>[port_based mac_based]</i> – Specifies whether 802.1x authentication is by port or MAC address.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure 802.1x authentication by port address:

```

DES-1210-28/ME:5# config 802.1x auth_mode port_based
Command: config 802.1x auth_mode port_based

Success!
DES-1210-28/ME:5#

```

create 802.1x guest_vlan

Purpose	Enables network access to a Guest VLAN.
Syntax	create 802.1x guest_vlan <vlan_name 32>
Description	The create 802.1x guest_vlan command enables network access to a 802.1x Guest VLAN. A network administrator can use 802.1x Guest VLANs to deny network access via port-based authentication, but grant Internet access to unauthorized users.
Parameters	<i><vlan_name 32></i> – The name of the 802.1x Guest VLAN to be created.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a 802.1x Guest VLAN:

```
DES-1210-28/ME:5# create 802.1x guest_vlan default
Command: create 802.1x guest_vlan default
```

```
Success.
```

```
DES-1210-28/ME:5#
```

delete 802.1x guest_vlan

Purpose	Disables network access to a Guest VLAN.
Syntax	delete 802.1x guest_vlan <vlan_name 32>
Description	The delete 802.1x guest_vlan command disables network access to a 802.1x Guest VLAN. A network administrator can use 802.1x Guest VLANs to deny network access via port-based authentication, but grant Internet access to unauthorized users.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command. The user is required to disable Guest VLAN before deleting a specific the VLAN.

Example usage:

To delete a 802.1x Guest VLAN

```
DES-1210-28/ME:5# delete 802.1x guest_vlan default
Command: delete 802.1x guest_vlan default
```

```
Success.
```

```
DES-1210-28/ME:5#
```

config 802.1x guest_vlan ports

Purpose	Defines a port or range of ports to be members of the Guest VLAN.
Syntax	config 802.1x guest_vlan ports [<portlist> all] state [enable disable]
Description	The config 802.1x guest_vlan ports command defines a port or range of ports to be members of the 802.1x Guest VLAN. The 802.1x Guest VLAN can be configured to provide limited network access to authorized member ports. If a member port is denied network access via port-based authorization, but the 802.1x Guest VLAN is enabled, the member port receives limited network access. For example, a network administrator can use the 802.1x Guest VLAN to deny internal network access via port-based authentication, but grant Internet access to unauthorized users.
Parameters	<i><portlist></i> – A port or range of ports to be configured to the Guest VLAN. <i>All</i> – Indicates all ports to be configured to the guest vlan. <i>state [enable disable]</i> – Specifies the guest vlan port is enabled or disabled of the switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure ports to the Guest VLAN

```
DES-1210-28/ME:5# config 802.1x guest_vlan ports 1-5 state enable
Command: config 802.1x guest_vlan ports 1-5 state enable

Success.

DES-1210-28/ME:5#
```

show 802.1x guest_vlan

Purpose	Displays configuration information for the Guest VLAN.
Syntax	show 802.1x guest_vlan
Description	The show 802.1x guest_vlan command displays the Guest VLAN name, state, and member ports.
Parameters	None.
Restrictions	None.

Example usage:

To display the Guest VLAN configuration information:

```
DES-1210-28/ME:5# show 802.1x guest_vlan
Command: show 802.1x guest_vlan

Guest VLAN Settings
-----
Guest VLAN           : default
Enabled Guest VLAN Ports :
1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,2
1,22,23,24,25,26,27,28

DES-1210-28/ME:5#
```

create 802.1x user

Purpose	Enable network access to a 802.1x user.
Syntax	create 802.1x user <username 15>
Description	The create 802.1x user command enables network access to a 802.1x user.
Parameters	<vlan_name 15> – The name of the 802.1x user to be created.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a 802.1x user:

```

DES-1210-28/ME:5# create 802.1x user dlink
Command: create 802.1x user dlink

Enter a case-sensitive new password:****
Enter the new password again for confirmation:****

Success!
DES-1210-28/ME:5#

```

show 802.1x user

Purpose	Displays the user information for the Guest VLAN.
Syntax	show 802.1x user
Description	The show 802.1x user command displays the 802.1x user information on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the 802.1x user information:

```

DES-1210-28/ME:5# show 802.1x user
Command: show 802.1x user

Index      Username
-----
1          dlink

Total Entries: 1

Success!
DES-1210-28/ME:5#

```

delete 802.1x user

Purpose	Deletes network access to a 802.1x user.
Syntax	delete 802.1x user <username 15>
Description	The delete 802.1x user command deletes network access to a 802.1x user.
Parameters	<vlanname 15> – The name of the 802.1x user to be deleted.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete the 802.1x user:

```
DES-1210-28/ME:5# delete 802.1x user dlink
```

```
Command: delete 802.1x user dlink
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config 802.1x capability ports

Purpose	Defines a port or range of ports to be members of the Guest VLAN.
Syntax	config 802.1x capability ports [<portlist> all] [authenticator none]
Description	The config 802.1x capability ports is used to configure the capability for the 802.1x on the Switch.
Parameters	<p><i><portlist></i> – A port or range of ports to be configured to the 802.1x capability.</p> <p><i>All</i> – Indicates all ports to be configured to the 802.1x capability.</p> <p><i>[authenticator none]</i> – Specifies the 802.1x capability port to be authenticator or none.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure capability ports to the 802.1x on the Switch:

```
DES-1210-28/ME:5# config 802.1x capability ports all authenticator
```

```
Command: config 802.1x capability ports all authenticator
```

```
Success!
```

```
DES-1210-28/ME:5#
```

PORT SECURITY COMMANDS

The Port Security commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config port_security	[<portlist> all] [admin_state [enable disable] max_learning_addr <max_lock_no 0-64> lock_address_mode [Permanent DeleteOnTimeout DeleteOnReset]
show port_security	{ports <portlist>}

Each command is listed in detail, as follows:

config port_security	
Purpose	To configure port security settings.
Syntax	config port_security [<portlist> all] [admin_state [enable disable] max_learning_addr <max_lock_no 0-64> lock_address_mode [Permanent DeleteOnTimeout DeleteOnReset]
Description	The config port_security command configures port security settings for specific ports.
Parameters	<p><i>portlist</i> – A port or range of ports to be configured.</p> <p><i>all</i> – Configures port security for all ports on the Switch.</p> <p><i>admin_state [enable disable]</i> – Enables or disables port security for the listed ports.</p> <p><i>max_learning_addr <int 0-64></i> - 1-64 Limits the number of MAC addresses dynamically listed in the FDB for the ports.</p> <p><i>lock_address_mode</i> – Defines the TBD and contains the following options:</p> <ul style="list-style-type: none"> • <i>Permenant</i> – Learns up to the maximum number of dynamic addresses allowed on the port. The learned addresses are not aged out or relearned on other port for as long as the port is locked. • <i>DeleteOnReset</i> – Deletes the current dynamic MAC addresses associated with the port. Learn up to the maximum addresses allowed on the port (this number is also configurable). Aging is disabled; the addresses are deleted on reset • <i>DeleteOnTimeout</i> – Deletes the current dynamic MAC addresses associated with the port. The port learns up to the maximum addresses allowed on the port. Re-learned MAC addresses and address aging out are also enabled. The MAC addresses are deleted when the device is reset and on when the address is aged out.
Restrictions	Only administrator or operator-level users can issue this command

Example usage:

To configure port security:

```
DES-1210-28/ME:5# config port_security 1-5 admin_state enable
max_learning_addr 5 lock_address_mode DeleteOnReset
Command: config port_security 1-5 admin_state enable
max_learning_addr 5 lock_ad

dress_mode DeleteOnReset

Success

DES-1210-28/ME:5#
```

show port_security

Purpose	To display the current port security configuration.
Syntax	show port_security {ports <portlist>}
Description	The show port_security command displays port security information for the Switch's ports. The information displayed includes port security, admin state, maximum number of learning address and lock mode and trap interval.
Parameters	<i>ports <portlist></i> – A port or range of ports whose settings are to be displayed.
Restrictions	None.

Example usage:

To display the port security configuration:

```
DES-1210-28/ME:5# show port_security ports 1-5
Command: show port_security ports 1-5

Port Admin state Max.Learning Addr. Lock Address Mode
-----
1 enabled 5 DeleteOnReset
2 enabled 5 DeleteOnReset
3 enabled 5 DeleteOnReset
4 enabled 5 DeleteOnReset
5 enabled 5 DeleteOnReset

DES-1210-28/ME:5#
```

TIME AND SNTP COMMANDS

The Time and SNTP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config sntp	{primary <ipaddr> secondary <ipaddr> poll-interval <sec 30-99999>}
show sntp	
enable sntp	
disable sntp	
config time	<date> <systemtime>
config time_zone operator	[+ hour <gmt_hour 0-13> minute <minute 0-59> - hour <gmt_hour 0-12> minute <minute 0-59>]
config dst	[disable [annual s_date <start_date 1-31> s_mth <start_mth 1-12> s_time <start_time> end_date <int 1-31> e_mth <end_mth 1-12> e_time <end_time> offset [30 60 90 120]]]
show time	

Each command is listed in detail, as follows:

config sntp	
Purpose	To setup SNTP service.
Syntax	config sntp {primary <ipaddr> secondary <ipaddr> poll-interval <sec 30-99999>}
Description	The config sntp command configures SNTP service from an SNTP server. SNTP must be enabled for this command to function (See enable sntp).
Parameters	<p><i>primary <ipaddr></i> – Specifies the IP address of the primary SNTP server.</p> <p><i>secondary <ipaddr></i> – Specifies the IP address of the secondary SNTP server.</p> <p><i>poll-interval <sec 30-99999></i> – The interval between requests for updated SNTP information. The polling interval ranges from 60 seconds (1 minute) to 86,400 seconds (1 day).</p>
Restrictions	Only administrator or operate-level users can issue this command. SNTP service must be enabled for this command to function (<i>enable sntp</i>).

Example usage:

To configure SNTP settings:


```
DES-1210-28/ME:5# config sntp primary 10.1.1.1 secondary 10.1.1.2 poll-
interval 60
Command: config sntp primary 10.1.1.1 secondary 10.1.1.2 poll-interval 60

Success!

DES-1210-28/ME:5#
```

show sntp

Purpose	To display the SNTP information.
Syntax	show sntp
Description	The show sntp command displays SNTP settings information, including the source IP address, time source and poll interval.
Parameters	None.
Restrictions	None.

Example usage:

To display SNTP configuration information:

```
DES-1210-28/ME:5# show sntp
Command: show sntp

SNTP Information
-----
Current Time Source      : Local
SNTP                     : Disabled
SNTP Primary Server     : 10.1.1.1
SNTP Secondary Server   : 10.1.1.2
SNTP Poll Interval      : 60 sec

DES-1210-28/ME:5#
```

enable sntp

Purpose	To enable SNTP server support.
Syntax	enable sntp
Description	The enable sntp command enables SNTP server support. SNTP service must be separately configured (see config sntp). Enabling and configuring SNTP support override any manually configured system time settings.
Parameters	None.
Restrictions	Only administrator and Operator-level users can issue this command. SNTP settings must be configured for SNTP to function (config sntp).

Example usage:

To enable the SNTP function:

```
DES-1210-28/ME:5# enable sntp
```

```
Command: enable sntp
```

```
Success!
```

```
DES-1210-28/ME:5#
```

disable sntp

Purpose	To disable SNTP server support.
Syntax	disable sntp
Description	The disable sntp command disables SNTP support.
Parameters	None.
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To disable SNTP support:

```
DES-1210-28/ME:5# disable sntp
```

```
Command: disable sntp
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config time

Purpose	To manually configure system time and date settings.
Syntax	config time <date> <systemtime>
Description	The config time date command configures the system time and date settings. These will be overridden if SNTP is configured and enabled.
Parameters	<p><date> – Specifies the date, using two numerical characters for the day of the month, English abbreviation for the name of the month, and four numerical characters for the year. For example: 19jan2011.</p> <p><systemtime > – Specifies the system time, using the format hh:mm:ss; that is, two numerical characters each for the hour using a 24-hour clock, the minute and second. For example: 19:42:30.</p>
Restrictions	Only administrator or operate-level users can issue this command. Manually configured system time and date settings are overridden if SNTP support is enabled.

Example usage:

To manually set system time and date settings:

```
DES-1210-28/ME:5# config time 09jan2012 15:50:50
Command: config time 09jan2012 15:50:50

Success!

DES-1210-28/ME:5#
```

config time_zone operator

Purpose	To determine the time zone used in order to adjust the system clock.
Syntax	config time_zone operator [+ hour <gmt_hour 0-13> minute <minute 0-59> - hour <gmt_hour 0-12> minute <minute 0-59>]
Description	The config time_zone operator command adjusts the system clock settings according to the time zone. Time zone settings adjust SNTP information accordingly.
Parameters	<p><i>operator</i> – May be (+) to add or (-) to subtract time to adjust for time zone relative to GMT.</p> <p><i>hour</i> <gmt_hour 0-13> – Specifies the number of hours difference from GMT.</p> <p><i>Minute</i> <minute 0-59> – Specifies the number of minutes added or subtracted to adjust the time zone.</p>
Restrictions	Only administrator or operator level users can issue this command.

Example usage:

To configure time zone settings:

```
DES-1210-28/ME:5# config time_zone operator + hour 2 minute 30
Command: config time_zone operator + hour 2 minute 30

Success!

DES-1210-28/ME:5#
```

config dst

Purpose	To configure time adjustments to allow for the use of Daylight Saving Time (DST).
Syntax	config dst [disable [annual s_date <start_date 1-31> s_mth <start_mth 1-12> s_time <start_time> end_date <int 1-31> e_mth <end_mth 1-12> e_time <end_time> offset [30 60 90 120]]]
Description	The config dst command disables or configures Daylight Saving Time (DST). When enabled, this adjusts the system clock to comply with any DST requirement. DST adjustment affects system time for both manually configured time and time set using SNTP service.
Parameters	<p><i>disable</i> – Disables the DST seasonal time adjustment for the Switch.</p> <p><i>annual</i> – Enables DST seasonal time adjustment on an annual basis. Annual mode requires that the DST beginning and ending date be specified concisely. For example, specify to begin DST on April 3 and end DST on October 14. The format for annual mode is as follows, and in the order listed:</p>

- *s_date* <start_date 1-31> - The day of the month to begin DST, expressed numerically.
- *s_mth* <start_mth 1-12> - The month of the year to begin DST, expressed numerically.
- *s_time* <start_time> - The time of day to begin DST in hours and minutes, expressed using a 24-hour clock.
- *end_date* <int 1-31> - The day of the month to end DST, expressed numerically.
- *e_mth* <end_mth 1-12> - The month of the year to end DST, expressed numerically.
- *e_time*<end_time> - The time of day to end DST, in hours and minutes, expressed using a 24-hour clock.

offset [30 | 60 | 90 | 120] – Indicates the number of minutes to add during the summertime. The possible offset times are 30, 60, 90, and 120. The default value is 60.

Restrictions

Only Administrator or operator-level users can issue this command.

Example usage:

To configure daylight savings time on the Switch to run from the 2nd Tuesday in April at 3 PM until the 2nd Wednesday in October at 3:30 PM and add 30 minutes at the onset of DST:

```
DES-1210-28/ME:5# config dst annual s_date 2 s_mth 4 s_time 3 end_date 2
e_mth 10 e_time 3 offset 30
```

```
Command: config dst annual s_date 2 s_mth 4 s_time 3 end_date 2 e_mth 10
e_time 3 offset 30
```

Success!

```
DES-1210-28/ME:5#
```

show time

Purpose	To display the current time settings and status.
Syntax	show time
Description	The show time command displays the system time and date configuration, as well as displays the current system time.
Parameters	None.
Restrictions	None.

Example usage:

To show the time currently set on the Switch's System clock:

DES-1210-28/ME:5# show time

Command: show time

Time information

Current Time Source : Local
Current Time : 09 Jan 2012 15:56:02
GMT Time Zone offset : GMT +02:30
Daylight Saving Time Status : Disabled
Offset in Minutes : 60
Annual From : 01 Jan 00:00
To : 01 Jan 00:00

DES-1210-28/ME:5#

ARP COMMANDS

The ARP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create ArpSpoofing	ip_address <ipaddr> mac_address <macaddr> [<portlist> all]
show ArpSpoofing	
delete ArpSpoofing	ip_address <ipaddr>
config arp_aging time	<value 0-65535 >
clear arptable	
show arpentry	{information interface_name ip_address mac_address summary}
show arpentry aging_time	

Each command is listed in detail, as follows:

create ArpSpoofing	
Purpose	To create the on the Switch.
Syntax	create ArpSpoofing ip_address <ipaddr> mac_address <macaddr> [<portlist> all]
Description	The create ArpSpoofing command sets the maximum amount of time, in minutes, that an ARP entry can remain in the Switch's ARP table, without being accessed, before it is dropped from the table.
Parameters	<p><i>ip_address <ipaddr></i> – Specifies the IP address of the end node or station.</p> <p><i>mac_address<macaddr></i> – Specifies the MAC address corresponding to the IP address above.</p> <p><i>[<portlist> all]</i> – Specifies a port, a range of ports or all ports to be configured for the ARP snooping.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create an ARP Spoofing IP address on the Switch:

```
DES-1210-28/ME:5# create ArpSpoofing ip_address 10.2.1.1
mac_address 00-00-00-01-01-2 all
Command: create ArpSpoofing ip_address 10.2.1.1 mac_address 00-
00-00-01-01-2 all

Success!
DES-1210-28/ME:5#
```

show ArpSpoofing

Purpose	To display the ARP Spoofing information on the Switch.
Syntax	show ArpSpoofing
Description	The show ArpSpoofing displays the information, includes IP address, MAC address and Port list information on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the ARP Spoofing information on the Switch:

```
DES-1210-28/ME:5# show ArpSpoofing
Command: show ArpSpoofing

IP Address      MAC Address      PortList
10.2.1.1        00:00:00:01:01:02  1-28

DES-1210-28/ME:5# show ArpSpoofing
```

delete ArpSpoofing

Purpose	To delete an IP address and the corresponding MAC address into the Switch's ARP table.
Syntax	delete ArpSpoofing ip_address <ip_addr>
Description	The delete ArpSpoofing command deletes an IP address and the corresponding MAC address into the Switch's ARP table.
Parameters	<i>ip_address <ipaddr></i> – The IP address of the end node or station.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete the ARP spoofing configuration:

```
DES-1210-28/ME:5# create ArpSpoofing ip_address 10.2.1.1
mac_address 00-00-00-01-01-2 all
Command: create ArpSpoofing ip_address 10.2.1.1 mac_address 00-
00-00-01-01-2 all

Success!
DES-1210-28/ME:5#
```

config arp_aging time

Purpose	To configure the age-out timer for ARP table entries on the Switch.
Syntax	config arp_aging time <value 0-65535 >
Description	The config arp_aging time command sets the maximum amount of time, in minutes, that an ARP entry can remain in the Switch's ARP table, without being accessed, before it is dropped from the table.
Parameters	<i>time <value 0-65535></i> – The ARP age-out time, in minutes. The value may be in the range of 0-65535 minutes, with a default setting of 20 minutes.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure ARP aging time:

```
DES-1210-28/ME:5# config arp_aging time 30
Command: config arp_aging time 30

Success.

DES-1210-28/ME:5#
```

clear arptable

Purpose	To remove all dynamic ARP table entries.
Syntax	clear arptable
Description	The clear arptable command is used to remove dynamic ARP table entries from the Switch's ARP table. Static ARP table entries are not affected.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To remove dynamic entries in the ARP table:

```
DES-1210-28/ME:5# clear arptable
Command: clear arptable

Success.

DES-1210-28/ME:5#
```


show arpentry

Purpose	To displays all ARP entries on the Switch.
Syntax	show arpentry {information interface_name ip_address mac_address summary}
Description	The show arpentry command displays all ARP entries on the Switch.
Parameters	<i>information</i> – Displays the information of ARP entry. <i>interface_name</i> – Displays the interface name of ARP entry. <i>ip_address</i> – Displays the IP address of ARP entry. <i>mac_address</i> – Displays the MAC address of ARP entry. <i>summary</i> – Displays the summary of ARP entry.
Restrictions	None.

Example usage:

To display all ARP entries information on the Switch:

```
DES-1210-28/ME:5# show arpentry information
Command: show arpentry information

ARP Configurations:
-----
Maximum number of ARP request retries is 3
ARP cache timeout is 1800 seconds

DES-1210-28/ME:5#
```

show arpentry aging_time

Purpose	To displays the ARP entry aging time on the Switch.
Syntax	show arpentry
Description	The show arpentry command displays the ARP entry aging time on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the ARP entry aging time on the Switch:

```
DES-1210-28/ME:5# show arpentry aging_time
Command: show arpentry aging_time

ARP Aging Time = 30 (minutes)

DES-1210-28/ME:5#
```

BANNER COMMANDS

The Banner commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config log_save_timing	[log_trigger on_demand time_interval <minutes 1-65535>]
show log_save_timing	
show log	

Each command is listed in detail, as follows:

config log_save_timing	
Purpose	Used to configure the method of saving logs to the Switch's Flash memory.
Syntax	config log_save_timing [log_trigger on_demand time_interval <minutes 1-65535>]
Description	This config log_save_timing command is used to configure the method used in saving logs to the Switch's Flash memory.
Parameters	<p><i>log_trigger</i> – Users who choose this method will have logs saved to the Switch every time a log event occurs on the Switch.</p> <p><i>on_demand</i> – Users who choose this method will only save logs when they manually tell the Switch to do so, using the save all or save log command.</p> <p><i>time_interval <minutes 1-65535></i>– Use this parameter to configure the time interval that will be implemented for saving logs. The logs will be saved every x number of minutes that are configured here.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the time interval as every 30 minutes for saving logs:

```
DES-1210-28/ME:5# config log_save_timing time_interval 30
Command: config log_save_timing time_interval 30

Success!

DES-1210-28/ME:5#
```

show log_save_timing

Purpose	Used to show the login banner.
Syntax	show log_save_timing
Description	This command allows display of the log save timing on the Switch
Parameters	None.
Restrictions	None.

Usage Example:

To show the login banner:

```
DES-1210-28/ME:5# show log_save_timing
Command: show log_save_timing

Saving log method: time_interval
Interval : 300

DES-1210-28/ME:5#
```

show log

Purpose	Used to show the login banner.
Syntax	show log
Description	This command allows display of the log.
Parameters	None.
Restrictions	None.

Usage Example:

To show the log on the Switch:

```
DES-1210-28/ME:5# show log
Command: show log

Index Time                Log Text
-----
  3  Jan  9 17:43:25 2012:CLI-6:Successful login through console port
  2  Jan  1 00:00:23 2011:SYSTEM-2:System started up
  1  Jan  1 00:00:20 2011:CLI-6:Successful login through console port

DES-1210-28/ME:5#
```

COMMAND HISTORY LIST COMMANDS

The Command History List commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
?	
show command_history	
dir	

Each command is listed in detail, as follows:

?	
Purpose	To display all commands in the Command Line Interface (CLI).
Syntax	?
Description	The ? command displays all of the commands available through the Command Line Interface (CLI).
Parameters	{<command>} – Lists all the corresponding parameters for the specified command, along with a brief description of the command's function and similar commands having the same words in the command.
Restrictions	None.

Example usage:

To display all of the commands in the CLI:

```

DES-1210-28/ME:5# ?

Command: ?

?
cable diagnostic port
clear arptable
clear counters
clear dos_prevention counters
clear flood_fdb
clear igmp_snooping data_driven_group
clear log
config 802.1p default_priority
config 802.1p user_priority
config 802.1x auth_mode ports
config 802.1x auth_parameter ports
config 802.1x auth_protocol
config 802.1x capability ports
config 802.1x feap
config 802.1x guest_vlan ports
config 802.1x init port_based ports
config 802.1x reauth port_based ports
config access_profile ip
config access_profile profile_id
CTRL+C ESC q Quit SPACE n Next Page ENTER Next Entry a
ALL

```

show command_history

Purpose	To display the command history.
Syntax	show command_history
Description	The show command_history command displays the command history.
Parameters	None.
Restrictions	None.

Example usage:

To display the command history:

```

DES-1210-28/ME:5# show command_history

Command: show command_history

?
show log
show log_save_timing
show log_save_timing

```

```
DES-1210-28/ME:5#
```

dir

Purpose	To display all commands.
Syntax	dir
Description	The dir command displays all commands.
Parameters	None.
Restrictions	None.

Example usage:

To display all of the commands:

```
DES-1210-28/ME:5# dir
Available commands:
?          cable      clear      config
create     delete     disable    download
enable     logout     ping       reboot
reset      save       show       smtp
upload
DES-1210-28/ME:5#
```

SSH COMMANDS

The SSH commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable ssh	
disable ssh	
config ssh algorithm	[3DES MD5 RSA SHA1] [disable enable]
config ssh authmode	[publickey hostbased password] [enable disable]
show ssh authmode	
config ssh server	[authfail <int 2-20> contimeout <sec 120-600> maxsession <int 1-4> rekey [10min 30min 60min never]]
show ssh server	
show ssh algorithm	
config ssh user	<string 15> authmode [hostbased hostname <domain_name> hostname_IP <ipaddr> password publickey]
show ssh user authmode	

Each command is listed in detail, as follows:

enable ssh	
Purpose	To enable SSH.
Syntax	enable ssh
Description	The enable ssh command enables SSH on the Switch.
Parameters	None
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable SSH:

```
DES-1210-28/ME:5# enable ssh
```

```
Command: enable ssh
```

```
Success.
```

```
The SSH server is enabled.
```

```
DES-1210-28/ME:5#
```

disable ssh

Purpose	To disable SSH.
Syntax	disable ssh
Description	The disable ssh command disables SSH on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable SSH:

```
DES-1210-28/ME:5# disable ssh
```

```
Command: disable ssh
```

```
Success.
```

```
The SSH server is disable.
```

```
DES-1210-28/ME:5#
```

config ssh algorithm

Purpose	To configure the SSH algorithm.
Syntax	config ssh algorithm [3DES MD5 RSA SHA1] [disable enable]
Description	The config ssh algorithm command configures the SSH algorithm setting on the Switch.
Parameters	Select the algorithm to be disabled or enabled: <ul style="list-style-type: none"> ▪ <i>3DES</i> – Triple Data Encryption Standard encryption algorithm with Cipher Block Chaining. ▪ <i>MD5</i> – Hash for Message Authentication Code (HMAC) MD5 Message Digest (MD5) mechanism. ▪ <i>RSA</i> – Hash for Message Authentication Code (HMAC) mechanism utilizing the RSA encryption algorithm. ▪ <i>SHA1</i> – Hash for Message Authentication Code (HMAC) Secure Hash Algorithm (SHA) mechanism. <p><i>[disable enable]</i> – Enables or Disables the SSH algorithm on the Switch.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure SSH algorithm:

```
DES-1210-28/ME:5# config ssh algorithm 3DES enable
Command: config ssh algorithm 3DES enable

Success.

DES-1210-28/ME:5#
```

config ssh authmode

Purpose	To configure the SSH authentication mode setting.
Syntax	config ssh authmode [publickey hostbased password] [enable disable]
Description	The config ssh authmode command configures the SSH authentication mode for users attempting to access the Switch.
Parameters	<i>publickey</i> [enable disable] – Specifies that a publickey configuration set on a SSH server is to be used for authentication. Enables or disables SSH authentication on the Switch.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable the SSH authentication mode:

```
DES-1210-28/ME:5# config ssh authmode password enable
Command: config ssh authmode password enable

Success.

DES-1210-28/ME:5#
```

show ssh authmode

Purpose	To display the SSH authentication mode setting.
Syntax	show ssh authmode
Description	The show ssh authmode command displays the current SSH authentication set on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To view the current authentication mode set on the Switch:

```
DES-1210-28/ME:5# show ssh authmode
```

```
Command: show ssh authmode
```

```
The SSH Authmode :
```

```
-----
```

```
Password : Disabled
```

```
Publickey : Enabled
```

```
Hostbased : Disabled
```

```
Success.
```

```
DES-1210-28/ME:5#
```

config ssh server

Purpose	To configure the SSH server.
Syntax	config ssh server [authfail <int 2-20> contimeout <sec 120-600> maxsession <int 1-4> rekey [10min 30min 60min never]]
Description	The config ssh server command configures the SSH server.
Parameters	<p><i>authfail <int 2-20></i> - Specifies the authfail times. The value may be between 2 and 20 times.</p> <p><i>contimeout <sec 120-600></i> - Specifies the connection timeout. The value may be between 120 and 600 seconds. The default is 600 seconds.</p> <p><i>maxsession <int 1-4></i> – Specifies the maxsession of ssh server.</p> <p><i>rekey [10min 30min 60min never]</i> – Specifies the rekey time. The possible values are 10min, 30min, 60min and never.</p>
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the SSH server:

```
DES-1210-28/ME:5# config ssh server authfail 20 maxsession 1
```

```
Command: config ssh server authfail 20 maxsession 1
```

```
Success.
```

```
DES-1210-28/ME:5#
```

show ssh server

Purpose	To display the SSH server setting
Syntax	show ssh server
Description	The show ssh server command displays the current SSH server settings.
Parameters	None.
Restrictions	None.

Example usage:

To display the SSH server:

```
DES-1210-28/ME:5# show ssh server
```

```
Command: show ssh server
```

```
The SSH Server Configuration :
```

```
Max Session           : 1
Connection Timeout    : 120
Authfail Attempts     : 20
Rekey Timeout         : never
Success.
```

```
DES-1210-28/ME:5#
```

show ssh algorithm

Purpose	To display the SSH algorithm setting.
Syntax	show ssh algorithm
Description	The show ssh algorithm command displays the current SSH algorithm setting status.
Parameters	None.
Restrictions	None.

Example usage:

To display SSH algorithms currently set on the Switch:

```
DES-1210-28/ME:5# show ssh algorithm
```

```
Command: show ssh algorithm
```

```
Encryption Algorithm
```

```
-----
DES      : Enabled
3DES     : Enabled
```

```
Data Integrity Algorithm
```

```
-----
MD5      : Enabled
SHA1     : Enabled
```

```
Public Key Algorithm
```

```
-----
RSA      : Disabled
Success.
```

```
DES-1210-28/ME:5#
```

config ssh user

Purpose	To specify which SSH public key is manually configured.
Syntax	config ssh user <string 15> authmode [hostbased hostname <domain_name> hostname_IP <ipaddr> password publickey]
Description	The config ssh crypto command specifies which SSH public key is manually configured.
Parameters	<i><string 15></i> – Specifies the name of SSH user. <i>hostbased hostname <domain_name></i> – The username of the remote SSH client. <i>[hostbased password publickey]</i> – Specifies which configuration will be set on a SSH server for authentication.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure the SSH user:

```
DES-1210-28/ME:5# config ssh user dlink authmode publickey
Command: config ssh user dlink authmode publickey

Success.

DES-1210-28/ME:5#
```

show ssh user authmode

Purpose	To display the SSH public key stored on the device.
Syntax	show ssh user authmode
Description	The show ssh user authmode command displays the SSH user stored on the device.
Parameters	None.
Restrictions	None.

Example usage:

To display the SSH public key on the device:

```
DES-1210-28/ME:5# show ssh user authmode
Command: show ssh user authmode

Account is empty!
Total Entries: 0

Success.

DES-1210-28/ME:5#
```

SSL COMMANDS

The SSL commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable ssl	
disable ssl	
show ssl	
download ssl certificate	<ipaddr> certfilename <path_filename 64>

Each command is listed in detail, as follows:

enable ssl

Purpose	To enable the SSL function on the Switch.
Syntax	enable ssl
Description	The enable ssl command enables SSL on the Switch by implementing every combination of listed ciphersuites on the Switch. Entering this command enables the SSL status on the Switch. Enabling SSL disables the web-manager on the Switch.
Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To enable SSL on the Switch for all ciphersuites:

```
DES-1210-28/ME:5# enable ssl
```

```
Command: enable ssl
```

Note: HTTP will be disabled if SSL is enabled.

Success.

```
DES-1210-28/ME:5#
```

disable ssl

Purpose	To disable the SSL function on the Switch.
Syntax	disable ssl
Description	The disable ssl command disables SSL on the Switch and can be used to disable all combinations of listed ciphersuites on the Switch. Note that disabling SSL will not enable WEB access automatically (WEB access will stay disabled), and you'll need to enable it manually.

Parameters	None.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To disable the SSL status on the Switch:

```
DES-1210-28/ME:5# disable ssl
Command: disable ssl

Success.
DES-1210-28/ME:5#
```

show ssl

Purpose	To view the SSL status and the certificate file status on the Switch
Syntax	show ssl
Description	The show ssl command displays the SSL status and the certificate file status on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To view the SSL status on the Switch:

```
DES-1210-28/ME:5# show ssl
Command: show ssl

SSL Status                Enabled
RSA-NULL-MD5              0x0001 Enabled
RSA-NULL-SHA1             0x0002 Enabled
RSA-DES-SHA1              0x0004 Enabled
RSA-3DES-SHA1            0x0008 Enabled
DH-RSA-DES-SHA1          0x0010 Enabled
DH-RSA-3DES-SHA1         0x0020 Enabled
RSA-EXP1024-DES-SHA1     0x0040 Enabled

Success.
DES-1210-28/ME:5#
```

download ssl certificate

Purpose	To download ssl certificate file on the Switch.
Syntax	download ssl certificate <ipaddr> certfilename <path_filename 64>
Description	The download ssl certificate command downloads the SSL file on the Switch.
Parameters	<ipaddr> – Specifies the IP address of SSL file.

	<i><path_filename 64></i> –The DOS path and filename of the SSL file, up to 64 characters, on the TFTP server. For example, C:\1210.had.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To download SSL on the Switch:

```
DES-1210-28/ME:5# download ssl certificate 10.48.47.22 certfilename
1210.had
Command: download ssl certificate 10.48.47.22 certfilename 1210.had

Success.
DES-1210-28/ME:5#
```

ACCESS AUTHENTICATION CONTROL COMMANDS

The Access Authentication Control commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create authen_login method_list_name	<string 15>
config authen_login	[default method_list_name <string 15>] method [tacacs+ radius local server_group <string 15> none]
delete authen_login method_list_name	<string 15>
show authen_login	[all default method_list_name <string 15>]
show authen_policy	
create authen_enable method_list_name	<string 12>
config authen_enable	[default method_list_name <string 15>] method {tacacs+ radius local server_group <string 15> none}
delete authen_enable method_list_name	<string 15>
show authen_enable	[all default method_list_name <string 15>]
enable authen_policy	
disable authen_policy	
config authen application	{console http ssh all} [login enable] [default method_list_name <string 15>]
show authen application	
config authen parameter	[attempt <int 1-255> response_timeout <int 0-255>]
show authen parameter	
create authen server_host	<ipaddr> protocol [radius tacacs+] {port <int 1-65535> key [<string 254> none] timeout <int 1-255> retransmit <int 1-255>}
config authen server_host	<ipaddr> protocol [tacacs+ radius] {port <int 1-65535> key [<string 254> none] timeout <int 1-255> retransmit <int 1-255>}
delete authen server_host	<ipaddr> protocol [tacacs radius]
show authen server_host	
create authen server_group	<string 15>

Command	Parameter
config authn server_group	[<string 15> radius tacacs+] [add delete] server_host <ipaddr> protocol [radius tacacs+]
delete authn server_group	<string 15>
show authn server_group	{<string 15>}
enable admin	
config admin local_enable	

Each command is listed in detail, as follows:

create authn_login method_list_name	
Purpose	To create a user-defined list of authentication methods for users logging on to the Switch.
Syntax	create authn_login method_list_name <string 15>
Description	The create authn_login method_list_name command creates a list of authentication techniques for user login. The Switch can support up to eight method lists, but one is reserved as a default and cannot be deleted. Multiple method lists must be created and configured separately.
Parameters	<string 15> - Defines the <i>method_list_name</i> to be created as a string of up to 15 alphanumeric characters.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create the method list 'Trinity':

```
DES-1210-28/ME:5# create authn_login method_list_name Trinity
Command: create authn_login method_list_name Trinity

Success.

DES-1210-28/ME:5#
```

config authn_login	
Purpose	To configure a user-defined or default <i>method list</i> of authentication methods for user login.
Syntax	config authn_login [default method_list_name <string 15>] method [tacacs+ radius local server_group <string 15> none]
Description	The config authn_login command configures a user-defined or default <i>method list</i> of authentication methods for users logging on to the Switch. The sequence of methods implemented in this command

	<p>affects the authentication result. For example, if a user enters a sequence of methods like <i>tacacs – local</i>, the Switch sends an authentication request to the first <i>tacacs</i> host in the server group. If no response comes from the server host, the Switch sends an authentication request to the second <i>tacacs</i> host in the server group and so on, until the list is exhausted. When the local method is used, the privilege level is dependant on the local account privilege configured on the Switch.</p> <p>Successful login using any of these methods gives the user a ‘user’ privilege only. If the user wishes to upgrade his or her status to the administrator level, the user must implement the <i>enable admin</i> command, followed by a previously configured password. (See the <i>enable admin</i> part of this section for more detailed information, concerning the <i>enable admin</i> command.)</p>
Parameters	<p><i>default</i> – The default method list for access authentication, as defined by the user. The user may choose one or more of the following authentication methods:</p> <ul style="list-style-type: none"> ▪ <i>tacacs+</i> – Specifies that the user is to be authenticated using the TACACS+ protocol from the remote TACACS+ <i>server hosts</i> of the TACACS+ <i>server group</i> list. ▪ <i>radius</i> - Specifies that the user is to be authenticated using the RADIUS protocol from the remote RADIUS <i>server hosts</i> of the RADIUS <i>server group</i> list. ▪ <i>local</i> - Specifies that the user is to be authenticated using the local <i>user account</i> database on the Switch. ▪ <i>server_group <string 15></i> –Specifies that the user is to be authenticated using the server group <i>account</i> database on the Switch. ▪ <i>none</i> – Specifies that no authentication is required to access the Switch. <p><i>method_list_name <string 15></i> – Specifies a previously created method list name defined by the user. One or more of the following authentication methods may be added to this method list:</p> <ul style="list-style-type: none"> ▪ <i>tacacs+</i> – Specifies that the user is to be authenticated using the TACACS+ protocol from a remote TACACS+ server. ▪ <i>radius</i> - Specifies that the user is to be authenticated using the RADIUS protocol from a remote RADIUS server. ▪ <i>local</i> - Specifies that the user is to be authenticated using the local <i>user account</i> database on the Switch. ▪ <i>server_group <string 15></i> –Specifies that the user is to be authenticated using the server group <i>account</i> database on the Switch. ▪ <i>none</i> – Specifies that no authentication is required to access the Switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the user defined method list ‘Trinity’ with authentication methods TACACS+, RADIUS and local, in that order.

```
DES-1210-28/ME:5# config authen_login method_list_name Trinity method tacacs+ radius local
Command: config authen_login method_list_name Trinity method tacacs+ radius local
```

Success.

```
DES-1210-28/ME:5#
```

delete authen_login method_list_name

Purpose	To delete a previously configured user defined list of authentication methods for users logging on to the Switch.
Syntax	delete authen_login method_list_name <string 15>
Description	The delete authen_login method_list_name command deletes a list of authentication methods for user login.
Parameters	<string 15> - The previously created <i>method_list_name</i> to delete.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete the method list name 'Trinity':

```
DES-1210-28/ME:5# delete authen_login method_list_name Trinity
Command: delete authen_login method_list_name Trinity
```

Success.

```
DES-1210-28/ME:5#
```

show authen_login

Purpose	To display a previously configured user defined method list of authentication methods for users logging on to the Switch.
Syntax	show authen_login [all default method_list_name <string 15>]
Description	The show authen_login command displays a list of authentication methods for user login.
Parameters	<p><i>default</i> – Displays the default method list for users logging on to the Switch.</p> <p><i>method_list_name</i> <string 15> - Specifies the <i>method_list_name</i> to display.</p> <p><i>all</i> – Displays all the authentication login methods currently configured on the Switch.</p> <p>The command displays the following parameters:</p> <ul style="list-style-type: none"> • Method List Name – The name of a previously configured method list name. • Method Name – Defines which security protocols are implemented, per method list name.
Restrictions	None.

Example usage:

To view all authentication login method list names:

```
DES-1210-28/ME:5# show authen_login all
Command: show authen_login all

Method List Name Priority Method Name Comment
-----
default            1      local      Keyword
Trinity            1      tacacs+    Built-in Group
                   2      radius     Built-in Group
                   3      local      Keyword

DES-1210-28/ME:5#
```

show authen_policy

Purpose	Used to display the system access authentication policy status on the Switch.
Syntax	show authen_policy
Description	The show authen_policy command display the system access authentication policy status on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the system access authentication policy:

```
DES-1210-28/ME:5# show authen_policy
Command: show authen_policy

Authentication Policy : Disabled

DES-1210-28/ME:5#
```

create authen_enable method_list_name

Purpose	To create a user-defined method list of authentication methods for promoting normal user level privileges to Administrator level privileges on the Switch
Syntax	create authen_enable method_list_name <string 12>
Description	The create authen_enable method_list_name command creates a list of authentication methods for promoting users with normal level privileges to Administrator level privileges using authentication methods on the Switch. Once a user acquires normal user level privileges on the Switch, he or she must be authenticated by a method on the Switch to gain administrator privileges on the Switch, which is defined by the Administrator. A maximum of eight (8) enable method lists can be implemented on the Switch.

Parameters	<string 12> - Defines the <i>authen_enable method_list_name</i> to be created as a string of up to 12 alphanumeric characters.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a user-defined method list, named 'Permit' for promoting user privileges to Administrator privileges:

```
DES-1210-28/ME:5# create authen_enable method_list_name Permit
Command: create authen_enable method_list_name Permit

Success.

DES-1210-28/ME:5#
```

config authen_enable

Purpose	To configure a user-defined method list of authentication methods for promoting normal user level privileges to Administrator level privileges on the Switch.
Syntax	config authen_enable [default method_list_name <string 15>] method {tacacs+ radius local server_group <string 15> none}
Description	<p>The config authen_enable command configures a user-defined list of authentication methods for promoting normal user level privileges to Administrator level privileges using authentication methods on the Switch. Once a user acquires normal user level privileges on the Switch, he or she must be authenticated by a method on the Switch to gain administrator privileges on the Switch, which is defined by the Administrator. A maximum of eight (8) enable method lists can be implemented simultaneously on the Switch.</p> <p>The sequence of methods implemented in this command affects the authentication result. For example, if a user enters a sequence of methods like <i>tacacs+ – radius – local_enable</i>, the Switch sends an authentication request to the first TACACS+ host in the server group. If no verification is found, the Switch sends an authentication request to the second TACACS+ host in the server group and so on, until the list is exhausted. At that point, the Switch restarts the same sequence with the following protocol listed, <i>radius</i>. If no authentication takes place using the <i>radius</i> list, the <i>local_enable</i> password set in the Switch is used to authenticate the user.</p> <p>Successful authentication using any of these methods gives the user an 'Admin' level privilege.</p>
Parameters	<p><i>default</i> – The default method list for administration rights authentication, as defined by the user. The user may choose one or more of the following authentication methods:</p> <ul style="list-style-type: none"> • <i>tacacs+</i> – Specifies that the user is to be authenticated using the TACACS+ protocol from the remote TACACS+ <i>server hosts</i> of the TACACS+ <i>server group</i> list. • <i>radius</i> – Specifies that the user is to be authenticated using the RADIUS protocol from the remote RADIUS <i>server hosts</i> of the RADIUS <i>server group</i> list. • <i>local</i> - Specifies that the user is to be authenticated using the local <i>user account</i> database on the Switch.

- *server_group* <string 15> – Specifies the server group name for authentication.
- *none* – Specifies that no authentication is required to access the Switch.

method_list_name <string 15> – Specifies a previously created *authen_enable method_list_name*. The user may add one or more of the following authentication methods to this method list:

- *tacacs+* – Specifies that the user is to be authenticated using the TACACS+ protocol from a remote TACACS+ server.
- *radius* - Specifies that the user is to be authenticated using the RADIUS protocol from a remote RADIUS server.
- *local* - Specifies that the user is to be authenticated using the local *user account* database on the Switch. The local enable password of the device can be configured using the '**config admin local_password**' command.
- *server_group* <string 15> – Specifies that the user is to be authenticated using the server group account database on the Switch.
- *none* – Specifies that no authentication is required to access the Switch.

Restrictions

Only Administrator or operator-level users can issue this command.

Example usage:

To configure the user defined method list 'Permit' with authentication methods TACACS+, RADIUS and local_enable, in that order.

```
DES-1210-28/ME:5# config authen_enable method_list_name Trinity method
tacacs+ radius local
Command: config authen_enable method_list_name Trinity method tacacs+ radius
local

Success.

DES-1210-28/ME:5#
```

delete authen_enable method_list_name

Purpose	To delete a user-defined list of authentication methods for promoting normal user level privileges to Administrator level privileges on the Switch.
Syntax	delete authen_enable method_list_name <string 15>
Description	The delete authen_enable method_list_name command deletes a user-defined list of authentication methods for promoting user level privileges to Administrator level privileges.
Parameters	<string 15> - The previously created <i>authen_enable method_list_name</i> to be deleted.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete the user-defined method list 'Permit'

```
DES-1210-28/ME:5# delete authen_enable method_list_name Permit
Command: delete authen_enable method_list_name Permit
```

```
Success.
```

```
DES-1210-28/ME:5#
```

show authen_enable

Purpose	To display the list of authentication methods for promoting normal user level privileges to Administrator level privileges on the Switch.
Syntax	show authen_enable [all default method_list_name <string 15>]
Description	The show authen_enable command deletes a user-defined list of authentication methods for promoting user level privileges to Administrator level privileges.
Parameters	<p><i>default</i> – Displays the default method list for users attempting to gain access to Administrator level privileges on the Switch.</p> <p><i>method_list_name <string 15></i> – The <i>method_list_name</i> to be displayed.</p> <p><i>all</i> – Displays all the authentication login methods currently configured on the Switch.</p> <p>The command displays the following parameters:</p> <ul style="list-style-type: none"> • Method List Name – The name of a previously configured method list name. • Method Name – Defines which security protocols are implemented, per method list name.
Restrictions	None.

Example usage:

To display all method lists for promoting user level privileges to administrator level privileges.

```
DES-1210-28/ME:5# show authen_enable all
Command: show authen_enable all
```

Method List Name	Priority	Method Name	Comment
default	1	local	Keyword

```
DES-1210-28/ME:5#
```

enable authen_policy

Purpose	To enable the authentication policy on the Switch.
Syntax	enable authen_policy
Description	The enable authen_policy command enables the authentication policy on the Switch.

Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the authentication policy:

```
DES-1210-28/ME:5# enable authen_policy
Command: enable authen_policy

Success.

DES-1210-28/ME:5#
```

disable authen_policy

Purpose	To disable the authentication policy on the Switch.
Syntax	disable authen_policy
Description	The disable authen_policy command disables the authentication policy on the Switch.
Parameters	None.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable the authentication policy:

```
DES-1210-28/ME:5# disable authen_policy
Command: disable authen_policy

Success.

DES-1210-28/ME:5#
```

config authen application

Purpose	To configure various applications on the Switch for authentication using a previously configured method list.
Syntax	config authen application {console http ssh all} [login enable] [default method_list_name <string 15>]
Description	The config authen application command configures Switch applications (console, Telnet, SSH) for login at the user level and at the administration level (<i>authen_enable</i>), utilizing a previously configured method list.
Parameters	<p><i>application</i> – Specifies the application to configure. One of the following four options may be selected:</p> <ul style="list-style-type: none"> • <i>console</i> – Configures the command line interface login method. • <i>http</i> – Configures the http login method. • <i>ssh</i> – Configures the Secure Shell login method. • <i>all</i> – Configures all applications as (console, Telnet, SSH)

login methods.

login – Configures an application for normal login on the user level, using a previously configured method list.

enable – Configures an application for upgrading a normal user level to administrator privileges, using a previously configured method list.

default – Configures an application for user authentication using the default method list.

method_list_name <string 15> – Configures an application for user authentication using a previously configured *method_list_name*.

Restrictions

Only Administrator or operator-level users can issue this command.

Example usage:

To configure the default method list for the command line interface:

```
DES-1210-28/ME:5# config authen application http login default
```

```
Command: config authen application http login default
```

```
Success.
```

```
DES-1210-28/ME:5#
```

show authen application

Purpose	To display authentication methods for the various applications on the Switch.
Syntax	show authen application
Description	The show authen application command displays all of the authentication method lists (login, enable administrator privileges) for Switch configuration applications (console, Telnet, SSH) currently configured on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the login and enable method list for all applications on the Switch:

```
DES-1210-28/ME:5# show authen application
```

```
Command: show authen application
```

```

Application Login Method List  Enable Method List
-----
Console      default                    default
Telnet       default                    default
SSH          default                    default
HTTP         default                    default

```

```
DES-1210-28/ME:5#
```

config authen parameter

Purpose	To provide user to configure the authentication parameters on the Switch.
Syntax	config authen parameter [attempt <int 1-255> response_timeout <int 0-255>]
Description	The config authen parameter attempt command provides user to configure the authentication parameters on the Switch.
Parameters	<i>attempt <integer 1-255></i> – Specifies the attempt of authentication parameter on the Switch. The value range is between 1 and 255. <i>response_timeout <integer 0-255></i> – Specifies the response timeout of authentication parameter on the Switch. The value range is between 0 and 255.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the default method list for the command line interface:

```
DES-1210-28/ME:5# config authen parameter attempt 10
Command: config authen parameter attempt 10

Success.

DES-1210-28/ME:5#
```

show authen parameter

Purpose	To display authentication parameters for the various applications on the Switch.
Syntax	show authen parameter
Description	The show authen parameter command displays the authentication parameter on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display the authentication parameters for all applications on the Switch:

```
DES-1210-28/ME:5# show authen parameter
Command: show authen parameter

Response Timeout : 10 seconds
User Attempts   : 10

DES-1210-28/ME:5#
```

create authen server_host

Purpose	To create an authentication server host.
Syntax	create authen server_host <ipaddr> protocol [radius tacacs+] {port <int 1-65535> key [<string 254> none] timeout <int 1-255> retransmit <int 1-255>}
Description	The create authen server_host command creates an authentication server host for the TACACS+/RADIUS security protocols on the Switch. When a user attempts to access the Switch with authentication protocol enabled, the Switch sends authentication packets to a remote TACACS+/RADIUS server host on a remote host. The TACACS+/RADIUS server host then verifies or denies the request and returns the appropriate message to the Switch. More than one authentication protocol can be run on the same physical server host but, remember that TACACS+/RADIUS are separate entities and are not compatible with each other. The maximum supported number of server hosts is 16.
Parameters	<p><i>server_host</i> <ipaddr> – The IP address of the remote server host to add.</p> <p><i>protocol</i> – The protocol used by the server host. The options are:</p> <ul style="list-style-type: none"> • <i>tacacs+</i> – Specifies that the server host utilizes the TACACS+ protocol. • <i>radius</i> – Specifies that the server host utilizes the RADIUS protocol. <p><i>port</i> <int 1-65535> – The virtual port number of the authentication protocol on a server host. The value must be between 1 and 65535. The default port number is 49 for TACACS/TACACS+ servers and 1812 and 1813 for RADIUS servers but the user may set a unique port number for higher security.</p> <p><i>key</i> [<string 254> none] – The authentication key to be shared with a configured TACACS+ or RADIUS server only. The value is a string of up to 254 alphanumeric characters, or <i>none</i>.</p> <p><i>timeout</i> <int 1-255> – The time in seconds the Switch waits for the server host to reply to an authentication request. The default value is 5 seconds.</p> <p><i>retransmit</i> <int 1-255> – The number of times the device resends an authentication request when the server does not respond. The value is between 1 and 255. This field is inoperable for the TACACS+ protocol.</p>
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a TACACS+ authentication server host, with port number 1234, a timeout value of 10 seconds and a retransmit count of 5.

```
DES-1210-28/ME:5# create authn server_host 10.1.1.121 protocol tacacs+ port
1234 timeout 10 retransmit 5
```

```
Command: create authn server_host 10.1.1.121 protocol tacacs+ port 1234
timeout 10 retransmit 5
```

Key is empty for TACACS+ or RADIUS.

Retransmit is meaningless for TACACS+.

Success.

```
DES-1210-28/ME:5#
```

config authn server_host

Purpose	To configure a user-defined authentication server host.
Syntax	config authn server_host <ipaddr> protocol [tacacs+ radius] {port <int 1-65535> key [<string 254> none] timeout <int 1-255> retransmit <int 1-255>}
Description	The config authn server_host command configures a user-defined authentication server host for the TACACS+/RADIUS security protocols on the Switch. When a user attempts to access the Switch with the authentication protocol enabled, the Switch sends authentication packets to a remote TACACS+/RADIUS server host on a remote host. The TACACS+/RADIUS server host then verifies or denies the request and returns the appropriate message to the Switch. More than one authentication protocol can be run on the same physical server host but, remember that TACACS+/RADIUS are separate entities and are not compatible with each other. The maximum supported number of server hosts is 16.
Parameters	<p><i>server_host <ipaddr></i> – The IP address of the remote server host the user wishes to alter.</p> <p><i>protocol</i> – The protocol used by the server host. The options are:</p> <ul style="list-style-type: none"> • <i>tacacs+</i> – Specifies that the server host utilizes the TACACS+ protocol. • <i>radius</i> – Specifies that the server host utilizes the RADIUS protocol. <p><i>port <int 1-65535></i> – The virtual port number of the authentication protocol on a server host. The value must be between 1 and 65535. The default port number is 49 for TACACS/TACACS+ servers and 1812 and 1813 for RADIUS servers but the user may set a unique port number for higher security.</p> <p><i>key [<string 254> none]</i> – The authentication key to be shared with a configured TACACS+ or RADIUS server only. The value is a string of up to 254 alphanumeric characters, or <i>none</i>.</p> <p><i>timeout <int 1-255></i> – The time in seconds the Switch waits for the server host to reply to an authentication request. The default value is 5 seconds.</p> <p><i>retransmit <int 1-255></i> – The number of times the device resends an authentication request when the server does not respond. The value is between 1 and 255. This field is inoperable for the TACACS+ protocol.</p>

Restrictions	Only Administrator or operator-level users can issue this command.
--------------	--

Example usage:

To configure a TACACS+ authentication server host, with port number 4321, a timeout value of 12 seconds and a retransmit count of 4.

```
DES-1210-28/ME:5# config authn server_host 10.1.1.121 protocol tacacs+ port 4321 timeout 12 retransmit 4
```

```
Command: config authn server_host 10.1.1.121 protocol tacacs+ port 4321 timeout 12 retransmit 4
```

Retransmit is meaningless for TACACS+.

Success.

```
DES-1210-28/ME:5#
```

delete authn server_host

Purpose	To delete a user-defined authentication server host.
Syntax	delete authn server_host <ipaddr> protocol [tacacs+ radius]
Description	The delete authn server_host command deletes a user-defined authentication server host previously created on the Switch.
Parameters	<p><i>server_host <ipaddr></i> - The IP address of the remote server host to be deleted.</p> <p><i>protocol</i> – The protocol used by the server host the user wishes to delete. The options are:</p> <ul style="list-style-type: none"> • <i>tacacs+</i> – Specifies that the server host utilizes the TACACS+ protocol. • <i>radius</i> – Specifies that the server host utilizes the RADIUS protocol.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a user-defined RADIUS authentication server host:

```
DES-1210-28/ME:5# delete authn server_host 10.1.1.121 protocol radius
```

```
Command: delete authn server_host 10.1.1.121 protocol radius
```

Success.

```
DES-1210-28/ME:5#
```

show authn server_host

Purpose	To view a user-defined authentication server host.
Syntax	show authn server_host
Description	The show authn server_host command displays user-defined

	<p>authentication server hosts previously created on the Switch.</p> <p>The following parameters are displayed:</p> <p>IP Address – The IP address of the authentication server host.</p> <p>Protocol – The protocol used by the server host. Possible results include TACACS+ or RADIUS.</p> <p>Port – The virtual port number on the server host. The default value is 49.</p> <p>Timeout - The time in seconds the Switch waits for the server host to reply to an authentication request.</p> <p>Retransmit - The value in the retransmit field denotes how many times the device resends an authentication request when the TACACS server does not respond. This field is inoperable for the tacacs+ protocol.</p> <p>Key - Authentication key to be shared with a configured TACACS+ server only.</p>
Parameters	None.
Restrictions	None.

Example usage:

To view authentication server hosts currently set on the Switch:

```
DES-1210-28/ME:5# show authen server_host
Command: show authen server_host

IP Address      Protocol Port  Timeout Retransmit Key
-----
10.1.1.121     tacacs+ 4321  ----- -1

Total Entries : 1

DES-1210-28/ME:5#
```

create authen server_group

Purpose	To create an authentication server host.
Syntax	create authen server_group <string 15>
Description	The create authen server_group command creates an authentication server group for the protocols on the Switch.
Parameters	<string 15> – Defines the authentication group name as a string of up to 15 alphanumeric characters.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To create a server group “dlinkgroup”:

```
DES-1210-28/ME:5# create authen server_group dlinkgroup
Command: create authen server_group dlinkgroup
```

```
Success.
```

```
DES-1210-28/ME:5#
```

config authen server_group

Purpose	To configure a user-defined authentication server host.
Syntax	config authen server_group [<string 15> radius tacacs+] [add delete] server_host <ipaddr> protocol [radius tacacs+]
Description	The config authen server_group command configures a user-defined authentication server group for the TACACS+/RADIUS security protocols on the Switch. When a user attempts to access the Switch with the authentication protocol enabled, the Switch sends authentication packets to a remote TACACS+/RADIUS server group on a remote host. The TACACS+/RADIUS server group then verifies or denies the request and returns the appropriate message to the Switch. More than one authentication protocol can be run on the same physical server host but, remember that TACACS+/RADIUS are separate entities and are not compatible with each other. The maximum supported number of server group is 16.
Parameters	<p><string 15> – Defines the authentication group name as a string of up to 15 alphanumeric characters.</p> <p>server_host <ipaddr> – The IP address of the remote server group the user wishes to alter.</p> <p>[add delete] – Specifies the authentication server host will be add or deleted of the server group.</p> <p>protocol – The protocol used by the server host. The options are:</p> <ul style="list-style-type: none"> • <i>tacacs+</i> – Specifies that the server host utilizes the TACACS+ protocol. • <i>radius</i> – Specifies that the server host utilizes the RADIUS protocol.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure a RADIUS authentication server group:

```
DES-1210-28/ME:5# config authen server_group dlinkgroup add server_host
10.1.1.121 protocol radius
Command: config authen server_group dlinkgroup add server_host 10.1.1.121
protocol radius
```

```
Success.
```

```
DES-1210-28/ME:5#
```

delete authen server_group

Purpose	To delete a user-defined authentication server host.
Syntax	delete authen server_group <string 15>
Description	The delete authen server_group command deletes a user-defined authentication server group previously created on the Switch.
Parameters	<string 15> –Specifies the authentication server group name to be deleted.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To delete a user-defined rd1 authentication server group:

```
DES-1210-28/ME:5# delete authen server_group dlinkgroup
Command: delete authen server_group dlinkgroup
```

```
Success.
```

```
DES-1210-28/ME:5#
```

show authen server_host

Purpose	To view a user-defined authentication server host.
Syntax	show authen server_group {<string 15>}
Description	The show authen server_group command displays user-defined authentication server groups previously created on the Switch. The following parameters are displayed: Group Name – The name of the server group. IP Address – The IP address of the authentication server group. Protocol – The protocol used by the server group. Possible results include TACACS+ or RADIUS.
Parameters	None.
Restrictions	None.

Example usage:

To view authentication server hosts currently set on the Switch:


```
DES-1210-28/ME:5# show authen server_group
```

```
Command: show authen server_group
```

Group Name	IP Address	Protocol
-----	-----	-----
tacacs+	10.1.1.121	tacacs+
radius	10.1.1.121	radius

```
Total Entries : 2
```

```
DES-1210-28/ME:5#
```

enable admin

Purpose	To promote user level privileges to administrator level privileges.
Syntax	enable admin
Description	The enable admin command enables a user to be granted administrative privileges on to the Switch. After logging on to the Switch, users have only 'user' level privileges. To gain access to administrator level privileges, the user may enter this command. The system then prompts for an authentication password. Possible authentication methods for this function include TACACS, TACACS+, RADIUS, user defined server groups, local enable (local account on the Switch), or no authentication (none). Because TACACS does not support the enable function, the user must create a special account on the server host which has the username 'enable', and a password configured by the administrator that will support the 'enable' function. This function becomes inoperable when the authentication policy is disabled.
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To enable administrator privileges on the Switch:

```
DES-1210-28/ME:5# enable admin
```

```
Command: enable admin
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config admin local_enable

Purpose	To configure the local_enable password for administrator level privileges.
Syntax	config admin local_enable
Description	The config admin local_enable command changes the locally enabled password for the local_enable admin command. When a user chooses the ' <i>local_enable</i> ' method to promote user level

	<p>privileges to administrator privileges, the user is prompted to enter the password configured here.</p> <p>After entering the config admin local_enable command, the user is prompted to enter the old password, then a new password in a string of no more than 15 alphanumeric characters, and finally prompted to enter the new password again for confirmation. See the example below.</p>
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To configure the password for the 'local_enable' authentication method.

```

DES-1210-28/ME:5# config admin local_enable
Command: config admin local_enable

Enter the old password:
Enter the case-sensitive new password:*****
Enter the new password again for confirmation:*****
Success.

DES-1210-28/ME:5#

```

LACP COMMANDS

The LACP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config lacp port_priority	<portlist> <value 1-65535> [timeout <long short>]
show lacp	{<portlist>}

Each command is listed in detail, as follows:

config lacp port_priority	
Purpose	To set the priority value of a physical port in an LACP group.
Syntax	config lacp port_priority <portlist> <value 1-65535> [timeout <long short>]
Description	The config lacp port_priority command sets the LACP priority value and administrative timeout of a physical port or range of ports in an LACP group.
Parameters	<p><i><portlist></i> - A port or range of ports to be configured.</p> <p><i><value 1-65535></i> - Specifies the LACP priority value for a port or range of ports to be configured. The default is 1.</p> <p><i><timeout></i> - Specifies the administrative LACP timeout.</p> <ul style="list-style-type: none"> <i>long</i> – Specifies the LACP timeout to be 90 seconds. This is the default. <i>short</i> – Specifies the LACP timeout to be 3 seconds.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure the LACP priority of ports 1-5:

```
DES-1210-28/ME:5# config lacp port_priority 1-5 100 timeout long
Command: config lacp port_priority 1-5 100 timeout long
```

```
Success
DES-1210-28/ME:5#
```

show lacp	
Purpose	To display current LACP port mode settings.
Syntax	show lacp {<portlist>}
Description	The show lacp command displays the current LACP mode settings.
Parameters	<i><portlist></i> - A port or range of ports whose LACP settings are to be

	displayed. If no parameter is specified, the system displays the current LACP status for all ports.
Restrictions	None.

Example usage:

To display LACP information for port1~5:

```
DES-1210-28/ME:5# show lacp 1-5
Command: show lacp 1-5

Port Priority Timeout
-----
1      100      90 sec
2      100      90 sec
3      100      90 sec
4      100      90 sec
5      100      90 sec
DES-1210-28/ME:5#
```

LLDP COMMANDS

The LLDP commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
enable lldp	
disable lldp	
config lldp message_tx_interval	<sec 5-32768>
config lldp message_tx_hold_multiplier	<int 2-10>
config lldp reinit_delay	<sec 1-10>
config lldp tx_delay	<sec 1-8192>
show lldp	
show lldp ports	{<portlist>}
show lldp local_ports	{<portlist>} {mode[brief normal detailed]}
show lldp remote_ports	{<portlist>} {mode[brief normal detailed]}
config lldp ports	[<portlist> all] notification [enable disable]
config lldp ports	[<portlist> all] admin_status [tx_only rx_only tx_and_rx disable]
config lldp ports	[<portlist> all] mgt_addr ipv4 <ipaddr> [enable disable]
config lldp ports	[<portlist> all] basic_tlvs [all {port_description system_name system_description system_capabilities}] [enable disable]
config lldp ports ports	[<portlist> all] dot3_tlvs [all link aggregation mac_phy_configuration_status maximum_frame_size power_via_mdi] [enable disable]
config lldp ports ports	[<portlist> all] dot1_tlv_pvid [disable enable]
config lldp ports ports	[<portlist> all] dot1_tlv_protocol_identity [all eapol gvrp lacp stp][disable enable]
config lldp ports ports	[<portlist> all] dot1_tlv_vlan_name [vlan <vlan_name 32> vlanid <vidlist>] [disable enable]
show lldp mgt_addr	{ipv4 <ipaddr>}
show lldp statistics	{ports <portlist>}

Each command is listed in detail, as follows:

enable lldp

Purpose	To enable LLDP on the switch.
Syntax	enable lldp

Description	The enable lldp command enables the <i>Link Layer Discovery Protocol</i> (LLDP) on the switch.
Parameters	None
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable LLDP on the switch:

```
DES-1210-28/ME:5# enable lldp
Command: enable lldp

Success!

DES-1210-28/ME:5#
```

disable lldp

Purpose	To disable LLDP on the switch.
Syntax	disable lldp
Description	The disable lldp command disables the <i>Link Discovery Protocol</i> (LLDP) on the switch.
Parameters	None
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To disable LLDP on the switch:

```
DES-1210-28/ME:5# disable lldp
Command: disable lldp

Success!

DES-1210-28/ME:5#
```

config lldp message_tx_interval

Purpose	To define the lldp message tx interval
Syntax	config lldp message_tx_interval <sec 5-32768>
Description	The config lldp message_tx_interval defines the lldp message interval of the incoming messages.
Parameters	<sec 5-32768> – Defines the message interval time. The range is between 5 and 32768.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP message tx interval on the switch:

```
DES-1210-28/ME:5# config lldp message_tx_interval 10
Command: config lldp message_tx_interval 10

Success!

DES-1210-28/ME:5#
```

config lldp message_tx_hold_multiplier

Purpose	To define the lldp hold-multiplier on the switch.
Syntax	config lldp message_tx_hold_multiplier <int 2-10>
Description	The config lldp message_tx_hold_multiplier command specifies the amount of time the receiving device should hold a <i>Link Layer Discovery Protocol</i> (LLDP) packet before discarding it.
Parameters	<i>Message_tx_hold_multiplier (int 2-10)</i> – Specifies the hold time to be sent in the LLDP update packets as a multiple of the timer value. (Range: 2-10). The default configuration is 4.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP Message tx hold multiplier settings:

```
DES-1210-28/ME:5# config lldp message_tx_hold_multiplier 2
Command: config lldp message_tx_hold_multiplier 2

Success!

DES-1210-28/ME:5#
```

config lldp reinit_delay

Purpose	To define the lldp reinit-delay on the switch.
Syntax	config lldp reinit_delay <sec 1-10>
Description	The lldp reinit_delay seconds command specifies the minimum time an LLDP port will wait before reinitializing LLDP transmission.
Parameters	<sec 1-10> – Specifies the minimum time in seconds an LLDP port will wait before reinitializing LLDP transmission. The range is 1 – 10 seconds. The default configuration is 2 seconds.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP reinit delay:

```
DES-1210-28/ME:5# config lldp reinit_delay 1
Command: config lldp reinit_delay 1

Success!

DES-1210-28/ME:5#
```

config lldp tx_delay

Purpose	To configure the lldp tx_delay on the switch.
Syntax	config lldp tx_delay <sec 1-8192>
Description	The config lldp tx_delay command specifies the delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB, use the lldp tx_delay command in global configuration mode.
Parameters	<sec 1-8192> – Specifies the minimum time in seconds an LLDP port will wait before reinitializing LLDP transmission. The range is 1 – 8192 seconds. The default configuration is 2 seconds.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP tx delay:

```
DES-1210-28/ME:5# config lldp tx_delay 1
Command: config lldp tx_delay 1

Success!

DES-1210-28/ME:5#
```

show lldp

Purpose	To display the <i>Link Layer Discovery Protocol</i> (LLDP) on the switch.
Syntax	show lldp
Description	The show lldp displays the LLDP configuration on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To show LLDP settings:


```

DES-1210-28/ME:5# show lldp
Command: show lldp

LLDP System Information
  Chassis Id Subtype   : MAC Address
  Chassis Id          : 00-B2-FD-DA-EE-EB
  System Name         :
  System Description   : DES-1210-28/ME      6.00.011
  System Capabilities : Bridge

LLDP Configurations
  LLDP Status         : Enable
  Message Tx Interval : 10
  Message Tx Hold Multiplier: 2
  Reinit Delay       : 1
  Tx Delay           : 1
  Notification Interval : 5

DES-1210-28/ME:5#

```

show lldp ports

Purpose	To display the <i>Link Layer Discovery Protocol</i> (LLDP) ports configuration on the switch.
Syntax	show lldp ports {<portlist>}
Description	The show lldp ports command displays the information regarding the ports.
Parameters	<portlist> – A port or range of ports to be displayed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To show the information for port 1:

```

DES-1210-28/ME:5# show lldp ports 1
Port ID                : 1
-----
Admin Status           : TX_and_RX
Notification Status    : Disable
Advertised TLVs Option :
  Port Description     : Disable
  Port Description     : Disable
  Port Description     : Disable
  Port Description     : Disable
Enabled Management Address
  (NONE)
Port VLAN ID           : Disable
Enabled Port_and_Protocol_VLAN_ID
  (None)
Enabled VLAN Name     : (None)
Enabled Protocol_Identity
  (None)
MAC/PHY Configuration/Status : Disable
Power Via MDI         : Disable
Link Aggregation      : Disable
Maximum Frame Size    : Disable
DES-1210-28/ME:5#

```

show lldp local_ports

Purpose	To display the <i>Link Layer Discovery Protocol</i> (LLDP) configuration that is advertised from a specific port.
Syntax	show lldp local_ports {<portlist>} {mode[brief normal detailed]}
Description	The show lldp local_ports command displays the configuration that is advertised from a specific port.
Parameters	<portlist> – A port or range of ports to be displayed. {mode[brief normal detailed]} – defines which mode of information want to be displayed, brief, normal or detailed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To show the local port information for port 1 with mode brief:

```

DES-1210-28/ME:5# show lldp local_ports 1 mode brief
Command: show lldp local_ports 1 mode brief

Port ID : 1
-----
Port ID Subtype      : Interface Alias
Port ID              : Slot0/1
Port ID Description  : Ethernet Interface
DES-1210-28/ME:5#

```

show lldp remote_ports

Purpose	To display information regarding the neighboring devices discovered using LLDP.
Syntax	show lldp remote_ports {<portlist>} {mode[brief normal detailed]}
Description	The show lldp remote_ports command displays the information regarding neighboring devices.
Parameters	<i><portlist></i> – A port or range of ports to be displayed. <i>[mode[brief normal detailed]]</i> – defines which mode of information want to be displayed, brief, normal or detailed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To show the information for remote ports:

```
DES-1210-28/ME:5# show lldp remote_ports 1 mode normal
Command: show lldp remote_ports 1 mode normal

Port ID : 1
-----
Remote Entities Count : 0
(NONE)

DES-1210-28/ME:5#
```

config lldp ports

Purpose	To enable LLDP notification on a port or ports.
Syntax	config lldp ports [<portlist> all] notification [enable disable]
Description	The config lldp ports notification command defines lldp notification per port on the switch.
Parameters	<i>ports</i> – Specify a port or ports to be configured. <i>notification [enable disable]</i> – defines is notification is enabled or disabled.
Restrictions	Only Administrator or operator-evel users can issue this command.

Example usage:

To configure LLDP notification:

```
DES-1210-28/ME:5# config lldp ports 1-3 notification enable
Command: config lldp ports 1-3 notification enable

Success!

DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP admin status on a port or ports.
Syntax	config lldp ports [<portlist> all] admin_status [tx_only rx_only tx_and_rx disable]

Description	The config lldp ports admin status command defines lldp admin status per port on the switch.
Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>Admin status</i> – defines admin status of ports on the switch Tx- Tx only Rx – Rx only Both – Tx and RX Disable – admin status disabled.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP admin status

```
DES-1210-28/ME:5# config lldp ports 2 admin_status disable
Command: config lldp ports 2 admin_status disable

Success!

DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP management address advertisement on a port or ports.
Syntax	config lldp ports [<i><portlist></i> <i>all</i>] mgt_addr ipv4 <i><ipaddr></i> [enable disable]
Description	The config lldp mgt_addr command defines if lldp will advertise the switch's IP address the command is per port on the switch.
Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>mgt_addr ipv4 <ipaddr></i> – defines whether the management address (IP address) advertisement will be enabled or disabled
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP management address advertisement

```
DES-1210-28/ME:5# config lldp ports 1 mgt_addr ipv4 100.1.1.2 enabled
Command: config lldp ports 1 mgt_addr ipv4 100.1.1.2 enabled

Success!

DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP management basic TLVs advertisement on a port or ports.
Syntax	config lldp ports [<i><portlist></i> <i>all</i>] basic_tlvs [all {port_description system_name system_description system_capabilities}] [enable disable]
Description	The config lldp basic TLVs command defines if lldp will advertise

	the switch's basic TLVs the command is per port on the switch.
Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>Basic TLVs</i> <i>all</i> – Advertisement of all the basic TLVs <i>port description</i> – Advertisement of <i>Port description</i> <i>system name</i> – Advertisement of <i>system name</i> <i>system description</i> – Advertisement of <i>System description</i> <i>system capabilities</i> – Advertisement of system capabilities
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP Basis TLVs

```
DES-1210-28/ME:5# config lldp ports 1 basic_tlvs all enable
Command: config lldp ports 1 basic_tlvs all enable
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP management basic TLVs advertisement on a port or ports.
Syntax	config lldp ports ports [<portlist> all] dot3_tlvs [all link aggregation mac_phy_configuration_status maximum_frame_size power_via_mdi] [enable disable]
Description	The config lldp dot3 TLVs command defines if lldp will advertise the mac_phy_configuration_status the command is per port on the switch.
Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>dot3_tlvs</i> – defines if the advertisement is enabled or disabled. The possible values are: link_aggregation, mac_phy_configuration_status, maximum_frame_size, power_via_mdi or all.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP mac_phy_configuration status:

```
DES-1210-28/ME:5# config lldp ports 2 dot3_tlvs mac_phy_configuration_status
enable
Command: config lldp ports 2 dot3_tlvs mac_phy_configuration_status enable
```

```
Success!
```

```
DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP management basic TLVs advertisement on a port or ports.
Syntax	config lldp ports ports [<portlist> all] dot1_tlv_pvid [disable enable]
Description	The config lldp ports dot1 TLVs command defines if lldp will advertise the mac_phy_configuration_status the command is per port on the switch.

Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>[enable disable]</i> - Defines if the advertisement is enabled or disabled.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP TLV PVID:

```
DES-1210-28/ME:5# config lldp ports all dot1_tlv_pvid disable
Command: config lldp ports all dot1_tlv_pvid disable

Success!

DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP management basic TLVs advertisement on a port or ports.
Syntax	config lldp ports ports [<portlist> all] dot1_tlv_protocol_identity [all eapol gvrp lacp stp][disable enable]
Description	The config lldp ports dot1 TLVs command defines if lldp will advertise the mac_phy_configuration_status the command is per port on the switch.
Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>dot1_tlv_protocol_identity</i> – Defines if the advertisement is enabled or disabled. The possible values are: eapol, gvrp, lacp, stp or all.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP ports configuration status:

```
DES-1210-28/ME:5# config lldp ports all dot1_tlv_protocol_identity eapol enable
Command: config lldp ports all dot1_tlv_protocol_identity eapol enable

Success!

DES-1210-28/ME:5#
```

config lldp ports

Purpose	To define LLDP management basic TLVs advertisement on a port or ports.
Syntax	config lldp ports ports [<portlist> all] dot1_tlv_vlan_name [vlan <vlan_name 32> vlanid <vidlist>] [disable enable]
Description	The config lldp ports dot1 TLVs command defines lldp admin status per port on the switch.
Parameters	<i>[<portlist> all]</i> – Specify a port or ports to be configured. <i>vlan <vlan_name 32></i> –The name of the VLAN to be configured. <i>dot1_tlv_vlan_name</i> – Defines if the advertisement is enabled or disabled. <i>vlanid <vidlist></i> –The vid of the VLAN to be configured.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To configure LLDP mac_phy_configuration status:

```
DES-1210-28/ME:5# config lldp ports all dot1_tlv_vlan_name vlanid 1 disable
Command: config lldp ports all dot1_tlv_vlan_name vlanid 1 disable
```

Success!

```
DES-1210-28/ME:5#
```

show lldp mgt_addr

Purpose	To display the <i>Link Layer Discovery Protocol</i> (LLDP) configuration that is advertised from a specific port.
Syntax	show lldp mgt_addr {ipv4 <ipaddr>}
Description	The show lldp mgt_addr command displays the information regarding the ipv4 address.
Parameters	<i>ipv4 <ipaddr></i> –Specifies the lldp ipv4 address to be displayed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To show the LLDP management address advertisement:

```
DES-1210-28/ME:5# show lldp mgt_addr
Command: show lldp mgt_addr
```

```
Total Address : 0
```

```
DES-1210-28/ME:5#
```

show lldp statistics

Purpose	To display the <i>Link Layer Discovery Protocol</i> (LLDP) statistics for the specified ports.
Syntax	show lldp statistics {ports <portlist>}
Description	The show lldp statistics command displays the statistics of LLDP on the Switch.
Parameters	<i>{ports <portlist>}</i> – Specifies the ports to be displayed.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To show the LLDP statistics for port 15:

```
DES-1210-28/ME:5# show lldp statistics ports 15
Command: show lldp statistics ports 15

Port ID : 15
-----
lldpStatsTxPortFramesTotal      : 0
lldpStatsRxPortFramesDiscardedTotal : 0
lldpStatsRxPortFramesErrors     : 0
lldpStatsRxPortFramesTotal      : 0
lldpStatsRxPortTLVsDiscardedTotal : 0
lldpStatsRxPortTLVsUnrecognizedTotal : 0
lldpStatsRxPortAgeoutsTotal     : 0

DES-1210-28/ME:5#
```


ACCESS CONTROL LIST COMMANDS

The Access Control List commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
create access_profile	[ethernet {vlan source_mac <macmask> destination_mac <macmask> 802.1p ethernet_type} ip {source_ip_mask <netmask> destination_ip_mask <netmask> dscp [icmp {type code} igmp {type} tcp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)> flag_mask} udp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)>} protocol_id_mask <hex (0x0-0xff)>] } packet_content_mask {[offset1 offset2 offset3 offset4] [I2 I3 I4] <value (0-31)> <hex 0x0-0xffff>} profile_id <value (1-50)>
config access_profile	[profile_id <value (1-50)>] [add access_id [auto_assign <value (1-250)>]] [ethernet {vlan <vlanid (1-4094)> source_mac <macaddr> destination_mac <macaddr> 802.1p <value (0-7)> ethernet_type <hex (0x0-0xffff)>} ip {source_ip <ipaddr> destination_ip <ipaddr> dscp <value (0-63)> [icmp {type <value (0-255)> code <value (0-255)>} igmp {type <value (0-255)>} tcp {src_port <value (0-65535)> dst_port <value (0-65535)> urg ack psh rst syn fin} udp {src_port <value (0-65535)> dst_port <value (0-65535)>} protocol_id <value(0-255)>}] packet_content {offset1 <hex (0x0-0xffffffff)> offset2 <hex (0x0-0xffffffff)> offset3 <hex (0x0-0xffffffff)> offset4 <hex (0x0-0xffffffff)>}] [port [<portlist> all] [permit {replace_priority_with <value (0-7)> replace_dscp_with <value (0-63)>} rx_rate {no_limit <value (64-1024000)>}] mirror deny]] delete access_id <value (1-250)>]
delete access_profile	profile_id <value 1-50>
show access_profile	{profile_id <value 1-50>}
create cpu_access_profile	[ethernet {vlan source_mac <macmask> destination_mac <macmask> 802.1p ethernet_type} ip {source_ip_mask <netmask> destination_ip_mask <netmask> dscp [icmp {type code} igmp {type} tcp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)> flag_mask} udp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)>} protocol_id_mask <hex (0x0-0xff)>] }] profile_id <value (1-3)>
config cpu_access_profile	[profile_id <value (1-3)>] [add access_id [auto_assign <value (1-5)>]] [ethernet {vlan <vlanid (1-4094)> source_mac <macaddr> destination_mac <macaddr> 802.1p <value (0-7)> ethernet_type <hex (0x0-0xffff)>} ip {source_ip <ipaddr> destination_ip <ipaddr> dscp <value (0-63)> [icmp {type <value (0-255)> code <value (0-255)> } igmp {type <value (0-255)>} tcp {src_port <value (0-65535)> dst_port <value (0-65535)> urg ack psh rst syn fin} udp {src_port <value (0-65535)> dst_port <value (0-65535)>} protocol_id <value(0-255)>}] [port [<portlist> all] [permit deny]] delete access_id <value (1-5)>]
delete cpu access_profile	profile_id <value 1-3>
show cpu access_profile	{profile_id <value 1-3>}

Each command is listed in detail, as follows:

create access_profile

Purpose	To create an access profile on the Switch by examining the Ethernet part of the packet header. Masks entered are combined with the values the Switch finds in the specified frame header fields. Specific values for the rules are entered using the config access_profile command, below.
Syntax	create access_profile [ethernet {vlan source_mac <macmask> destination_mac <macmask> 802.1p ethernet_type} ip {source_ip_mask <netmask> destination_ip_mask <netmask> dscp [icmp {type code} igmp {type} tcp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)> flag_mask} udp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)>} protocol_id_mask <hex (0x0-0xff)> }] packet_content_mask {[offset1 offset2 offset3 offset4] [I2 I3 I4] <value (0-31)> <hex 0x0-0xffff> profile_id <value (1-50)>
Description	The create access_profile command creates a profile for packets that may be accepted or denied by the Switch by examining the Ethernet part of the packet header. Specific values for rules pertaining to the Ethernet part of the packet header may be defined by configuring the config access_profile command for Ethernet, as stated below.
Parameters	<p><i>ethernet</i> - Specifies that the Switch examines the layer 2 part of each packet header with emphasis on one or more of the following:</p> <ul style="list-style-type: none"> • <i>vlan</i> – Specifies that the Switch examine the VLAN part of each packet header. • <i>source_mac <macmask></i> – Specifies a MAC address mask for the source MAC address. This mask is entered in the following hexadecimal format: 000000000000-FFFFFFFFFFFF. • <i>destination_mac <macmask></i> – Specifies a MAC address mask for the destination MAC address in the following format: 000000000000-FFFFFFFFFFFF. • <i>802.1p</i> – Specifies that the Switch examine the 802.1p priority value in the frame's header. <p><i>ethernet_type</i> – Specifies that the Switch examine the Ethernet type value in each frame's header.</p> <p><i>ip</i> - Specifies that the Switch examines the IP fields in each packet with special emphasis on one or more of the following:</p> <p><i>icmp</i> – Specifies that the Switch examines the Protocol field in each frame's IP header , and that the value must be 1 (Internet Control Message Protocol- ICMP) for the action to take place.</p> <ul style="list-style-type: none"> • <i>type</i> – Specifies that the Switch examines each frame's ICMP Type field. • <i>code</i> – Specifies that the Switch examines each frame's ICMP Code field. <p><i>igmp</i> – Specifies that the Switch examine each frame's protocol field and it must be 2 (Internet Group Management Protocol- IGMP) for the action to take place.</p> <ul style="list-style-type: none"> • <i>type</i> – Specifies that the Switch examine each frame's IGMP Type field. <p><i>tcp</i> – Specifies that the Switch examines each frames protocol field and its value must be 6 (Transmission Control Protocol-</p>

TCP) for the action to take place.

- *src_port_mask* <hex 0x0-0xffff> – Specifies a TCP port mask for the source port.
- *dst_port_mask* <hex 0x0-0xffff> – Specifies a TCP port mask for the destination port.
- *flag_mask* – Specifies the appropriate flag_mask parameter.

udp – Specifies that the Switch examines each frame's protocol field and its value must be 17 (User Datagram Protocol-UDP) in order for the action to take place..

- *src_port_mask* <hex 0x0-0xffff> – Specifies a UDP port mask for the source port.
- *dst_port_mask* <hex 0x0-0xffff> – Specifies a UDP port mask for the destination port.

packet_content_mask – Specifies the frame content mask.

[*offset1* | *offset2* | *offset3* | *offset4*] – Specifies the mask pattern offset of frame.

profile_id <value 1-50> – Specifies an index number between 1 and 50 that identifies the access profile being created with this command.

Restrictions

Only administrator or operate-level users can issue this command.

Example usage:

To create an Ethernet access profile:

```
DES-1210-28/ME:5# create access_profile ethernet vlan 802.1p profile_id 1
```

```
Command: create access_profile ethernet vlan 802.1p profile_id 1
```

Success.

```
DES-1210-28/ME:5#
```

config access_profile

Purpose	To create an access profile on the Switch by examining the Ethernet part of the packet header. Masks entered are combined with the values the Switch finds in the specified frame header fields. Specific values for the rules are entered using the config access_profile ethernet command, below.
Syntax	config access_profile [profile_id <value (1-50)>] [add access_id [auto_assign <value (1-250)>]] [ethernet { vlan <vlanid (1-4094)> source_mac <macaddr> destination_mac <macaddr> 802.1p <value (0-7)> ethernet_type <hex (0x0-0xffff)>} ip { source_ip <ipaddr> destination_ip <ipaddr> dscp <value (0-63)>} [icmp { type <value (0-255)> code <value (0-255)>} igmp { type <value (0-255)>} tcp { src_port <value (0-65535)> dst_port <value (0-65535)> urg ack psh rst syn fin } udp { src_port <value (0-65535)> dst_port <value (0-65535)>} protocol_id <value(0-255)>]} packet_content { offset1 <hex (0x0-0xffffffff)> offset2 <hex (0x0-0xffffffff)> offset3 <hex (0x0-0xffffffff)> offset4 <hex (0x0-0xffffffff)>]} [port [<portlist> all]] [permit { replace_priority_with <value (0-7)> replace_dscp_with <value (0-63)> rx_rate { no_limit <value (64-1024000)>}}] mirror deny]] delete access_id <value (1-250)>]

Description	The config access_profile ethernet command defines the rules used by the Switch to either filter or forward packets based on the Ethernet part of each packet header.
Parameters	<p><i>profile_id</i> <value 1-50> – Specifies the access profile id to be configured with this command. This value is assigned to the access profile when it is created with the create access_profile command. The lower the profile ID, the higher the priority the rule will be given.</p> <p><i>[add delete] access_id</i> <value 1-65535> – Adds or deletes an additional rule to the above specified access profile. The value specifies the relative priority of the additional rule. Up to 65535 rules may be configured for the Ethernet access profile.</p> <ul style="list-style-type: none"> • <i>auto_assign</i> – Configures the Switch to automatically assign a numerical value (between 1 and 65535) for the rule being configured. <p><i>ethernet</i> – Specifies that the Switch examine only the layer 2 part of each packet to determine if it is to be filtered or forwarded based on one or more of the following:</p> <ul style="list-style-type: none"> • <i>vlan</i> <vlanid 1-4094> – Specifies that the access profile applies only to this previously created VLAN. • <i>source_mac</i> <macaddr> – Specifies that the access profile applies only to packets with this source MAC address. MAC address entries may be made in the following format: 000000000000-FFFFFFFFFFFFFF. • <i>destination_mac</i> <macaddr> – Specifies that the access profile applies only to packets with this destination MAC address. MAC address entries may be made in the following format: 000000000000-FFFFFFFFFFFFFF • <i>802.1p</i> <value 0-7> – Specifies that the access profile applies only to packets with this 802.1p priority value. • <i>ethernet_type</i> <hex 0x05dd-0xffff> – Specifies that the access profile applies only to packets with this hexadecimal 802.1Q Ethernet type value in the packet header. <p><i>ports</i> <portlist> - The access profile for Ethernet may be defined for each port on the Switch.</p> <ul style="list-style-type: none"> • <i>mirror</i> – Specifies the action to mirror before being forwarded by the Switch. • <i>replace_dscp_with</i> <value 0-63> – Specifies a value to be written to the DSCP field of an incoming packet that meets the criteria specified in the first part of the command. This value will over-write the value in the DSCP field of the packet. • <i>rx_rate</i> <value 64-1024000> – Specifies the rate limit to limit Rx bandwidth for for the profile being configured. This rate is implemented using the following equation – 1 value = 64kbit/sec. (ex. If the user selects a rx rate limit of 10 then the ingress rate is 640kbit/sec.) The user may select a value between 64- 1024000 or no limit. The default setting is no limit. <p><i>deny</i> – Specifies that packets that do not match the access profile are not permitted to be forwarded by the Switch and will be filtered.</p> <p><i>ip</i> – Specifies that the Switch examine the IP fields in each packet to determine if it will be either forwarded or filtered based on one or more of the following:</p>

- *source_ip* <ipaddr> – Specifies that the access profile applies only to packets with this source IP address.
- *protocol_id* <value 0-255> – Specifies that the Switch examine the Protocol field in each packet and if this field contains the value entered here, apply the appropriate rules.
- *destination_ip* <ipaddr> – Specifies that the access profile applies only to packets with this destination IP address.
- *dscp* <value 0-63> – Specifies that the access profile applies only to packets that have this value in their Type-of-Service (DiffServ code point, DSCP) field in their IP packet header.
- *icmp* – Specifies that the Switch examine the protocol field in each frame's header and it should match Internet Control Message Protocol (ICMP).
- *type* – Specifies that the Switch examine each frame's ICMP Type field.
- *code* – Specifies that the Switch examine each frame's ICMP Code field.
- *igmp* – Specifies that the Switch examine each frame's protocol and it should match Internet Group Management Protocol (IGMP) field.
- *type* – Specifies that the Switch examine each frame's IGMP Type field.
- *tcp* - Specifies that the Switch examine each frame's protocol and it should match Transport Control Protocol (TCP) field.
- *src_port* <value 0-65535> – Specifies that the access profile applies only to packets that have this TCP source port in their TCP header.
- *dst_port* <value 0-65535> – Specifies that the access profile applies only to packets that have this TCP destination port in their TCP header.
- *flag* {+ | -} {urg | ack | psh | rst | syn | fin } – Specifies the appropriate flag parameter. All incoming packets have TCP flag bits associated with them which are parts of a packet that determine what to do with the packet. The user may deny packets by denying certain flag bits within the packets.
To specify flag bits that should be "1" type + and the flag bit name, to specify bits that should be "0" type – and the flag bit name.
- *udp* – Specifies that the Switch examine the protocol field in each packet and it should match User Datagram Protocol (UDP).
- *src_port* <value 0-65535> – Specifies that the access profile applies only to packets that have this UDP source port in their header.
- *dst_port* <value 0-65535> – Specifies that the access profile applies only to packets that have this UDP destination port in their header.

port [<portlist>] - The access profile for IP may be defined for each port on the Switch.

permit – Specifies that packets that match the access profile are permitted to be forwarded by the Switch.

- *mirror* – Specifies the action to mirror before being

forwarded by the Switch.

- *replace_dscp_with* <value 0-63> – Specifies a value to be written to the DSCP field of an incoming packet that meets the criteria specified in the first part of the command. This value will over-write the value in the DSCP field of the packet.

rx_rate <value 64-1024000> – Specifies the rate limit to limit Rx bandwidth for for the profile being configured. This rate is implemented using the following equation – 1 value = 64kbit/sec. (ex. If the user selects a rx rate limit of 10 then the ingress rate is 640kbit/sec.) The user may select a value between 64- 1024000 or no limit. The default setting is no limit.

Restrictions

Only administrator or operate-level users can issue this command.

Example usage:

To configure a rule for the Ethernet access profile:

```
DES-1210-28/ME:5# config access_profile profile_id 2 add access_id 2 ip
protocol_id 2 ports 2 deny
```

```
Command: config access_profile profile_id 2 add access_id 2 ip protocol_id
2 ports 2 deny
```

Success.

```
DES-1210-28/ME:5#
```

delete access_profile

Purpose	To delete a previously created access profile
Syntax	delete access_profile profile_id <value 1-50>
Description	The delete access_profile command deletes a previously created access profile on the Switch.
Parameters	<i>profile_id</i> <value 1-50> – Specifies the access profile to be deleted.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To delete the access profile with a profile ID of 1:

```
DES-1210-28/ME:5# delete access_profile profile_id 1
```

```
Command: delete access_profile profile_id 1
```

Success.

```
DES-1210-28/ME:5#
```

show access_profile

Purpose	To display the currently configured access profiles on the Switch.
Syntax	show access_profile {profile_id <value 1-50>}
Description	The show access_profile command displays the currently

	configured access profiles.
Parameters	<i>profile_id</i> <value 1-50> – Specifies the access profile to be displayed. This value is assigned to the access profile when it is created with the create access_profile command. If the <i>profile_id</i> parameter is omitted, all access profile entries are displayed.
Restrictions	None.

Example usage:

To display the currently configured access profiles which profile id is 1 on the Switch:

```
DES-1210-28/ME:5# show access_profile profile_id 1
Command: show access_profile profile_id 1

Access Profile Table

Access Profile ID: 1      Type: Ethernet
-----
Mask Option:
VLAN 802.1p
-----

DES-1210-28/ME:5#
```

create cpu_access_profile

Purpose	To create an access profile on the Switch by examining the Ethernet part of the packet header. Masks entered are combined with the values the Switch finds in the specified frame header fields. Specific values for the rules are entered using the config access_profile command, below.
Syntax	create cpu_access_profile [ethernet {vlan source_mac <macmask> destination_mac <macmask> 802.1p ethernet_type} ip {source_ip_mask <netmask> destination_ip_mask <netmask> dscp [icmp {type code} igmp {type} tcp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)> flag_mask} udp {src_port_mask <hex (0x0-0xffff)> dst_port_mask <hex (0x0-0xffff)>} protocol_id_mask <hex (0x0-0xff)>}]] profile_id <value (1-3)>
Description	The create cpu_access_profile command is used to create CPU access list rules on the Switch.
Parameters	<p><i>ethernet</i> - Specifies that the Switch examines the layer 2 part of each packet header with emphasis on one or more of the following:</p> <ul style="list-style-type: none"> • <i>vlan</i> – Specifies a VLAN mask. • <i>source_mac</i> <macmask > – Specifies the source MAC mask. • <i>destination_mac</i> <macmask> – Specifies the destination MAC mask. • <i>802.1p</i> – Specifies 802.1p priority tag mask.

ethernet_type – Specifies the Ethernet type mask.

ip - Specifies that the Switch examines the IP fields in each packet with special emphasis on one or more of the following:

- *type* – Specifies that the Switch examine each frame's ICMP Type field.
- *code* – Specifies that the Switch examine each frame's ICMP code field.
- *type* – Specifies that the Switch examine each frame's IGMP Type field.

tcp – Specifies that the Switch examines each frames protocol field and its value must be 6 (Transmission Control Protocol-TCP) for the action to take place.

- *src_port_mask* <hex 0x0-0xffff> – Specifies the TCP port mask for the source port.
- *dst_port_mask* <hex 0x0-0xffff> – Specifies the TCP port mask for the destination port.
- *flag_mask* - Specifies the appropriate flag.

udp – Specifies that the Switch examines each frame's protocol field and it's value must be 17 (User Datagram Protocol-UDP) in order for the action to take place.

- *src_port_mask* <0x0-0xffff> – Specifies the UDP port mask for the source port.
- *dst_port_mask* <0x0-0xffff> – Specifies the UDP port mask for the destination port mask.
- *protocol_id_mask* <0x0-0xffff> – Specifies the protocol id mask.
- *source_ip_mask* <netmask> – Specifies the source IP mask.
- *destination_ip_mask* <netmask> – Specifies the destination IP mask.

dscp – Specifies that the Switch examines the DiffServ Code Point (DSCP) field in each frame's header.

profile_id <value 1-3> – Specifies the cpu access profile to be displayed.

Restrictions

Only administrator or operate-level users can issue this command.

Example usage:

To create a CPU IP access profile:

```
DES-1210-28/ME:5# create cpu access_profile ip source_ip_mask 20.0.0.0
destination_ip_mask 10.0.0.0 dscp icmp type profile_id 2
Command: create cpu access_profile ip source_ip_mask 20.0.0.0
destination_ip_mask 10.0.0.0 dscp icmp type profile_id 2

Success.
DES-1210-28/ME:5#
```

config cpu_access_profile

Purpose	To configures the settings of cpu access profiles.
Syntax	config cpu_access_profile [profile_id <value (1-3)>] [add access_id [auto_assign <value (1-5)>]] [ethernet { vlan <vlanid (1-4094)> source_mac <macaddr> destination_mac

	<pre><macaddr> 802.1p <value (0-7)> ethernet_type <hex (0x0-0xffff)> ip {source_ip <ipaddr> destination_ip <ipaddr> dscp <value (0-63)> [icmp {type <value (0-255)> code <value (0-255)>} igmp {type <value (0-255)>} tcp {src_port <value (0-65535)> dst_port <value (0-65535)> urg ack psh rst syn fin} udp {src_port <value (0-65535)> dst_port <value (0-65535)>} protocol_id <value(0-255)>} [port [<portlist> all] [permit deny]] delete access_id <value (1-5)>]</pre>
Description	<p>The config cpu_access_profile command configures the settings of cpu access profiles.</p>
Parameters	<p><i>profile_id</i> <value 1-3> – Specifies the cpu access profile to be configured.</p> <p><i>[add delete]</i> – Add or delete the profile id.</p> <p><i>access_id</i> [<value 1-5> <i>auto_assign</i>] – Specifies the access id value or use auto assign.</p> <p><i>ethernet</i> – Specifies that the Switch examine only the layer 2 part of each packet to determine if it is to be filtered or forwarded based on one or more of the following:</p> <ul style="list-style-type: none"> • <i>802.1p</i> <value 0-7> – Specifies the 802.1p value. The range is between 0 and 7. • <i>destination_mac</i> <macaddr> – Specifies the destination MAC address. • <i>ethernet_type</i> – Specifies the Ethernet type mask. • <portlist> – Specifies the port or ports to be configured. • <i>source_mac</i> <macaddr> – Specifies the source MAC address. <p><i>vlan</i> <vlanid 1-4094> – Specifies the VLAN id.</p> <p><i>ip</i> – Specifies that the Switch examine the IP fields in each packet to determine if it will be either forwarded or filtered based on one or more of the following:</p> <ul style="list-style-type: none"> • <i>destination_ip</i> <ip_addr> – Specifies the destination IP address. • <i>dscp</i> <value 0-63> – Specifies the DSCP value. <p><i>icmp</i> – Specifies that the Switch examines the Protocol field in each frame's IP header , and that the value must be 1 (Internet Control Message Protocol- ICMP) for the action to take place.</p> <ul style="list-style-type: none"> • <i>code</i> <value 0-255> –Specifies that the Switch examine each frame's ICMP code field. • <i>type</i> <value 0-255> –Specifies that the Switch examine each frame's ICMP Type field. <p><i>igmp</i> – Specifies that the Switch examine each frame's protocol field and it must be 2 (Internet Group Management Protocol- IGMP) for the action to take place.</p> <ul style="list-style-type: none"> • <i>igmp_type</i> <value 0-255> – Specifies the IGMP type. <p><portlist> – Specifies the port or ports to be configured.</p> <p><i>protocol_id</i> <value 0-255> – Specifies the protocol id.</p> <p><i>source_ip</i> <ip_addr> –Specifies that the cpu access profile applies only to packets with this source IP address.</p> <p><i>Tcp</i> – Specifies that the Switch examines each frames protocol field and its value must be 6 (Transmission Control Protocol- TCP) for the action to take place</p> <ul style="list-style-type: none"> • <i>dst_port</i> <value 0-65535> –Specifies that the cpu access profile applies only to packets that have this TCP destination

port in their header.

- *flag <string>* – Specifies the appropriate flag parameter.
- *src_port <value 0-65535>* – Specifies that the cpu access profile applies only to packets that have this TCP source port in their header.

udp – Specifies that the Switch examines each frame's protocol field and its value must be 17 (User Datagram Protocol-UDP) in order for the action to take place.

- *dst_port <value 0-65535>* – Specifies that the CPU access profile applies only to packets that have this UDP destination port in their header.

src_port <value 0-65535> – Specifies that the CPU access profile applies only to packets that have this UDP source port in their header.

Restrictions

Only administrator or operate-level users can issue this command.

Example usage:

To configure a rule for the CPU IP access profile:

```
DES-1210-28/ME:5# config cpu access_profile profile_id 2 add access_id
auto_assignip destination_ip 10.48.100.2 ports 1-3 permit
Command: config cpu access_profile profile_id 2 add access_id auto_assign
ip destination_ip 10.48.100.2 ports 1-3 permit
```

Success.

```
DES-1210-28/ME:5#
```

delete cpu_access_profile

Purpose	To delete a previously created cpu access profile.
Syntax	delete cpu_access_profile profile_id <value 1-3>
Description	The delete cpu_access_profile command deletes a previously created access profile on the Switch.
Parameters	<i>profile_id <value 1-3></i> – Specifies the cpu access profile to be deleted.
Restrictions	Only administrator or operate-level users can issue this command.

Example usage:

To delete the CPU access profile with a profile ID of 1:

```
DES-1210-28/ME:5# delete cpu access_profile profile_id 1
Command: delete cpu access_profile profile_id 1
```

Success.

```
DES-1210-28/ME:5#
```

show cpu_access_profile

Purpose	To view the CPU access profile entry currently set in the Switch.
Syntax	show cpu_access_profile {profile_id <value 1-3>}
Description	The show cpu_access_profile command is used view the current CPU interface filtering entries set on the Switch.
Parameters	<i>profile_id <value 1-3></i> – Enter an integer between 1 and 3 that is used to identify the CPU access profile to be deleted with this command. This value is assigned to the access profile when it is created with the create cpu_access_profile command.
Restrictions	None.

Example usage:

To show the CPU filtering state on the Switch:

```
DES-1210-28/ME:5# show cpu_access_profile
Command: show cpu_access_profile
```

Access Profile Table

```
Access Profile ID: 1      Type: Ethernet
-----
```

```
Mask Option:
```

```
VLAN
-----
```

```
DES-1210-28/ME:5#
```

TRAFFIC SEGMENTATION COMMANDS

The Traffic Segmentation commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config traffic_segmentation	<portlist> forward_list [null <portlist>]
show traffic_segmentation	{<portlist>}

Each command is listed in detail, as follows:

config traffic_segmentation	
Purpose	To configure traffic segmentation on the Switch.
Syntax	config traffic_segmentation <portlist> forward_list [null <portlist>]
Description	The config traffic_segmentation command configures traffic segmentation on the Switch.
Parameters	<i><portlist></i> – A port or a port channel for which the current traffic segmentation configuration on the Switch is to be displayed. <i>forward_list</i> – Specifies a port or a port channel to receive forwarded frames from the source ports specified in the portlist, above.
Restrictions	Only administrator or operator-level users can issue this command.

Example usage:

To configure ports 1~5 to be able to forward frames to port 5~8:

```
DES-1210-28/ME:5# config traffic_segmentation 1-5 forward_list 5-8
Command: config traffic_segmentation 1-5 forward_list 5-8

Success.

DES-1210-28/ME:5#
```

show traffic_segmentation	
Purpose	To display the current traffic segmentation configuration on the Switch.
Syntax	show traffic_segmentation {<portlist>}
Description	The show traffic_segmentation command displays the current traffic segmentation configuration on the Switch.
Parameters	<i><portlist></i> – A port or a port channel for which the current traffic segmentation configuration on the Switch is to be displayed.

Restrictions	None.
--------------	-------

Example usage:

To display the current traffic segmentation configuration on the Switch:

```
DES-1210-28/ME:5# show traffic_segmentation
Command: show traffic_segmentation

Port Forward Portlist
-----
1      5-8
2      5-8
3      5-8
4      5-8
5      5-8
6      1-28
7      1-28
8      1-28
9      1-28
10     1-28
11     1-28
12     1-28
13     1-28
14     1-28
15     1-28
16     1-28
17     1-28
18     1-28
DES-1210-28/ME:5#
```

SAFEGUARD COMMANDS

The Safeguard commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameter
config safeguard_engine	state [enable disable]
show safeguard_engine	

Each command is listed in detail, as follows:

config safeguard_engine	
Purpose	To define the safeguard engine on the switch.
Syntax	config safeguard_engine state [enable disable]
Description	To define the safeguard_engine on the switch.
Parameters	<i>state [enable disable]</i> – enable and disable Safeguard engine on the Switch.
Restrictions	Only Administrator or operator-level users can issue this command.

Example usage:

To enable the safeguard engine on the switch:

```
DES-1210-28/ME:5# config safeguard_engine state enable
Command: config safeguard_engine state enable

Success!
DES-1210-28/ME:5#
```

show safeguard_engine	
Purpose	To show the safeguard engine status on the switch.
Syntax	show safeguard_engine
Description	To show the safeguard engine on the switch.
Parameters	None.
Restrictions	None.

Example usage:

To show the safeguard engine status on the switch:

```
DES-1210-28/ME:5# show safeguard_engine  
Command: show safeguard_engine
```

```
Safe Guard : Enabled  
DES-1210-28/ME:5#
```

DEVICE SPECIFICATIONS

This appendix contains the device specifications, and contains the following topics:

- Technical Specifications
- Cable Lengths

Technical Specifications

Performance	
Transmission Method	Store-and-forward
RAM Buffer	512Kbytes per device
Packet Filtering/ Forwarding Rate	Full-wire speed for all connections. 1,488,095 pps per port (for 1000Mbps)
MAC Address Learning	Automatic update. Supports 8K MAC address.
Priority Queues	4 Priority Queues per port.
Forwarding Table Age Time	Max age: 10–1000000 seconds. Default = 300.

Physical and Environmental	
AC Inputs	100 – 240 VAC, 50/60 Hz (internal universal power supply)
Power Consumption	16.2 watts maximum
DC Fans	0 pcs
Operating Temperature	-5 to 50 degrees Celsius
Storage Temperature	-40 to 70 degrees Celsius
Humidity	Storage: 0% to 95% non-condensing
Dimensions	440mm (W) x 140mm (D) x 44mm (H), 11-inch rack-mount width 1U height
Weight	3.8 kg (8.38 lb)
EMI	CE, CE LVD, UL/cUL
Safety	CSA International

General	
Standards	IEEE 802.3 10BASE-T Ethernet IEEE 802.3u 100BASE-TX Fast Ethernet IEEE 802.3z Gigabit Ethernet IEEE 802.1Q Tagged VLAN IEEE 802.1P Tagged Packets IEEE 802.3ab 1000BASE-T IEEE 802.3x Full-duplex Flow Control ANSI/IEEE 802.3 NWay auto-negotiation
Protocols	CSMA/CD
Data Transfer Rates Ethernet: Fast Ethernet: Gigabit Ethernet:	Half-duplex Full-duplex 10 Mbps 20 Mbps 100 Mbps 200 Mbps 2000 Mbps (Full duplex only)
Topology	Star

Network Cables	
10BASE-T:	UTP Category 3, 4, 5 (100 meters max.) EIA/TIA- 568 150-ohm STP (100 meters max.)
100BASE-TX:	UTP Cat. 5 (100 meters max.) EIA/TIA-568 150-ohm STP (100 meters max.)
1000BASE-T:	UTP Cat. 5e (100 meters max.) UTP Cat. 5 (100 meters max.) EIA/TIA-568B 150-ohm STP (100 meters max.)
1000BASE-LX:	Single-mode fiber module (10km)
1000BASE-SX:	Multi-mode fiber module (550m)
1000BASE-LHX:	Single-mode fiber module (40km)
1000BASE-ZX:	Single-mode fiber module (80km)
Mini-GBIC:	SFP Transceiver for 1000BASE-LX Single-mode fiber module (10km) SFP Transceiver for 1000BASE-SX Multi-mode fiber module (550m) SFP Transceiver for 1000BASE-LHX Single-mode fiber module (40km) SFP Transceiver for 1000BASE-ZX Single-mode fiber module (80km)
Number of Ports:	24 x 10/100 Mbps ports 2 x 100/1000Mbps SFP ports 2 x combo 10/100/1000/SFP ports

Cable Lengths

Use the following table to as a guide for the maximum cable lengths:

Standard	Media Type	Maximum Distance
Mini GBIC	DEM-310GT: SFP Transceiver for 1000BASE-LX, Single-mode fiber module	10km
	DEM-311GT: SFP Transceiver for 1000BASE-SX, Multi-mode fiber module	550m
	DEM-314GT: SFP Transceiver for 1000BASE-LHX, Single-mode fiber module	40km
	DEM-315GT: SFP Transceiver for 1000BASE-ZX, Single-mode fiber module	80km
1000BASE-T	Category 5e UTP Cable	100m
	Category 5 UTP Cable (1000 Mbps)	
100BASE-TX	Category 5 UTP Cable (100 Mbps)	100m
10BASE-T	Category 3 UTP Cable (10 Mbps)	100m